




L550/L555

Basic Guide

Ink Bottle Codes

	BK	C	M	Y
	Black	Cyan	Magenta	Yellow
	T6641	T6642	T6643	T6644

Contents

Introduction..... 2

Where to Find Information.	2
Caution, Important and Note.	2
Using Epson Connect Service.	2

Safety Instructions..... 2

Control Panel Overview..... 3

Buttons and LCD.	4
Lights.	5

Paper and Media Handling..... 5

Selecting Paper.	5
Loading Paper.	5
Placing Originals.	6
Automatic Document Feeder (ADF).	6
Scanner glass.	7

Copying..... 8

Scanning..... 8

Faxing..... 8

Introducing FAX Utility.	8
Connecting to a Phone Line.	9
About a phone cable.	9
Using the phone line for fax only.	9
Sharing line with phone device.	9
Checking the fax connection.	9
Setting Up Fax Features.	10
Setting up speed dial entries.	10
Setting up group dial entries.	10
Sending Faxes.	11
Receiving Faxes.	11
Printing Reports.	12

Refilling Ink..... 12

Safety instructions.	12
Precautions.	12
Checking the Ink Levels.	13
Refilling the Ink Tanks.	13

Transporting the Product..... 15

Basic Troubleshooting..... 16

Error Messages.	16
Paper Jams.	17
Removing jammed paper from inside the product.	18
Removing jammed paper from the Automatic Document Feeder (ADF).	18
Print Quality Help.	19
Faxing Help.	19

Where To Get Help..... 20

Technical Support Web Site.	20
----------------------------------	----

Introduction

Where to Find Information

The latest version of the following manuals are available on the Epson support website.

<http://www.epson.eu/Support> (Europe)

<http://support.epson.net/> (other than Europe)

Start Here (paper):

Provides you with information on setting up the product and installing the software.

Basic Guide (paper):

Provides you with basic information when you are using the product without a computer. This manual may not be included depending on the model and region.

User's Guide (PDF):

Provides you with detailed operating, safety, and troubleshooting instructions. See this guide when using this product with a computer.
To view the PDF manual, you need Adobe Acrobat Reader 5.0 or later, or Adobe Reader.

Network Guide (HTML):

Provides network administrators with information on both the printer driver and network settings.

Caution, Important and Note

Caution, Important, and Note in this manual are indicated as below and have the following meaning.



Caution

must be followed carefully to avoid bodily injury.



Important

must be observed to avoid damage to your equipment.

Note

contain useful tips and restrictions on product operation.

Using Epson Connect Service

Using Epson Connect, you can easily print directly from your smartphone or tablet. The services available vary by product. For more information about the printing and other services, visit the following URL:

<https://www.epsonconnect.com/> (Epson Connect portal site)

<http://www.epsonconnect.eu> (Europe only)

You can view the Epson Connect guide by double-clicking the  shortcut icon on the desktop.



Safety Instructions

Read and follow these instructions to ensure safe use of this product. Make sure you keep this guide for future reference. Also, be sure to follow all warnings and instructions marked on the product.


- Use only the power cord supplied with the product and do not use the cord with any other equipment. Use of other cords with this product or the use of the supplied power cord with other equipment may result in fire or electric shock.
- Be sure your AC power cord meets the relevant local safety standard.

Control Panel Overview


- ❑ Never disassemble, modify, or attempt to repair the power cord, plug, printer unit, scanner unit, or options by yourself, except as specifically explained in the product’s guides.
- ❑ Unplug the product and refer servicing to qualified service personnel under the following conditions: The power cord or plug is damaged; liquid has entered the product; the product has been dropped or the casing damaged; the product does not operate normally or exhibits a distinct change in performance. Do not adjust controls that are not covered by the operating instructions.
- ❑ Place the product near a wall outlet where the plug can be easily unplugged.
- ❑ Do not place or store the product outdoors, near excessive dirt or dust, water, heat sources, or in locations subject to shocks, vibrations, high temperature or humidity.
- ❑ Take care not to spill liquid on the product and not to handle the product with wet hands.
- ❑ Keep this product at least 22 cm away from cardiac pacemakers. Radio waves from this product may adversely affect the operation of cardiac pacemakers.
- ❑ If the LCD screen is damaged, contact your dealer. If the liquid crystal solution gets on your hands, wash them thoroughly with soap and water. If the liquid crystal solution gets into your eyes, flush them immediately with water. If discomfort or vision problems remain after a thorough flushing, see a doctor immediately.
- ❑ Avoid using a telephone during an electrical storm. There may be a remote risk of electric shock from lightning.
- ❑ Do not use a telephone to report a gas leak in the vicinity of the leak.

Note:
The following provides safety instructions for ink.
➔ “Refilling Ink” on page 12

Control Panel Overview



Control Panel Overview





* emits a beep.

Buttons and LCD

Buttons	Function
a	Turns the product on and off
b	Enters copy mode.
c	Enters fax mode.
d	Enters scan mode.
e	- LCD screen (monochrome 2-line display)
f	Press , , , to select menus. Press OK to confirm the setting you have selected and go to next screen. When typing a fax number, acts as a backspace key, and inserts a space.
g	0-9,*,# Specifies the date/time or the number of copies, as well as fax numbers. Enters alphanumeric characters and switches between uppercase, lowercase, and numbers each time it is pressed. Press 1 symb to enter symbols such as the sharp sign (#), plus (+), and apostrophe (').
h	Displays speed dial/group dial lists. Press again to switch lists.
i	Displays the last number dialed. When entering numbers in fax mode, this inserts a pause symbol (-) that acts as a brief pause during dialing.
j	Stops the ongoing operation or initializes the current settings. If this button is pressed to cancel copying, scanning, or faxing while the ADF is in use, all originals in the ADF will be fed out.
k	Displays detailed settings for each mode.
l	Cancels/returns to the previous menu.
m	Provided with Wi-Fi-capable models only. Displays the Wi-Fi Setup menus that allow you to set up the product wirelessly. For instructions on using the menus, see the Network Guide.
n	Start copying/faxing in black and white.
o	Start copying/faxing in color.

Lights

Lights	Function
	On when the product is on. Flashes when the product is receiving data, printing/copying/scanning/faxing, charging ink, or cleaning the print head.
	Stays on while the product is connected to a Wi-Fi network. Flashes while the Wi-Fi network settings are being made.*
ADF	On when originals are detected in the ADF.

* The availability of this part varies by product.

Paper and Media Handling

Selecting Paper


The product automatically adjusts itself for the type of paper you select in your print settings. That is why the paper type setting is so important. It tells your product what kind of paper you are using and adjusts the ink coverage accordingly. The table below lists the settings you should choose for your paper.

For this paper	LCD paper type
Plain paper	Plain Paper
Epson Bright White Ink Jet Paper	


Loading Paper

Follow these steps to load paper:

- 1 Flip the feeder guard forward.



- 2 Slide out the paper support and the output tray and then raise the stopper.




Note:
Leave enough space in front of the product for the paper to be fully ejected.

- 3 Slide the edge guide to the left.

Paper and Media Handling


- 4** Load paper with the printable side up, against the right side of the rear paper feed.



Note:

- Fan and align the edges of the paper before loading.
- The printable side is often whiter or brighter than the other side.
- Always load paper into the rear paper feed short edge first, even when you are printing landscape-oriented pictures.
- You can use the following sizes of paper with binding holes: A4, A5, A6, Legal, Letter. Load only 1 sheet of paper at a time.


- 5** Slide the edge guide against the left edge of the paper, but not too tightly.



Note:

For plain paper, do not load paper above the ▼ arrow mark inside the edge guide.
For Epson special media, make sure the number of sheets is less than the limit specified for the media.

- 6** Flip the feeder guard back.



Note:

For instructions on loading media other than plain paper, see the PDF User's Guide.

Placing Originals

Automatic Document Feeder (ADF)

You can load your original documents in the Automatic Document Feeder (ADF) to copy, scan, or fax multiple pages quickly. You can use the following originals in the ADF.

Size	A4/Letter/Legal
Type	Plain paper
Weight	64 g/m ² to 95 g/m ²
Capacity	Total thickness of 3 mm, up to about 30 sheets (Letter, A4) 10 sheets (Legal)



Important:


To prevent paper jams, avoid the following documents. For these types, use the scanner glass.

- Documents held together with paper clips, staples, etc.
- Documents that have tape or paper stuck to them.
- Photos, OHPs, or thermal transfer paper.
- Paper that is torn, wrinkled, or has holes.


Paper and Media Handling

- 1 Make sure that there are no originals on the scanner glass. The ADF may not detect documents in the feeder if there are originals on the scanner glass.


- 2 Tap the originals on a flat surface to even the edges.




- 3 Slide the edge guide on the Automatic Document Feeder.



- 4 Insert the originals face-up and short edge first into the Automatic Document Feeder.





- 5 Slide the edge guide until it is flush with the originals.




- 6 Check that the ADF light in the control panel is on.

Note:


- ❑ The ADF light may stay off if there is any other original on the scanner glass. If you press  in this case, the original on the scanner glass will be copied, scanned, or faxed instead of the originals in the ADF.
- ❑ The ADF light will not turn on when the product is in sleep mode. Press any button other than  to recover from sleep mode. It may take some time for the light to turn on after recovery from sleep mode.
- ❑ Be careful not to let any foreign object get inside the hole on the left front corner of the scanner glass. Doing so may prevent the ADF from operating.
- ❑ When you use the copy function with the Automatic Document Feeder (ADF), the print settings are fixed at Reduce/Enlarge - **Actual Size**, Paper Type - **Plain Paper**, and Paper Size - **A4/Legal**. The print is cropped if you copy an original larger than A4/Legal.

Scanner glass

- 1 Open the document cover and place your original face-down on the scanner glass.



- 2 Slide the original to the corner.











- 3 Close the cover gently.

Copying




Copying

Follow the steps below to copy documents.

- 1 Load paper.
➔ “Loading Paper” on page 5
- 2 Place your original(s) in the Automatic Document Feeder or on the scanner glass.
➔ “Placing Originals” on page 6
- 3 Press  to enter the copy mode.
- 4 Press  or  to set the number of copies.
- 5 Press  to display the copy setting menus.
- 6 Select the appropriate copy settings such as layout, paper size, paper type, and quality. Use  or  to select a setting item and then press **OK**. When finished, press  again to return to the copy mode top screen.
- 7 Press one of the  buttons to start copying.

Scanning

You can scan documents and send the scanned image from the product to a connected computer. Make sure you have installed software for the product on your computer and connected to the computer.

- 1 Place your original(s) in the Automatic Document Feeder or on the scanner glass.
➔ “Placing Originals” on page 6
- 2 Press  to enter the scan mode.
- 3 Select a scan menu item. Use  or  to select a menu, and press **OK**.

- 4 Select your computer.

Note:

- If the product is connected to a network, you can select the computer to which you want to save the scanned image.
- You can change the computer name displayed on the control panel using Epson Event Manager.

- 5 Press **OK** to start scanning.

Note:

For more information on other scan functions and the scan mode menu list, see the PDF User’s Guide.

Your scanned image is saved.

Faxing

Introducing FAX Utility

FAX Utility is a software capable of transmitting data such as documents, drawings, and tables created using a word processing or spreadsheet application directly by fax, without printing. Use the following procedure to run the utility.

Windows

Click the start button (Windows 7 and Vista) or click **Start** (Windows XP), point to **All Programs**, select **Epson Software**, and then click **FAX Utility**.

Mac OS X

Click **System Preference**, click **Print & Fax** or **Print & Scan**, and then select **FAX** (your product) from **Printer**. Then click as follows;

Mac OS X 10.6.x, 10.7.x: **Option & Supplies - Utility - Open Printer Utility**

Mac OS X 10.5.x: **Open Print Queue - Utility**

Note:

For more details, see the online help for FAX Utility.

Connecting to a Phone Line

About a phone cable


Use a phone cable with the following interface specification.

- ❑ RJ-11 Phone Line
- ❑ RJ-11 Telephone set connection

Depending on the area, a phone cable may be included with the product. If so, use that cable.

Using the phone line for fax only

- 1 Connect a phone cable leading from a telephone wall jack to the LINE port.



- 2 Make sure **Auto Answer** is set to **On**.


➔ "Receiving Faxes" on page 11

! **Important:**


If you do not connect an external telephone to the product, make sure you turn on auto answer. Otherwise, you cannot receive faxes.

Sharing line with phone device


- 1 Connect a phone cable leading from a telephone wall jack to the LINE port.



- 2 Remove the cap.



- 3 Connect a phone or answering machine to the EXT. port.








Note:

See the PDF User's Guide for other connection methods.

Checking the fax connection

You can check whether the product is ready to send or receive faxes.

Faxing

- 1 Load plain paper.
➔ “Loading Paper” on page 5
- 2 Press  to enter the fax mode.
- 3 Press  to display the menus.
- 4 Select **Fax Settings > Check Fax Connection**.
Use  or  to select a menu, and press **OK**.
- 5 Press one of the  buttons to print the report.





Note:



If an errors are reported, try the solutions in the report.

Setting Up Fax Features

Setting up speed dial entries




You can create a speed dial list allowing you to select fax recipient numbers quickly when faxing. Up to 60 combined speed dial and group dial entries can be registered.

- 1 Press  to enter the fax mode.
- 2 Press  to display the menus.
- 3 Select the menu shown below. Use  or  to select a menu, and press **OK**.

Select **Fax Settings > Speed Dial Setup**.
- 4 Select **Create**. You see the available speed dial entry numbers.
- 5 Select the speed dial entry number that you want to register. Use  or  to select a number, and press **OK**. You can register up to 60 entries.

- 6 Use the numeric keypad to enter a phone number, and press **OK**. You can enter up to 64 digits.

Note:

- Press  to enter a space. Press  to delete numbers. Press  to enter a hyphen (-).
- A hyphen (“-”) causes a slight pause when dialing. Only include it in phone numbers when a pause is necessary. Spaces entered between numbers are ignored when dialing.


- 7 Enter a name to identify the speed dial entry. You can enter up to 30 characters.

Press **OK** to register the name.

Setting up group dial entries

You can add speed dial entries to a group, allowing you to send a fax to multiple recipients at the same time. Up to 60 combined speed dial and group dial entries can be entered.

- 1 Press  to enter the fax mode.
- 2 Press  to display the menus.
- 3 Select the menu shown below. Use  or  to select a menu, and press **OK**.

Select **Fax Settings > Group Dial Setup**.
- 4 Select **Create**. You see the available group dial entry numbers.
- 5 Select the group dial entry number that you want to register. Use  or  to select a number, and press **OK**.
- 6 Enter a name to identify the group dial entry. You can enter up to 30 characters.

Press **OK** to register the name.


- 7** Select a speed dial entry that you want to register in the group dial list. Use ▲ or ▼ to select the entry and do the following to add it to the group.

Press ✕. When you want to cancel the selection, press ✕ again.

- 8** Repeat step 7 to add other speed dial entries to the group dial list. You can register up to 30 speed dial entries in a group dial.




- 9** Press **OK** to finish creating a group dial list.


Sending Faxes

- 1** Place your original(s) in the Automatic Document Feeder or on the scanner glass.
➔ “Placing Originals” on page 6
- 2** Press  to enter the fax mode.
- 3** Use the keys on the numeric keypad to enter the fax number. You can enter up to 64 digits.


If you want to send the fax to more than one recipient, press **OK** after entering a one fax number, and select **Yes** to add another fax number.

Note:

- To display the last fax number you used, press .
- You can change fax quality and contrast settings. When finished, press  again to return to the fax mode top screen.
Press  and select **Quality** or **Contrast**.
- Make sure you have entered the header information. Some fax machines automatically reject incoming faxes that do not include header information.

- 4** Press one of the  buttons to start sending.


Note:


If the fax number is busy or there is some problem, this product redials after one minute. Press  to redial immediately.

Receiving Faxes

Follow the instructions to make settings to receive faxes automatically. For instructions on receiving faxes manually, see the PDF User’s Guide.

- 1** Load plain paper in the rear paper feed.
➔ “Loading Paper” on page 5

- 2** Press  to enter the fax mode.


- 3** Press  to display the menus.

- 4** Make sure Auto Answer is set to On.

Fax Settings > Send/Receive Setup > Auto Answer > On

Note:

- When an answering machine is connected directly to this product, make sure you set **Rings to Answer** correctly using the following procedure.
- Depending on the region, **Rings to Answer** may be unavailable.

- 5** Press  and ▼ to select **Communication** and press **OK**.

- 6** Select **Rings to Answer** and press **OK**.

- 7** Press ▲ or ▼ to select the number of rings and press **OK**.

! Important:





Set more rings than needed for the answering machine to pick up. If it is set to pick up on the fourth ring, set the product to pick up on the fifth ring or later. Otherwise the answering machine cannot receive voice calls.

Note:

When you receive a call and the other party is a fax, the product receives the fax automatically even if the answering machine picks up the call. If you pick up the phone, wait until the LCD screen displays a message saying that a connection has been made before you hang up. If the other party is a caller, the phone can be used as normal or a message can be left on the answering machine.

Printing Reports

Follow the instructions below to print a fax report.


- 1 Load plain paper in the rear paper feed.
➔ “Loading Paper” on page 5
- 2 Press  to enter the fax mode.
- 3 Press  to display the menus.
- 4 Select the menu shown below. Use  or  to select a menu, and press **OK**.

Select **Fax Settings > Print Report**.

- 5 Select the item you want to print.

Note:

Only **Fax Log** can be viewed on the screen.

- 6 Press one of the  buttons to print the report you selected.

Note:

For more information on other fax functions and the fax mode menu list, see the *PDF User's Guide*.

Refilling Ink

Safety instructions

- Keep ink bottles and the ink tank unit out of the reach of children. Do not allow children to drink from or handle the ink bottles and ink bottle cap.
- Do not tilt or shake an ink bottle after removing its seal; this can cause leakage.
- Be careful not to touch any ink when you handle the ink tanks, ink tank caps, and opened ink bottles or ink bottle caps.
If ink gets on your skin, wash the area thoroughly with soap and water.
If ink gets into your eyes, flush them immediately with water. If discomfort or vision problems continue after a thorough flushing, see a doctor immediately.
If ink gets into your mouth, spit it out immediately and see a doctor right away.

Precautions

- Use ink bottles with the correct part number for this product.
➔ “Ink Bottle Codes” inside the front cover
- Epson recommends the use of genuine Epson ink bottles. Epson cannot guarantee the quality or reliability of non-genuine ink. The use of non-genuine ink may cause damage that is not covered by Epson’s warranties, and under certain circumstances, may cause erratic product behavior.
- Other products not manufactured by Epson may cause damage that is not covered by Epson’s warranties, and under certain circumstances, may cause erratic product behavior.
- This product requires careful handling of ink. Ink may splatter when the ink tanks are filled or refilled with ink. If ink gets on your clothes or belongings, it may not come off.

Refilling Ink

- ❑ To maintain optimum print head performance, some ink is consumed from all ink tanks not only during printing but also during maintenance operation such as print head cleaning.
- ❑ Do not open the ink bottle package until you are ready to fill the ink tank. The ink bottle is vacuum packed to maintain its reliability. If you leave an ink bottle unpacked for a long time before using it, normal printing may not be possible.
- ❑ Do not continue printing when the ink level is below the lower limit on the ink tank. Continued use of the product when the ink level is below the lower limit could damage the product. Epson recommends filling all ink tanks to the upper line when the product is not operating to reset the ink levels. If the ink tank is filled as specified above, this product provides an alert and stops operating at the estimated time so that the ink levels do not fall below the lower limit on the ink tank.
- ❑ Store the ink bottles in the same environment as the product. When storing or transporting an ink bottle after removing its seal, do not tilt the bottle and do not subject it to impacts or temperature changes. Otherwise, ink may leak even if the cap on the ink bottle is tightened securely. Be sure to keep the ink bottle upright when tightening the cap, and take measures to prevent ink from leaking when you transport the bottle.

Checking the Ink Levels

To confirm the actual ink remaining, visually check the ink levels in the product's ink tanks.


! Important:


If the ink level is below the lower limit on the ink tank, fill it to the upper line on the ink tank. Continued use of the product when the ink level is below the lower limit on the tank could damage the product.

Refilling the Ink Tanks

Note:

The illustrations show how to refill the cyan ink. However, the instructions are the same for all of the inks.


- 1 Make sure the  light is on, but not flashing.
- 2 Unhook the ink tank unit from the product and lay it down.



Note:

Do not pull the tubes.


- 3 Open the ink tank unit cover, and then remove the cap of the ink tank.



Note:

- ❑ *Be careful not to spill any ink.*
- ❑ *Make sure that the color of the ink tank matches the ink color that you want to refill.*

- 4 Snap off the top of the cap, remove the cap of the ink bottle, remove the seal from the bottle, and then install the cap.




Refilling Ink

! Important:
Install the ink bottle cap tightly; otherwise ink may leak.




Note:
Do not dispose of the top of the cap. If any ink remains in the ink bottle after refilling the tank, use the top of the cap to seal the ink bottle cap.


5 Refill the ink tank with the correct colored ink up to the upper line on the ink tank.



Note:
If any ink remains in the ink bottle after filling the ink tank up to the upper line, install the cap securely and store the ink bottle upright for later use.




6 Install the cap onto the ink tank securely.




7 Repeat steps 3 to 6 for each ink bottle.

8 Close the ink tank unit cover.



9 Hook the ink tank unit onto the product.



Note:

- If the product indicates that ink levels must be reset, follow the on-screen instructions.
- Even if you do not have new ink bottles and one or more ink tanks are not filled up to the upper line on the ink tank, you can continue using the product. To keep your product operating at its best, however, fill all ink tanks with ink up to the upper line immediately.

Transporting the Product

Transporting the Product

If you move the product some distance, you need to prepare it for transportation in its original box or one of a similar size.


! Important:

- ❑ When storing or transporting the product, avoid tilting it, placing it vertically, or turning it upside down; otherwise ink may leak.
- ❑ When storing or transporting an ink bottle after removing its seal, do not tilt the bottle and do not subject it to impacts or temperature changes. Otherwise, ink may leak even if the cap on the ink bottle is tightened securely. Be sure to keep the ink bottle upright when tightening the cap, and take measures to prevent ink from leaking when you transport the bottle.

1 Remove all paper from the rear paper feed and make sure the product is off.

2 Close the paper support and the output tray.

3 Open the scanner unit and make sure the print head is in the home position on the right.




Note:

If the print head is not in the home position on the right, turn on the product and wait until the print head locks in the far right position. Then turn off the product.

4 Unplug the power cord from the outlet, then disconnect all cables from the product.


5 Secure the print head to the case with tape as shown, then close the scanner unit.




Note:

Do not place tape on the white flat cable inside the product.

6 Set the transportation lock to the locked (Transporting) position.




7 Unhook the ink tank unit from the product and lay it down, and then make sure to install the cap onto the ink tank securely.



Basic Troubleshooting

- 8** Install the covers that came with your product over the protruding parts of the ink tank, and then hook the ink tank unit onto the product.




- 9** Repack the product in the box, using the protective materials that came with it.



Important:

- ❑ Keep the product level during transport. Otherwise, ink may leak.
- ❑ After you move it, remove the tape securing the print head and the covers of ink tanks, then set the transportation lock to the unlocked (Printing) position. If you notice a decline in print quality, run a cleaning cycle or align the print head.
- ❑ Do not put opened ink bottles in the box with product.

Note:
Store the covers of the installed ink tanks at the side of the product for use when transporting the product.





Basic Troubleshooting

Error Messages

This section describes the meaning of messages displayed on the LCD screen.

Error Messages	Solutions
Paper jam Press OK. If the error does not clear, remove the paper by hand.	Remove the jammed paper. ➔ "Paper Jams" on page 17
Paper jam in the ADF. Remove the jammed paper.	
Communication error. Make sure the cable is connected, then try again.	Make sure the computer is connected correctly. If the error messages still appears, make sure that scanning software is installed on your computer and that the software settings are correct.

Basic Troubleshooting

Error Messages	Solutions
<p>Printer error Paper jam. Open the scanner unit and remove the paper, then turn off the printer. See your documentation.</p>	<p>Turn the product off and then back on. Make sure that no paper is still in the product. If the error message still appears, contact Epson support.</p>
<p>ADF Error. Remove any objects or documents inside ADF. Turn power off. See documentation.</p>	
<p>Printer error See your documentation.</p>	
<p>Scanner error See your documentation.</p>	<p>Turn the product off and then back on. If the error message still appears, contact Epson support.</p>
<p>A fax error has occurred. See your documentation.</p>	
<p>A printer's ink pad is nearing the end of its service life. Please contact Epson Support.</p>	<p>Press OK to resume printing. The message will be displayed until the ink pad is replaced.</p> <p>Contact Epson support to replace ink pads before the end of their service life. When the ink pads are saturated, the product stops and Epson support is required to continue printing.</p>
<p>A printer's ink pad is at the end of its service life. Please contact Epson Support.</p>	<p>Contact Epson support to replace the ink pad.</p>
<p>No dial tone. Fax job incomplete.</p>	<p>Make sure the phone cable is connected correctly and the phone line works.</p> <p>➔ "Connecting to a Phone Line" on page 9</p> <p>If you connected the product to a PBX (Private Branch Exchange) phone line or Terminal Adapter, turn off the Dial Tone Detection.</p> <p>➔ Press  and then . Then select Fax Settings > Communication > Dial Tone Detection.</p>
<p>Recovery Mode</p>	<p>The firmware update has failed. You will need to re-attempt the firmware update. Ready a USB cable and visit your local Epson website for further instructions.</p>

Paper Jams



Caution:

Never touch the buttons on the control panel while your hand is inside the product.



Important:


Be careful not to pull the cables or ink tubes, or touch other components inside the product unnecessarily. Otherwise, ink may leak or the product may be damaged.

Note:

- Cancel the print job if prompted by a message from the LCD screen or the printer driver.
- After you have removed the jammed paper, press the button indicated in the LCD screen.

Removing jammed paper from inside the product


- 1 Open the scanner unit.



! Important:
Do not lift up the scanner unit when the document cover is open.



- 2 Remove all of the paper inside, including any torn pieces.




- 3 Close the scanner unit slowly.

Removing jammed paper from the Automatic Document Feeder (ADF)


- 1 Remove the stack of paper from the ADF input tray.

- 2 Open the ADF cover.




! Important:
Make sure you open the ADF cover before removing jammed paper. If you do not open the cover, the product may be damaged.

- 3 Carefully remove the jammed paper.




- 4 Open the Automatic Document Feeder (ADF).




Basic Troubleshooting

- 5 Remove all of the paper inside, including any torn pieces.




- 6 Close the Automatic Document Feeder (ADF).

- 7 Raise the ADF input tray.



- 8 Carefully remove the jammed paper.




- 9 Return the ADF input tray to its original position, and close the ADF cover.

Print Quality Help

If you see banding (light lines), missing colors, or any other quality problems in your printouts, try the following solutions.

- Make sure you have loaded the paper and place your original correctly.
 - ➔ “Loading Paper” on page 5
 - ➔ “Placing Originals” on page 6
- Check the paper size settings and the paper type settings.
 - ➔ “Selecting Paper” on page 5
- The print head may be clogged. Perform a nozzle check first and then clean the print head. Press \equiv and select **Maintenance > Nozzle Check**.



- (a) OK
(b) Needs a head cleaning

Faxing Help

- Make sure the phone cable is connected correctly and check that the phone line works. You can check the line status by using the **Check Fax Connection** function.
 - ➔ “Connecting to a Phone Line” on page 9
- If the fax did not send, make sure that the recipient’s fax machine is turned on and working.
- If this product is not connected to a phone and you want to receive faxes automatically, make sure you turn on auto answer.
 - ➔ “Receiving Faxes” on page 11

Note:

For more solutions to faxing problems, see the online User’s Guide.

Where To Get Help

Technical Support Web Site

Epson's Technical Support Web Site provides help with problems that cannot be solved using the troubleshooting information in your product documentation. If you have a Web browser and can connect to the Internet, access the site at:

<http://support.epson.net/>
<http://www.epson.eu/Support> (Europe)

If you need the latest drivers, FAQs, manuals, or other downloadables, access the site at:

<http://www.epson.com>
<http://www.epson.eu/Support> (Europe)

Then, select the support section of your local Epson Web site.

Note:

If your Epson product is not operating properly and you cannot solve the problem using the troubleshooting information in your product documentation, contact Epson support services for assistance. See the User's Guide for Epson support information.

Copyright Notice

No part of this publication may be reproduced, stored in a retrieval system, or transmitted in any form or by any means, electronic, mechanical, photocopying, recording, or otherwise, without the prior written permission of Seiko Epson Corporation. The information contained herein is designed only for use with this product. Epson is not responsible for any use of this information as applied to other printers.

Neither Seiko Epson Corporation nor its affiliates shall be liable to the purchaser of this product or third parties for damages, losses, costs, or expenses incurred by the purchaser or third parties as a result of accident, misuse, or abuse of this product or unauthorized modifications, repairs, or alterations to this product, or (excluding the U.S.) failure to strictly comply with Seiko Epson Corporation's operating and maintenance instructions.

Seiko Epson Corporation shall not be liable for any damages or problems arising from the use of any options or any consumable products other than those designated as Original Epson Products or Epson Approved Products by Seiko Epson Corporation.

Seiko Epson Corporation shall not be held liable for any damage resulting from electromagnetic interference that occurs from the use of any interface cables other than those designated as Epson Approved Products by Seiko Epson Corporation.

EPSON® is a registered trademark, and EPSON EXCEED YOUR VISION or EXCEED YOUR VISION is a trademark of Seiko Epson Corporation.

General Notice: Other product names used herein are for identification purposes only and may be trademarks of their respective owners. Epson disclaims any and all rights in those marks.

© 2012 Seiko Epson Corporation. All rights reserved.
Printed in XXXXXX



412378600