

EPSON

User's Guide

L-300/200



CAMERA SET-UP

**STANDARD
OPERATION**

**ADVANCED
FUNCTIONS**

**DIRECT
PRINTING**

**ADDITIONAL
SETTINGS**

**ADDITIONAL
INFORMATION**

TROUBLE SHOOTING

**EPSON
INFORMATION**

CONTENTS

INSTRUCTION BOOK SYMBOLS	4
IMPORTANT SAFETY INSTRUCTIONS	5
WHEN USING THIS PRODUCT	5
WHEN USING THE STRAP	5
WHEN USING THE BATTERIES	6
FOR USERS IN HONG KONG	7
WHEN CHOOSING A POWER SOURCE	8
EPSON FEATURES	10
CAMERA SETUP	11
ITEMS	12
CHECKING THE PACKING CONTENTS	12
TOP VIEW	14
BATTERIES AND MEMORY CARD INSTALLATION	16
ACCESSING THE BATTERIES AND MEMORY CARD	16
HOW TO INSERT AND REMOVE THE MEMORY CARD	16
BATTERY SETUP	17
BATTERY LIFE INDICATOR	17
SETTING UP YOUR CAMERA	18
POWER ON/OFF	18
INITIAL SETTINGS	18
STANDARD OPERATION	19
HOLDING THE CAMERA / RELEASING THE SHUTTER	20
FULL & HALF SHUTTER BUTTON POSITIONS	21
CAMERA RANGE	21
THE IMAGE SYSTEM	22
TAKING PHOTOS USING THE LCD MONITOR	22
TURNING THE QUICK VIEW ON/OFF	23
USING THE VIEWFINDER-ONLY METHOD	24
IF THE CAPTURED IMAGE IS OUT OF FOCUS FRAME	26
OPTICAL ZOOM & DIGITAL ZOOM	27
IMAGE CAPTURE SETTINGS	28
CONFIRMING THE NUMBER OF PHOTOGRAPHS	29
FLASH CONTROL	30
USING THE SELF TIMER	31
PLAYBACK SYSTEM	32
ONE BY ONE PLAYBACK	32
DISPLAYING MULTIPLE IMAGES	33

LCD MONITOR IMAGE ENLARGEMENT	33
SLIDE SHOW	34
QUICK PHOTO REVIEW	35
DELETING FILES	36
DELETING A SINGLE PHOTO	36
DELETING ALL IMAGES	37
USING YOUR IMAGES	38
DISPLAYING ON A TV	38
EXPORTING IMAGES TO A COMPUTER	38
WORKING WITH IMAGES ON A COMPUTER	39
DIRECT PRINTING FROM CAMERA TO PRINTER	39
USING THE AC ADAPTER	40
HOW TO CONNECT THE AC ADAPTER	40

ADVANCED FUNCTIONS 41

DISPLAY & MENU BUTTON SETTINGS	42
DISPLAY BUTTON FUNCTION	42
MENU BUTTON FUNCTION	43
PRINT Image Framer (P.I.F) FUNCTION	44
PRINT Image Framer (P.I.F) SHOOTING	45
TAKING PHOTOS WITHIN THE FRAME	45
VIEWING A P.I.F. IMAGE	46
REPLACING FRAMES	47
USING THE CD-ROM	47
DOWNLOADING FROM THE WEB	47
DELETING FRAMES	48
INSTALLING FRAMES	49
TAKING PHOTOS IN MACRO MODE	50
MACRO MODE	50
CONTINUOUS SHOOTING	51
CONTINUOUS SHOOTING	51
SCENE MODES	52
SELECTING A SCENE MODE	52
NORMAL MODE	53
LANDSCAPE MODE	53
PORTRAIT MODE	53
WHITE BALANCE	54
AUTOMATIC WHITE BALANCE	54
SELECTING WHITE BALANCE MANUALLY	55

LIGHT SENSITIVITY	56
CHANGING TO AUTOMATIC SENSITIVITY MODE	56
SETTING LIGHT SENSITIVITY MANUALLY	57
MAKING EXPOSURE SETTINGS	58
ADJUSTMENTS	58
RESETTING TO DEFAULT MODE	60
RESETTING TO DEFAULT MODE	60
VIEWING RECORDED IMAGE DATA	61
DISPLAYING RECORDED IMAGE DATA	61
VIDEO CLIPS	62
RECORDING A VIDEO CLIP	62
PLAYING BACK A CLIP	63
DELETING VIDEO CLIPS	64

DIRECT PRINTING **65**

DIRECT PRINTING	66
LIST OF COMPATIBLE PRINTERS	66
DIRECT PRINTING PROCESS	67
PRINTING THE IMAGE SEEN ON THE LCD MONITOR	67
PRINTING ALL THE IMAGES IN MEMORY	68
PRINTING SELECTED IMAGES	69
PRINT Image Framer (P.I.F.) PRINTING	70
PRINTING PRINT Image Framer (P.I.F.) IMAGES	71
PRINTING THE P.I.F. IMAGE DISPLAYED ON THE LCD MONITOR	71
OTHER P.I.F. PRINTING OPTIONS	72
CHANGING THE FRAMES	73
PRINT SETTINGS	74
HOW TO CHANGE PRINT SETTINGS	74
SETTING PAPER SIZE	75
SELECTING PRINT BORDERS	75
PRINTING THE DATE	76
HIGH SPEED PRINTING	76
PRINTER UTILITIES	77
PRINTER UTILITIES	77
TEST PRINTING FOR NOZZLE CHECK	78
HEAD CLEANING	78

ADDITIONAL SETTINGS **79**

DIGITAL PRINT ORDER FORMAT (DPOF)	80
SAVING PHOTOS IN DPOF	80

SOUND AND SHUTTER SETTINGS	81
ADJUSTING LCD BRIGHTNESS	82
MEMORY CARD FORMATTING	83
AUTO POWER SAVE	84
RESETTING THE AUTO POWER SAVE	84
DATE & TIME AND DATE/TIME FORMATS	85
RULES FOR NAMING FILES (Cumulative function)	86
RESETTING FILE NUMBERS	86
RESETTING VIDEO OUT	87
SETTING THE MENU LANGUAGE	87
RESETTING CAMERA DEFAULTS	88

ADDITIONAL INFORMATION 89

CLEANING THE CAMERA	90
WHEN THE CAMERA NEEDS CLEANING	90
STORING THE CAMERA	90
SPECIFICATIONS L-300	91
SPECIFICATIONS L-200	92

TROUBLESHOOTING 93

TROUBLESHOOTING	94
IF YOU RUN INTO TROUBLE	94
BEFORE YOU CALL CUSTOMER SUPPORT	94
CAMERA BODY PROBLEMS	94
IMAGE PROBLEMS	97
PRINTING PROBLEMS	98
LIST OF ERROR MESSAGES	99
PHOTO MODE MESSAGES	99
PLAYBACK MODE MESSAGES	99
SET UP MODE MESSAGES	100
DIRECT PRINTING MESSAGES	100

EPSON INFORMATION 102




CONTACTING CUSTOMER SUPPORT	102
INDEX	104

INSTRUCTION BOOK SYMBOLS




The symbols used in this book are explained below.

Symbols

Required Reading

	Must be followed carefully to avoid bodily injury.
	Necessary to avoid damaging the camera and or other devices.
	Necessary to ensure correct camera function.

Very Useful Information

	Useful extra information.
	For Your Information: Technical terms and professional concepts.
	This suggestion will improve your photography.

Copyrights and Trademarks

Copyrights

All rights reserved. No part of this publication may be reproduced, stored in a retrieval system, or transmitted in any form or by any means, electronic, mechanical, photocopying, recording, or otherwise, without the prior written permission of SEIKO EPSON CORPORATION. No patent liability is assumed with respect to the use of the information contained herein. Neither is any liability assumed for damages resulting from the use of the information contained herein.

Neither SEIKO EPSON CORPORATION nor its affiliates shall be liable to the purchaser of this product or third parties for damages, losses, costs, or expenses incurred by the purchaser or third parties as a result of: accident, misuse, or abuse of this product or unauthorized modifications, repairs, or alterations to this product, or (excluding the U.S.) failure to strictly comply with SEIKO EPSON CORPORATION's operating and maintenance instructions.

SEIKO EPSON CORPORATION shall not be liable against any damages or problems arising from the use of any options or any consumable products other than those designated as Original EPSON Products or EPSON Approved Products by SEIKO EPSON CORPORATION.

Trademarks

EPSON is a registered trademark of SEIKO EPSON CORPORATION. PRINT Image Matching is a trademark of SEIKO EPSON CORPORATION. The PRINT Image Matching logo is a trademark of SEIKO EPSON CORPORATION. DPOF is a trademark of CANON INC., Eastman Kodak Company, Fuji Photo Film Co., Ltd. and Matsushita Electric Industrial Co., Ltd. The PRINT Image Framer is a trademark of SEIKO EPSON CORPORATION. The name PRINT Image Framer will be abbreviated within this User's Guide and will simply be called P.I.F.

MultiMediaCard is a registered trademark of Infineon Technologies AG (Germany), licensed to MMCA (MultiMediaCard Association).

General Notice: Other product names used herein are for identification purposes only and may be trademarks of their respective owners. EPSON disclaims any and all rights in those marks.

Copyright © 2003 by SEIKO EPSON CORPORATION, Nagano, Japan.

IMPORTANT SAFETY INSTRUCTIONS

WARNING



Read all of these instructions before using this product, and keep this guide handy for later reference. Follow all warnings and instructions marked on this product and options.

WHEN USING THIS PRODUCT

Note the following when using this product.

- To reduce the risk of electric shock, do not remove the cover of this product or options. Do not open any compartments except as instructed in this User's Guide.
- Do not insert objects into any openings.
- To prevent fire or electric shock, do not expose this product or options to rain or moisture.
- To prevent fire or electric shock, do not cover this product with a blanket or other covering that may give off an electric charge.
- To prevent fire or explosion, do not use this product where flammable or volatile gas is stored.
- Do not use this product outdoors during a thunderstorm.
- To prevent possible injury, do not take flash pictures in close proximity to anyone's eyes.
- Remove the batteries from and/or unplug this product and refer servicing to qualified service personnel under the following conditions:
The power cord or plug is damaged; liquid has entered this product or its options; this product or its options have been dropped or the case damaged; this product or its options do not operate normally or exhibit a distinct change in performance; this product or its options emit unusual noises, odors, or smoke.
- Never adjust controls that are not mentioned in the operating instructions.
- If the liquid crystal solution contained in the LCD monitor leaks out and gets on your hands, wash them thoroughly with soap and water. If it gets into your eyes, flush them immediately with water.
- Do not look at the sun through the viewfinder. Doing so could damage your eyes.

WHEN USING THE STRAP

Note the following when using this product strap.

- Do not swing this product about. Doing so could damage this product or other objects, or cause injury.
- Do not pull or tighten the strap too much when wearing it. Doing so could cause serious injury.
- Keep the strap away from children.

WHEN USING THE BATTERIES

Note the following when using batteries.

- Only use the batteries in EPSON Digital Cameras as specified in this manual.
- To guard against short-circuiting, do not remove the outside sleeves of the batteries.
- Keep the batteries from making contact with metal objects such as coins or keys, which could short circuit the batteries.
- Do not put the batteries near or into fire or water.
- Read all relevant safety and operating instructions before using the batteries.
- Do not use manganese batteries (IEC R6).
- Do not charge primary (non-rechargeable) batteries.
- To avoid fire or electric shock, do not use batteries that are leaking or damaged in any way.
- Do not handle the batteries with wet hands or use them near water. Do not expose the batteries to water or high humidity.
- Do not place the batteries near or into heat sources or fire.
- Do not drop, puncture, disassemble, mutilate, or short-circuit batteries.
- To protect against short-circuiting, do not remove the outside sleeves of the batteries.
- Prevent the batteries from coming into contact with metal objects which could short-circuit the batteries, such as coins or keys.
- Do not insert batteries into wall outlets or other power sources such as car cigarette lighter sockets.
- Do not solder lead wires or terminals directly to a battery.

Replacing the batteries

You can replace them with any of the following batteries.

Single-use AA alkaline batteries

Rechargeable AA Ni-MH batteries

Rechargeable AA nickel-manganese batteries

NOTE



- Battery life varies depending on the battery type and the manufacturer.
- If you use rechargeable batteries in the L-300/200, replace them with four fully-charged batteries. If you find that your batteries run out soon after recharging them a number of times, make sure you discharge them completely before recharging.

Handling the batteries

Keep the battery ends clean by wiping them with a dry cloth.



WARNING

- Do not apply heat or force to batteries, and do not disassemble, drop, short-circuit, or put batteries into fire or water.
- Do not keep batteries loose in your pockets.
- Do not mix different types of batteries; this can cause fire or explosion.
- Always use batteries from the same package as a set. Do not mix old and new batteries.

Storing the batteries

If you do not plan to use the camera for a long period of time, remove the batteries and store them at a low temperature in a dry location.

WARNING



- Do not store batteries with metal objects, which could short-circuit the batteries.
- Avoid storing batteries in extremely hot or humid locations.
- Store batteries out of reach of children.
- Always remove the batteries from the camera and charger before storing. Batteries left in your camera and charger for a long time may leak and cause damage.

Disposing of the batteries

Before disposing of batteries, make sure you discharge them completely.

WARNING



- Be sure to securely cover the + end of each battery with tape to prevent combustion or explosion when disposing.
- Dispose of used batteries according to the manufacturer' s instructions and in compliance with all applicable laws. Contact your local government agency for information about battery recycling and disposal.

For the Netherlands users:

Do not dispose of the batteries with ordinary refuse. Instead, dispose of them as small chemical waste in accordance with local laws, and the following Dutch Government Gazette 45, KCA Marking:



Bij dit produkt zijn batterijen geleverd. Wanneer deze leeg zijn, moet u ze niet weggooien maar inleveren als KCA.

For German users:



Do not dispose of batteries with ordinary refuse. Instead, dispose of them in a recycle box in accordance with local laws.

WARNING



If battery acid gets into your eyes or on your skin, immediately rinse the affected area thoroughly with water and seek medical treatment. If a battery is swallowed, seek medical treatment immediately.

FOR USERS IN HONG KONG

If damage occurs to the plug, replace the cord set or consult a qualified electrician.

Replace fuses only with fuses of the correct size and rating.

WHEN CHOOSING A POWER SOURCE

The AC adapter converts AC voltage from a wall outlet into the correct DC voltage for your EPSON product.

- 1) Read these instructions.
- 2) Keep these instructions.
- 3) Heed all warnings.
- 4) Follow all instructions.
- 5) Do not use this apparatus near water.
- 6) Clean only with dry cloth.
- 7) Do not block any ventilation openings. Install in accordance with the manufacturer's instructions.
- 8) Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
- 9) Protect the power cord from being walked on or pinched particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.
- 10) Only use attachments/accessories specified by the manufacturer.
- 11) Unplug this apparatus during lightning storms or when unused for long periods of time.
- 12) Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.

WARNING



- To reduce the risk of fire or electric shock, do not expose this apparatus to rain or moisture.
- The apparatus shall not be exposed to dripping or splashing and that no objects filled with liquids, such as vases, shall be placed on the apparatus.
- Only use this adapter in the manner described in your product's documentation. Check the product's documentation to make sure that this is the correct adapter for your product.
- Read all relevant safety and operating instructions before using these products, as misuse could result in personal injury from fire, explosion, leakage, overheating, or electric shock.

These safety and operating instructions should be kept for future reference.


NOTE



AC Adapter model A211H conforms to CE marking requirements in accordance with EC Directives 73/23/EEC and 89/336/EEC.

- Beware of electrical shock hazards.
- Do not use this product near water or handle it with wet hands.
- Keep away from heat sources. Do not use the charger outside the temperature range of 5° C to 35° C (41° F to 95° F).
- Do not insert objects into any openings as they may touch dangerous voltage points or short out parts.
- Never disassemble or modify this product.
- Use only indoors, in a dry location.
- Do not expose to water or excess humidity.
- Use the type of power source indicated on the label, and always supply power directly from a standard domestic electrical outlet.
- Do not place multiple loads on the electrical outlet.
- Be sure your AC power cord meets the relevant local safety standards.
- Never insert or disconnect the power plug with wet hands.
- Power-supply cords should be protected from abrasion, cuts, crimping and kinking. Be sure to place your cords to avoid any damage. Do not place objects on top of the power cord or allow the power cord to be stepped on or run over. You should take special care to try to keep the power cord straight at the ends and the points where it enters and leaves the transformer.
- Do not allow the AC power cord to become damaged or frayed.
- Unplug your equipment from the wall outlet and refer servicing to qualified personnel under the following conditions:
If the power cord or plug is damaged; if liquid has entered your equipment; if your equipment has been exposed to rain or water; if your equipment has been dropped or damaged; if your equipment is operating abnormally or exhibits a distinct change in performance. Adjust only those controls described in your product documentation.
- Never attempt to repair this product yourself. Improper repair work can be dangerous.
- Unplug this product from the wall outlet before cleaning.
- Clean only with a clean, soft dry cloth.
- Do not use liquid or aerosol cleaners.
- Keep out of reach of children.
- For US and Canadian users:
Use the included power cord or a 6-10 foot UL-approved type SPT-2 or heavier type, 2 x 18 AWG cord with a 125 V 10 A plug and 125V 7A connector.
- If you plan to use the AC Adapter in Germany, observe the following:
To provide adequate short-circuit protection and over-current protection for these products, the building installation must be protected by a 16 Amp circuit breaker.

CAUTION



**This product is designed for use with EPSON products ONLY.
Do not attempt to use it with other electronic devices.**

EPSON FEATURES

Thank you for purchasing an EPSON L-300/200. It's not only a high quality digital camera, but has many useful features as well. Please read the Instruction Booklet thoroughly to prepare for many years of enjoyable photography.

Get beautiful results from many easy-to-use camera features!



You can take high quality photos just like a normal film camera. This camera has special "Scene Modes" that result in fool-proof automatic photography in every situation.

For "Scene Modes"
(See page 52-53.)


Print your pictures directly to your own EPSON printer!



There is no need for a computer. You can print directly to an EPSON printer using a USB cable. (See page 66.) The camera's excellent digital images allow for truly high quality direct prints.

For "Direct Printing"
(See page 65.)

Enhance your photos with special printing features!



Select from a variety of frames stored right in the camera and add them to your photos when you print directly from the camera to an EPSON printer.

For "PRINT Image Framer"
(See page 44.)
For "Direct Printing"
(See page 65.)

CAMERA SETUP

How to set up your camera for optimal performance.

P.12 ● ITEMS

P.14 ● TOP VIEW

P.16 ● BATTERIES AND MEMORY CARD INSTALLATION


P.18 ● SETTING UP YOUR CAMERA

ITEMS


ITEMS

CHECKING THE PACKING CONTENTS


Make sure that your camera box contains all of the items shown below and that they are undamaged. If there is a problem, check with the store where you bought it.




Camera Body




User's Guide



4 AA Alkaline Batteries



One CD-ROM



Digital Camera Software Guide




- SD Memory Card
- 16 MB memory card (with model L-300)
 - 8 MB memory card (with model L-200)

SD Memory Card

Installed in the camera

Batteries do not come installed in the camera.




SD Memory Card




Strap


Attaching The STRAP

Please refer to the illustration.






PC Cable
May be used to connect the camera to a printer that can support USB DIRECT-PRINT (STYLUS Photo 935) .



AV Cable




Printer Cable




AC-Adapter
(A211H)

The AC power cord packed with your adapter is designed to match the voltage of the country of purchase.







AC-Adapter AC Cable

TOP VIEW





TOP VIEW






Connector Cover



BATTERIES AND MEMORY CARD INSTALLATION


ACCESSING THE BATTERIES AND MEMORY CARD

Opening the cover



Slide the Battery / Memory Card Cover in the direction of the arrow while pressing down on it.

Closing the cover



Slide the Battery / Memory Card Cover in the direction of the arrow until it clicks into place.



ALERT
Be sure the camera is turned OFF before opening and closing the battery / memory card cover.

HOW TO INSERT AND REMOVE THE MEMORY CARD

The memory card is installed in the camera at the factory. Check that it is properly set.



MEMORY CARD INSERTION

Checking that the card is facing the right direction, slide it in until it clicks.

REMOVING THE MEMORY CARD

Release the card by pushing once and then pull it out with your fingers. (Push once to set it, push again to release it.)

CAUTION



The memory card is a precision electronic component. Comply with the instructions below to avoid damage.

- Don't touch the terminals with your fingers or metal. Resulting static electricity could cause damage. Discharge body static electricity by touching something metal before you handle the card.
- Don't bend, drop or otherwise shock the memory card.
- Keep the memory card away from water, excessive heat or direct sunlight.
- Don't break down or take apart the memory card.

NOTE



You may also use a MultiMedia Card

You may use an SD memory card or a MultiMedia Card. (See pages 29, 90-92.)

NOTE



The memory card must be removed when:

- you would like to copy images saved on the memory card to a computer.
- the printer has a memory card slot that you may use directly.

BATTERY SETUP

Be sure the battery poles + – are aligned properly.



SETTING THE BATTERIES

Insert the batteries according to the pole indications on the cover.

NOTE





To find out what batteries may be used. See pages 91-92.


CAUTION



If you insert the batteries incorrectly you may cause leaking, overheating or injury to yourself. You may also damage the camera.

BATTERY LIFE INDICATOR

As the batteries lose power, the icon on the LCD monitor will change from  to .



Batteries Icon



When the icon changes from to

Power in the batteries is almost depleted. Please be ready to insert a spare.

When the is flashing

The power is low and you can no longer photograph. Then the indicator light will show red and the camera will automatically shut down.

WARNING



- When changing the batteries, change all 4 at the same time and use the same brand.
- The life of a battery will vary depending on the brand and grade. The conditions and modes that are used will also affect the length of use.
- Non-rechargeable batteries cannot be recharged. Follow the instructions provided to discharge batteries.

NOTE




If the batteries run low, you can simply plug in the AC adapter to continue using the camera. (See page 40.)



- Rechargeable batteries should be recharged in their own charge until used up.
- Do not dispose of batteries as ordinary refuse.
- Instead, dispose of them in a collection or recycle box in accordance with local laws.

SETTING UP YOUR CAMERA

POWER ON/OFF



POWER button

Turning on the Power

Turn on the camera by pressing the POWER button. The lens cover will open automatically, and the lens will extend.

Turning off the Power

Pressing the POWER button again will turn the power off. The lens will automatically retract and the lens cover will close.

NOTE



When the camera is left on for a long period of time without being used, it will automatically shut down to save the batteries. (See page 82.)

INITIAL SETTINGS

The first time you use the camera, you must set the following three items. You will only need to do this once.



MACRO button FLASH button



1. Selecting a Language

The first time you turn on the POWER, the "Language" screen appears. Use the ▲▼ buttons to select English, then press the ⚡ FLASH button. (See page 87.)



2. Setting Date & Time

Next the screen "Date/Time" will appear with the year highlighted.

Use the ▲▼ buttons to change the numbers.


Use the ◀▶ buttons to highlight the next item.

Press the ⚡ FLASH button to save the settings.

Press the ⏪ MACRO button to return to previous settings.

Hold down the ▲▼ buttons to scroll faster.

You may change these settings at a later date. (See page 83.)



3. Setting the Video Out Signal

The last screen will say Video Out.

Use the ▲▼ buttons to highlight PAL or NTSC. Then press the

⚡ FLASH button to save. (See page 87.)

Initial settings are complete.

STANDARD OPERATION



How to use in the automatic mode.

P.20	●	HOLDING THE CAMERA / RELEASING THE SHUTTER
P.22	●	THE IMAGE SYSTEM
P.32	●	PLAYBACK SYSTEM
P.36	●	DELETING SYSTEM
P.38	●	USING YOUR IMAGE
P.40	●	USING THE AC ADAPTER



HOLDING THE CAMERA / RELEASING THE SHUTTER

There is no special picture-taking stance for this particular camera, but it is useful to know these basic techniques for taking good pictures in general.

Good Form For Taking Horizontal Shots



Good Form For Taking Vertical Shots




NOTE



In P.I.F. mode the image will sometimes appear upside down.

FULL & HALF SHUTTER BUTTON POSITIONS



Full & Half Positions

The shutter button has a two-step function. Hold it halfway down to activate the flashing green Indicator light. The camera is automatically setting focus and shutter speed. Fully press it completely to release the shutter.



Remember to make an L-shape platform and to avoid covering the lens or flash with your fingers. If you arch your right forefinger, you may press the shutter button too hard, jerking the camera as the shutter releases. Also, it is difficult to maintain a half-press when the finger is arched.



CAMERA RANGE

When taking a photograph, you will want your subject to stand at least 50cm (19.6 inches) away.

When you want to photograph something that is closer than 50cm use the MACRO mode for better results. (See page 50.)



THE IMAGE SYSTEM

A brief description of how to take photos.

TAKING PHOTOS USING THE LCD MONITOR

You can use the LCD Monitor to compose your photo using automatic focusing. The captured image will appear, then disappear.

CAUTION



Be careful to avoid placing your fingers in front of the lens. Do not try to extend or retract the lens manually. This may damage the mechanism.



1

Press the POWER button to turn the camera ON.

The lens will extend and the cover will open.
The picture will appear on the LCD screen.

2

Center the subject in the middle of the focus frame of the LCD monitor.

3

Press the SHUTTER button halfway to set the focus.

When focus is set, the indicator light turns steady and the focus frame on the LCD monitor will turn green. When the picture is not in focus the indicator light will flash and the focus frame on the LCD monitor will turn red. If this occurs, take your finger off the shutter button and try refocus the picture.

Please note that the picture will not focus if your subject is closer than 50 cm. Use the MACRO mode. (See page 50.)



focus frame

4 Press the SHUTTER button fully to take the photo.

You will know the picture is recorded when you hear the shutter sound. This sound may be turned off. (See page 81.)

5 Press the POWER button to turn the camera OFF when finished.

The lens will retract and the lens cover will close.

TURNING THE QUICK VIEW ON/OFF

This system sends the recorded photo to the LCD monitor 3 seconds after the image is captured. This function may be turned ON or OFF.

SET
UP



Turn the DIAL SWITCH to SET UP mode and press the POWER button.



Use the ▲▼ buttons to highlight QUICK VIEW. Use the ◀▶ buttons to select ON/OFF.

The recorded picture is displayed. It will disappear after 3 seconds, or after the shutter button is pressed halfway, whichever is sooner.

When using only the VIEWFINDER the QUICK VIEW function will not work.

SETUP		2/3
Power Save	3 min.	
Quick View	◀ ON ▶	
Date / Time	2003.3.20	
	15:30	
Date Format	Y.M.D. 24hr	

USING THE VIEWFINDER-ONLY METHOD

How to take photos using the viewfinder only with the LCD monitor turned off. It is similar to using a standard range finder camera. This saves battery power when compared to using the LCD monitor to compose your pictures.

CAUTION



Be careful to avoid placing your fingers in front of the lens. Do not try to extend or retract the lens manually. This may damage the mechanism.



1

Press the POWER button to turn ON the camera.


The lens will extend and the cover will open. The subject will appear on the LCD monitor.

The explanation for turning ON the POWER will be omitted from now on.

2

Press the DISPLAY button to turn off the LCD MONITOR.

See page 42 for the explanations for the DISPLAY button.



3

Center the subject in the focus frame.

The camera will set the focus on the image located in the exact center of the frame.



The viewfinder during shooting.

4**Press the SHUTTER button halfway to set the focus.**

When focus is set, the indicator light turns steady. When the picture is not in focus the indicator light will flash. If this occurs, take your finger off the shutter button and try refocus the picture.

Please note that the picture will not focus if your subject is closer than 50 cm. Use the MACRO mode. (See page 50.)

**5****Press the SHUTTER button all the way to take the photo.**

The shutter sound indicates the shutter has released. To turn off the shutter sound, see page 81. You are ready for the next shot when the green light stops flashing.

6**Be sure to turn OFF the camera when you are finished by pressing the POWER button.**

The lens will retract and the automatic cover will close.

The explanation for turning OFF the POWER will be omitted from now on.




When using the VIEWFINDER to take close-up pictures, there will be a slight difference between what you see and what the camera records through the lens, referred to as parallax. Be mindful of this difference in close-up situations using the viewfinder.



When taking photos using the VIEWFINDER with the LCD Monitor off, pushing the MENU button will turn on the function display menus so you can change settings for different situations. (See pages 43,51-61.) You can turn off the menu display by pressing the MENU button again.

IF THE CAPTURED IMAGE IS OUT OF FOCUS FRAME

The automatic focus works only if the subject is in the FOCUS FRAME while the SHUTTER button is first pressed halfway down. After the focus is locked on the subject, you can adjust the frame to the desired composition and release the SHUTTER.



Turn the DIAL SWITCH to PHOTO MODE, and then turn the POWER ON.

1 Place the subject in the center of the focus frame.

Just as when using the LCD monitor to compose the shot, you must put the object to be focused on in the center of the viewfinder.



2 Press the shutter button halfway to set focus.

When focus is set, the indicator light stops blinking on both the LCD monitor and the VIEWFINDER.



3 Maintain the halfway shutter button position and if you wish, reposition the framing to your liking.




4 Press the shutter button completely to take the photo.

The shutter sound indicates the shutter has released.

OPTICAL ZOOM & DIGITAL ZOOM

This camera has a 3X OPTICAL ZOOM and a 2X DIGITAL ZOOM. When using the DIGITAL ZOOM, you must use the LCD monitor to see the 6X magnification and compose the picture correctly.

Focal lengths covered by the 35mm optical zoom lens.



OPTICAL ZOOM RANGE (3X)



To zoom in press **T** to zoom out press **W**.


DIGITAL ZOOM (2X)



To activate DIGITAL ZOOM, press **T** until it stops zooming in, remove your finger and press **T** again. To turn off the Digital Zoom feature, press **W** until it stops zooming out, then remove your finger and press **W** again.

NOTE

Selecting Digital Zoom through the MENU



After pressing the MENU button, use the ◀▶ buttons to highlight Digital Zoom. Using the ▲▼ buttons, select either ON or OFF.

NOTE



When using digital magnification, the zoom will be shown on the right side of **T**.




ALERT

You can also use the Digital Zoom while shooting through the VIEWFINDER, although all digitally enhanced images are inferior in resolution.

IMAGE CAPTURE SETTINGS


Selecting the Resolution and Compression



Turn the DIAL SWITCH to PHOTO MODE and then turn the POWER ON.

1

Press the MENU button and use the ◀ ▶ buttons to highlight RESOLUTION.



This sample screen is from the L-300 model.

2

Use the ▲ ▼ buttons to select the number of pixels (size) from Standard, Fine or Superfine.


RESOLUTION	L-300	L-300 (DIGITAL ZOOM)	L-200	L-200 (DIGITAL ZOOM)
Standard ★	640 × 480pixels	640 × 480pixels	640 × 480pixels	640 × 480pixels
Fine ★★	1600 × 1200pixels	1024 × 768pixels	1280 × 960pixels	800 × 600pixels
Super fine ★★★	2048 × 1536pixels	1024 × 768pixels	1600 × 1200pixels	800 × 600pixels

3

Press the MENU button and use the ◀ ▶ buttons to highlight COMPRESSION.

Normal mode is set at high compression, which takes less memory space but produces a lower quality picture.

Fine mode produces the highest quality picture, but will require more memory.



4

Use the ▲ ▼ buttons to select Normal or Fine Compression.

NOTE



Photograph Quality Settings

The number of pictures you can fit on a memory card is determined by photograph quality. (See page 29.)


The camera keeps the setting at your last choice when it is turned off.

The camera is set in the "Normal" compression mode at the factory. Changing to "Fine" mode will improve the quality of your pictures (See page 29.), but the number of pictures that fit on a single memory card will be reduced.

Photograph quality level is automatic when taking pictures in the VIDEO CLIPS mode.

CONFIRMING THE NUMBER OF PHOTOGRAPHS

The number of pictures stored on the memory card (at current quality and resolution settings) is displayed on the LCD monitor.



Approximate Number of Images

Quality	Approximate Number of Images L-300 (16MB)		Approximate Number of Images L-200 (8MB)	
	Normal	Fine	Normal	Fine
Standard ★	Approx. 127 Images	Approx. 68 Images	Approx. 62 Images	Approx. 32 Images
Fine ★★	Approx. 35 Images	Approx. 17 Images	Approx. 32 Images	Approx. 16 Images
Super fine ★★★	Approx. 21 Images	Approx. 10 Images	Approx. 16 Images	Approx. 8 Images

Frame data will also be installed on the provided SD Memory card. This may reduce the total indicated on the table.



ALERT

- The numbers are the result of factory tests made by the manufacturer.
- The numbers on the LCD monitor are only a guide. The actual numbers may vary.
- The numbers on the LCD monitor may vary with image capture settings.
- The number on the LCD monitor may change after each picture is taken. Each one will take up different amounts of memory. The number is calculated based on the factory average.
- When you take VIDEO CLIPS the amount of pictures you can take will change drastically. See page 62 for more detailed information on VIDEO CLIPS.
- The number of the sheets which can take pictures is a maximum of 9999.



Comparing the SD and MultiMedia Memory Cards

You may use both the SD Memory card and the MultiMediaCard (MMC) with this camera. The SD Memorycard is quite fast and has the ability to hold large amounts of data. The MultiMedia Card uses less power so that the batteries last longer.

If you decide to buy a new memorycard, the SD Memory card is recommended for its speed and ability to lock and protect your data. (See page 85.)


FLASH CONTROL

You can change the flash settings by pushing the **⚡ FLASH** button and observing the icons on the LCD monitor.

The mode changes each time you press the **⚡ FLASH** button.

Flashing green means the battery is recycling for the next shot.

FLASH Mode Icons



Indicator light



FLASH button

NOTE



Blurred Shot

When taking pictures in "No Flash" setting or in the "Forced Flash" setting (Slow Synchro), the shutter will be slower than 1/30 sec. at wide angle or 1/60 sec. at telephoto. At such slow speeds in low light, the image may blur from camera motion, therefore, a green light will flash to warn you.



Slow Synchro Shutter Shooting

This technique allows you to sync the Flash with the Slow Shutter Shooting. In most cases, if the flash is used in a very dark setting the background turns out dark, but when using the Forced Flash settings the exposure time lengthens (Slow Synchro Shutter Shooting) and brightens the background. The use of a tripod is recommended to prevent blurring.

Main Functions Of The Flash Icons

⚡	Automatic Flash (default setting)	The flash will automatically go off in a dark setting. In a well lighted setting, the flash will not go off. This can be used for most settings.
⚡/	No Flash	Turns off the flash even in dark scenes. Use it for night scenes or wherever you are prohibited from using a flash. Please note that these shots may become blurred due to very slow shutter speed. 'No Flash' is the automatic setting in CONTINUOUS or VIDEO CLIP mode.
👁	Auto red-eye reduction	Use this setting when recording with a flash at night or indoors. The flash will go off once and will go off again when the picture is taken. This will help to reduce red-eye phenomenon.
⚡	Forced Flash	The flash will go off at any time no matter the brightness. Use it when the background is bright or when you are shooting against the sun. When used in dark settings, the length of exposure becomes longer, changing into Slow Synchro Shutter Shooting. Please note that these shots may become blurred.


Flash Range

ISO Sensitivity		Normal (Wide Angle)	Normal (Telephoto)
Standard Sensitivity	ISO 100	0.5 - 2.6m (1.6 - 8.5ft)	0.5 - 1.5m (1.6 - 4.9ft)
High Sensitivity	ISO 200	0.5 - 3.7m (1.6 - 12.1ft)	0.5 - 2.1m (1.6 - 6.9ft)
Super High Sensitivity	ISO 400	0.5 - 5.2m (1.6 - 17.1ft)	0.5 - 3.0m (1.6 - 9.8ft)




ISO Sensitivity
(See page 56-57.)

USING THE SELF TIMER

Use the self-timer when you are recording an image of yourself or a group that includes you. Also, this feature will eliminate blurring.



Turn the **DIAL SWITCH** to **PHOTO MODE** and then turn the **POWER ON**.



1

Press the **MENU** button and select **SELF TIMER** by using the **◀▶** buttons.

2

Select either **2 sec.** or **10 sec.** by using the **▲▼** buttons.



Short Self Timer

Shots taken at night, at sunset or in **MACRO** mode can easily become blurred. The shot often becomes blurred when the camera moves (because the shutter is open) while the shutter button is pressed down. When using the Short Self Timer the shutter is set to release 2 seconds after the button has been pressed, helping you to take photos that are not blurred. The light will flash quickly for 2 seconds before the shutter goes off.

3

Center the image and press the SHUTTER button.

In the 10-sec. mode, the light flashes slowly for 8 seconds, then faster for the last 2 seconds before the shutter releases.

Light will flash slowly for 8 seconds



Light will flash quickly for 2 seconds



Shutter will release



Illumination Light

NOTE



If you want to stop the process after pressing the shutter button in self timer mode, just press the


MACRO button.

EPSON recommends using a tripod or placing the camera on a flat horizontal surface when using this mode.

PLAYBACK SYSTEM

You can playback images and video clips in several ways.

ONE BY ONE PLAYBACK



Turn the **DIAL SWITCH** to **PLAYBACK MODE** and then turn the **POWER ON**.

The camera becomes a viewer and will playback the pictures you have just taken.





Image ID System


The left-hand number 24 is the current image, the right-hand number 75 is the number of photos taken.

Press the ◀ button to display the previous image.
Press the ▶ button to display the next.

You may delete this image by pressing the 🗑️ MACRO button. (See page 36.)
Each time you press the DISPLAY button, the information icons on the LCD Monitor can be turned on or off.

DISPLAYING MULTIPLE IMAGES

The LCD Monitor can display 6 images at once.



Turn the DIAL SWITCH to PLAYBACK MODE and then turn the POWER ON.

1 Press the **W** ZOOM button to display 6 images at once.

2 Change the images by pressing the **▲▼◀▶** buttons.

To display only a single image, press the **T** ZOOM button.



NOTE



The following icons may appear on the LCD monitor.



: VIDEO CLIP data (See pages 62-64.)




: P.I.F. Framed image (See pages 44-49.)



: Cannot be displayed-or-printed data

LCD MONITOR IMAGE ENLARGEMENT

How to magnify captured images up to 4X.



Turn the DIAL SWITCH to PLAYBACK MODE and then turn the POWER ON.

Press the T ZOOM button.

The **T** button enlarges the image, the **W** button reduces it.

If you continue to press the **W** button, the image will return to normal size.


Move the indication area with the **▲▼◀▶** buttons.

Each time you press the DISPLAY button, the information icons on the LCD Monitor can be turned on or off.




SLIDE SHOW

You can playback photos in a series. You can also rotate photos.



Turn the DIAL SWITCH to PLAYBACK MODE and then turn the POWER ON.



1 Press the MENU button and select SLIDE SHOW with the ◀▶ buttons.




NOTE When viewing still images during the slide show, the pictures will be shown for 3 seconds. Once the slide show starts, both still images and VIDEO CLIP sequences will playback continuously.



2 Press the FLASH button to start the slide show.


Press the ⬇️ MACRO button to pause the slide show. Press the ⬆️ MACRO button again to restart the slide show.

Press the ⚡ FLASH button to quit the slide show.





QUICK PHOTO REVIEW







How to review photos while still in PHOTO MODE.




Turn the DIAL SWITCH to PHOTO MODE and then turn the POWER ON.



Press the  REVIEW button. The LCD Monitor will change to REVIEW mode.

-   Use the **T** ZOOM button to enlarge the image.
-  Use the **W** ZOOM button to reduce to normal size.
-  Buttons change the images.
-  MACRO button deletes the image.
-  REVIEW button returns to PHOTO mode.




DELETING FILES


How to delete photos you don't want to keep.

DELETING A SINGLE PHOTO

Deleting one images at a time.




Turn the DIAL SWITCH to PLAYBACK MODE and then turn the POWER ON.




1


Select the photo you want to delete with the ◀▶ buttons. Then press the  MACRO button.

Press **W** on the ZOOM button in order to view 6 images at a time.




2

Using the ▲▼ buttons, select "Delete this file." Press the  FLASH button.

If you do not wish to delete any files, press the  MACRO button.

If the data has been taken by another camera and has been locked the message "This file cannot be deleted because this file is locked or cannot be deleted." (See page 99.)




3

If there is still data left on the memory card, the monitor will return to the PLAYBACK mode screen. If there is no data, the message "No Images" will be displayed.

DELETING ALL IMAGES

You can delete all images from memory at the same time.




Turn the DIAL SWITCH to **PLAYBACK MODE** and then turn the **POWER ON**.

1 Select Delete with the **MACRO** button.

Press **W** on the **ZOOM** button in order to view 6 images at a time.



2 Select "Delete all files." with the buttons.



3 Press the **FLASH** button. The message "Delete all files?" will appear. Press the **MACRO** button to delete all files.

Press the  **FLASH** button to cancel the deleting process.

If the memory card has been locked by another camera the message "Some files are locked or could not be deleted." will appear on the monitor. (See page 99.)

4 When all the images have been deleted, the message "No Images" will appear on the monitor.

USING YOUR IMAGES

DISPLAYING ON A TV


Use your AV cable to connect the camera to video display devices.

CAUTION



Make sure the power is turned off before you begin.
Open the connector cover carefully, to avoid damaging it.

Open the connector cover and connect the AV cable from the camera to the TV.



NOTE



Be sure the "Video-out" setting matches your country's TV technical standard. It has been set to NTSC (the Japanese standard) at the factory.
(To change the setting see page 87.)

EXPORTING IMAGES TO A COMPUTER

How to copy your images directly to your computer.

CAUTION



Make sure the power is turned off before you begin.
Open the connector cover carefully, to avoid damaging it.

Open the connector cover and connect the PC cable from the camera to the computer.



Depending on the OS of your computer, you may have to install driver software. The driver software can be found on the CD-ROM that is included. For more instructions, refer to your Digital Camera Software Guide.

WORKING WITH IMAGES ON A COMPUTER

"EPSON Photo!4" and "EPSON PhotoQuicker" digital photo software is included with your camera.



EPSON Photo!4 Features

This software allows you to store, review and arrange your digital camera images easily. Please read the instructions that come with the disk.

EPSON PhotoQuicker Features

This software will print and enhance your images just like your local photo shop. Please read the instructions that come with the disk.



When images that were taken using the P.I.F.mode are copied to your computer, the link between the image and the frames will be broken.

DIRECT PRINTING FROM CAMERA TO PRINTER

You can print a selected image easily by pressing the PRINT button on this model camera. Since it is a digital camera, you can print selected pictures as you watch and make a collection of printed pictures without using a computer at all. (See page 65.)



USING THE AC ADAPTER

How to connect the AC adapter. When using the DIRECT PRINTING process, or when you have connected the camera to a computer or TV, the AC adapter can be used so that you do not have to worry about the life of the batteries in the camera.

HOW TO CONNECT THE AC ADAPTER


ALERT




- When connecting the AC adapter, please make sure that the power on the camera has been turned off.
- When using the DIRECT PRINTING process, using the AC adapter is recommended.
- The AC adapter DOES NOT recharge batteries installed in the camera.

AC Adapter (MODEL No.A211H)

AC Adapter AC Cable



Connect the AC adapter as shown in the diagram.



CAUTION



Do not use any equipment not listed in the manual. See page 8-9 for safety instructions. For the L-300/200, use only the provided AC adapter (MODEL No. A211H). Also, do not use this AC adapter for other electric devices.


ADVANCED FUNCTIONS

- P.42 ● DISPLAY & MENU BUTTONS SETTINGS
- P.44 ● PRINT Image Framer (P.I.F.) FUNCTION
- P.45 ● PRINT Image Framer (P.I.F.) SHOOTING
- P.47 ● REPLACING FRAMES
- P.50 ● MACRO MODE
- P.51 ● CONTINUOUS SHOOTING
- P.52 ● SCENE MODES
- P.54 ● WHITE BALANCE
- P.56 ● LIGHT SENSITIVITY
- P.58 ● MAKING EXPOSURE SETTINGS
- P.60 ● RESETTING TO DEFAULT MODE
- P.61 ● VIEWING RECORDED IMAGE DATA
- P.62 ● VIDEO CLIPS

DISPLAY & MENU BUTTON SETTINGS


Functions of the DISPLAY button and the MENU button.

DISPLAY BUTTON FUNCTION




Turn the DIAL SWITCH to PHOTO MODE and then turn the POWER ON.

Press the DISPLAY button to turn the operation icons ON or OFF. Each time you press the DISPLAY button, the monitor cycles between operation Icons ON/operation icons OFF and LCD monitor OFF.






MENU BUTTON FUNCTION



Turn the DIAL SWITCH to PHOTO MODE and then turn the POWER ON.


- Press the MENU button and the MENU shows up on the LCD monitor. Each time you press the MENU button you can turn the MENU ON or OFF.

Operation Icons ON Operation Icons OFF LCD monitor OFF



- In PHOTO mode, when you press the MENU button you may use the ◀▶ buttons to scroll through the menu. In PLAYBACK mode the Menu items will become active each time you press the ◀▶ buttons.

Menu for PHOTO mode



Use the ◀▶ buttons to scroll through the menu (Shown below).

Menu for PLAYBACK mode



Use the ◀▶ buttons to move across the menu.

Menu List



PRINT Image Framer (P.I.F.) FUNCTION

PRINT Image Framer(P.I.F.) will link a frame to your picture as it is recorded. You can then use the DIRECT PRINTING process to print the composite frame.

PRINT Image Framer ILLUSTRATION

Taking a photo



There are also vertical frames. The frame shown is just one example.



©DISNEY

Frame



©Disney® Based on the "Winnie the Pooh" works by A.A.Milne and E.H.Shepard.



©Disney® Based on the "Winnie the Pooh" works by A.A.Milne and E.H.Shepard.

You can load your camera memory with a maximum of 2 different frames at a time. The camera will come with 1 frame already loaded in its memory. The SD Memorycard that is included will come with 10 different frames. Other available frames can be found on the CD-ROM and on the EPSON website.

Finished P.I.F. Composite Picture



©Disney® Based on the "Winnie the Pooh" works by A.A.Milne and E.H.Shepard.

©DISNEY
Based on the "Winnie the Pooh" works, by A.A.Milne and E.H.Shepard.



©DISNEY
Based on the "Winnie the Pooh" works, by A.A.Milne and E.H.Shepard.

The frame is not recorded on the original image, but linked to it. They are combined during printing.



When using the P.I.F. mode, a green line will appear on the LCD monitor. When taking the photo, make sure that the green line comes to the top of the frame.

NOTE



P.I.F. Shooting and P.I.F. Printing

In P.I.F. mode, you will use frames that you have previously loaded into the camera. Select one and take a photo. The photo will be printed in this frame during DIRECT PRINTING. You can decide to change the frame before you print.


When you copy an image that has been taken in P.I.F. mode to a computer, the link connecting the image and the P.I.F. frame will be lost.




Images taken in P.I.F. mode and set in DPOF format and saved on a memory card when printed with the Stylus Photo 935 will print with the first frame that is stored in the printer.

PRINT Image Framer (P.I.F) SHOOTING

TAKING PHOTOS WITHIN THE FRAME



Turn the DIAL SWITCH to PHOTO MODE and then turn the POWER ON.




MACRO button FLASH button

1 Press the MENU button and then use the ◀▶ buttons to highlight P.I.F. Press the ⚡ FLASH button to select this function.



2 Find the frame you want by pressing the ▲▼ buttons. Select it using the ⚡ FLASH button.

To return to normal view press the 🍃 MACRO button.



3 The composite P.I.F. image is displayed on the monitor. You may now take the photograph.

NOTE



On the LCD monitor, the frame will show up as a black and white image.

To return to normal view press the 🍃 MACRO button.




NOTE




Once you press the MENU button again, the icons on the monitor will change. You can then select FLASH and MACRO settings as usual, even though the frame remains visible.

VIEWING A P.I.F. IMAGE

You can see what frame has been attached by using the REVIEW function.



Turn the DIAL SWITCH to **PLAYBACK MODE** and then turn the **POWER ON**.



1 Choose **PREVIEW** by using the **FLASH** button.

If there are no images with frames attached, the **PREVIEW** menu will not appear.

Press **W** on the **ZOOM** button in order to view 6 images at a time.



2 The image will appear with the frame attached.



The frame cannot be changed at this time, but it can be changed or deleted before printing. (See page 73.)

Press the **MACRO** button to return to **PLAYBACK** mode.



Pressing the **T** zoom button will zoom in on the picture, while pressing the **W** will zoom out of the picture.

You may shift the portion of the picture inside the frame using the **▲▼◀▶** buttons.



REPLACING FRAMES

In order to add or change the frames loaded in the camera's memory you must ready a memory card that already has replacement frames in memory. Frames can be found in the included CD-ROM or on the EPSON website.

USING THE CD-ROM

ALERT You will need a computer with a CD-ROM drive.
You will also need to have installed PRINT Image Framer Tool beforehand.



Download to a memory card.

For detailed information, refer to the online help for EPSON PRINT Image Framer Tool.

DOWNLOADING FROM THE WEB

ALERT You will need a computer that is connected to the Internet.
You will need to install PRINT Image Framer Tool.



Download to a memory card.


Detailed information can be found through EPSON'S web site online help.

ALERT The following instructions assume that you have already loaded frames from a SD memory card into the camera's own memory.




DELETING FRAMES

How to delete frames that are stored in the camera's memory or the memory card. You must do this in order to add new frames when either memory is already full.




Turn the DIAL SWITCH to SET UP MODE and then turn the POWER ON.

- Using the ▲▼ buttons, select "P.I.F. Frames" then press either the ► button or the ⚡ FLASH button.



- To delete the frames stored in the camera's memory use the ▲▼ buttons to select the frames you don't want.

You can also press the ⚡ FLASH button in order to access "In Memory Card".




NOTE




To delete the frames stored in the memory card use the ► button to select "In Memory Card". Use the ▲▼ buttons to select the frames you don't want.

You can also press the ⚡ FLASH button in order to access "In Camera".




- To delete the selected frame, press the Ⓜ MACRO button. A confirm message appears on the monitor. Press the ⚡ FLASH button to confirm deletion.

Press the Ⓜ MACRO button to stop the deletion process.




INSTALLING FRAMES

How to install frames from the memory card to the camera's memory or vice versa. You can store up to 2 frames in the camera.




Turn the DIAL SWITCH to SET UP MODE and then turn the POWER ON.

- Using the ▲▼ buttons, select "P.I.F. Frames" then press either the ► button or the ⚡ FLASH button.




- When you want to install frames from the memory card to the camera use the ► button to choose "In Memory Card", then use the ▲▼ buttons to select the desired frame.

Pressing the ⚡ MACRO button will delete the frame.



- NOTE** To transfer the frames stored in the camera use the ◀ button to select "In Camera". Use the ▲▼ buttons to select the frames you want. Pressing the ⚡ MACRO button will delete the frame.



- Once you press the ⚡ FLASH button, a confirmation message will appear on the monitor. Press the ⚡ FLASH button again to install the frame.

Press the ⚡ MACRO button to stop the process.


- NOTE** If there is not enough memory space available on either the camera or the memory card, the messages "Not enough free space on the memory card" or "Not enough free space in the camera's memory" will appear on the monitor. In this case, you must delete any frames you don't need in order to make enough room for another frame.

MACRO MODE

The MACRO mode allows you to focus on subjects at distances between 11-50cm (4.3-19.6 inches) from the camera.

When shooting objects that are 50cm or more away from the camera, reset the camera to NORMAL mode. (See page 21.)

TAKING PHOTOS IN MACRO MODE




Turn the DIAL SWITCH to PHOTO MODE and then turn the POWER ON.


Press the  MACRO button to switch to MACRO mode.

In MACRO mode, the zoom is automatically locked at **W**.

You will not be able to use the ZOOM buttons.




MACRO button DISPLAY button

Even if you have turned off the LCD monitor with the DISPLAY button, the  MACRO icon will still be visible.



FOCUS AREA



ALERT Remember the parallax problem when you take photos in the MACRO mode using the VIEWFINDER with the LCD monitor turned off. (See page 25.)

If the flash is used during very close shoots, the picture may come out overexposed. See page 30 for more detailed information on flash range.


CONTINUOUS SHOOTING

You can record images continuously by holding down the SHUTTER button.


CONTINUOUS SHOOTING



The flash will not work during continuous shooting.





Turn the DIAL SWITCH to PHOTO MODE and then turn the POWER ON.

1 Press the MENU button and select  CONTINUOUS SHOOTING with the ◀▶ buttons.

2 Select ON with the ▲▼ buttons.

3 While the SHUTTER button remains fully pressed, images will be recorded continuously.

When the DISPLAY button is pressed the  CONTINUOUS icon replaces the  FLASH icon.



Continuous Image Recording Table


Quality		Approximate Number of Shots	
RESOLUTION	COMPRESSION	NORMAL	FINE
Standard	★	Approx. 31 shots	Approx. 16 shots
Fine	★★	Approx. 8 shots	Approx. 5 shots
Super Fine	★★★	Approx. 4 shots	Approx. 4 shots



The total number of shots will vary according to quality, compression, the amount of memory left on the memory card and the shooting conditions.


SCENE MODES

When using a programmed SCENE mode, the camera is automatically configured to the best image capture settings for the situation.



Selecting the right mode helps you take the best photos automatically. And when combined with P.I.M. printing (See page 66.), the results will be terrific.


SELECTING A SCENE MODE



Turn the DIAL SWITCH to PHOTO MODE and then turn the POWER ON.

1

Press the MENU button and select **SCENE** SCENE mode using the ◀ ▶ buttons.



2

Use the ▲▼ buttons to select the specific SCENE mode you desire.


NOTE



FLASH control in SCENE mode

Any flash settings (See page 30.) can be used in SCENE mode. Please note that using either the NO FLASH or FORCED FLASH settings in dark scenes will lengthen the time of exposure (shutter speed) up to 1/2 sec. which may lead to blurring. The use of a tripod is recommended to prevent blurring.

NORMAL MODE



This mode is best for most shooting. The FLASH works automatically based on the available light on the subject. The SHUTTER speed is also selected to minimize blurring.

LANDSCAPE MODE

This mode is best for broad landscapes. The FLASH is deactivated and the depth of field is increased. In low light the shutter speed is slower so you can take night scenes. Use a tripod to prevent blurring.



PORTRAIT MODE



This mode is designed for personal portraits. The depth of field is reduced (1-3m) and the FLASH is automatically set to reduce red-eyes. When using the FORCED FLASH in dark settings the SLOW SYNCRO SHUTTER feature is set (See page 30.) allowing you to take shots with a brighter background. The use of a tripod is recommended to prevent blurring.

ALERT



When any SCENE mode is set, selecting MACRO shifts the camera settings to NORMAL mode. If you cancel the MACRO, the camera settings remains in NORMAL mode.

NOTE



When using SCENE mode

Using SCENE modes together with Exif 2.2 software and PRINT Image Matching II will provide the best possible printing results.

NOTE



Other camera settings and functions in SCENE mode

The Self timer, Exposure Adjustment, Resolution, Continuous Shooting, Digital Zoom, Frames, etc. are not affected by the SCENE mode.

WHITE BALANCE

The white balance function adjusts the camera for different kinds of lighting. It makes white look the same color in any situation. The camera has two white balance modes; automatic and manual. In manual mode you can change the color settings according to your own needs.




White Balance And Color Temperatures

Light comes in a range of colors from high-temperature sources like the sun which are bluer to low-temperature incandescent light bulbs which are redder. The human eye adapts to these differences automatically, so things usually look the same color to us under most lighting conditions. The camera's light sensors however, must sometimes be set to reproduce the truest colors under certain conditions.

AUTOMATIC WHITE BALANCE


In this mode the camera automatically senses the light source and corrects the colors so you get the same white in any lighting situation. We recommend that you regularly use the camera in this mode.



Turn the DIAL SWITCH to PHOTO MODE and then turn the POWER ON.

1

Press the MENU button and use the ◀▶ buttons to select **WB** WHITE BALANCE.




2

Select AUTO by using the ▲▼ buttons.

SELECTING WHITE BALANCE MANUALLY


You can select specialized white balance settings to achieve truer colors in certain conditions; DAYLIGHT, CLOUDY, INCANDESCENT, and FLUORESCENT.



Turn the DIAL SWITCH to PHOTO MODE and then turn the POWER ON.


1

Press the MENU button and use the ◀▶ buttons to select [WB] WHITE BALANCE.



2

Using the ▲▼ buttons select the best choice among auto, daylight, cloudy, incandescent and fluorescent.



Effective use of manual WHITE BALANCE.

- Pictures taken under fluorescent light tend to turn out greenish. Use the FLUORESCENT setting to correct for this.
- Incandescent light tends to make subjects appear reddish-yellow. Using the DAYLIGHT setting will allow reddish yellow colors of sunset to stay that way.


LIGHT SENSITIVITY

A roll of film loaded in a camera has a fixed light sensitivity, but the digital camera is more flexible. You can change the light sensitivity for a specific purpose any time manually or let the camera select it automatically.



In general, setting higher (ISO) light sensitivity allows for easier focusing and less chance of blurring. However your photos will appear grainier and you will lose color richness. Think about the shooting conditions and the results you want before you set the ISO.


Image Quality
Fine grain
Beautiful color



Recording Conditions
Surer focus
Less blurring

CHANGING TO AUTOMATIC SENSITIVITY MODE

The camera is set in AUTO mode at the factory, so there is no need to change anything to use this mode when you first begin. This is the best setting for most picture taking. The status is confirmed on the LCD monitor display. You can set this function during shooting with the viewfinder.




Turn the DIAL SWITCH to PHOTO MODE and then turn the POWER ON.

1

Press the MENU button and use the ◀▶ buttons to select **ISO** SENSITIVITY.


2

Select AUTO by using the ▲▼ buttons.



SETTING LIGHT SENSITIVITY MANUALLY

You can change the sensitivity to manual control. Use this mode when you expect blurring problems from camera motion, when you need to control depth of field and when you want to control FLASH range.



Turn the DIAL SWITCH to PHOTO MODE and then turn the POWER ON.

- 1 Press the MENU button and use the ◀▶ buttons to select [ISO] SENSITIVITY.



- 2 Using the ▲▼ buttons, you may select the desired sensitivity from [100] [200] or [400].



Situations for Manual Sensitivity Control


- When the image is too dark ,but you can't use the flash.
Or when the image is blurry, but you can't use the flash.
- When you must be moving the camera in order to get a shot.
OR when the object is blurry from moving at high speed.
- When you are anticipating problems in MACRO mode or any close-up situation.
When you get blurry results in MACRO or any close-up situation.
- When you want to record a distant object with the FLASH.
You can extend the range of the FLASH by increasing the sensitivity.

MAKING EXPOSURE SETTINGS

You can adjust exposure to help control how much light falls on the CCD. It influences the brightness of the entire image. You usually don't need to make manual adjustments, but it is possible to increase + or decrease – the exposure to suit a particular purpose.

It is recommended that these adjustments be used when shooting against the sun or when you have any very bright background where the automatic sensors may not work well.

ADJUSTMENTS



Turn the DIAL SWITCH to PHOTO MODE and then turn the POWER ON.

1

Press the MENU button and use the \blacktriangleleft \blacktriangleright buttons to select \blacksquare EXPOSURE ADJUSTMENT.

2

Select the adjustment value using the \blacktriangle \blacktriangledown buttons.



Effects of Exposure Adjustment



– 2.0EV



± 0EV



+ 2.0EV

NOTE



The exposure adjustment range is from – 2.0 EV to + 2.0 EV during programmed shooting. There are 9 steps of 0.5 EV each. You can confirm the setting on the Display Panel of the LCD monitor. (See page 22.42) You can also set the number while shooting through the VIEWFINDER.



Shot against the sun or bright background : + 1.5EV



Before Adjustments



Low key image : - 1.0EV



High key image : + 2.0EV



Effective Use of the Exposure Adjustment Controls

+ Adjustments

- To make white objects whiter, especially images of white paper in the MACRO mode, eliminating gray tones.
- To brighten the image of subjects that have the sun in the background.
- To brighten the image of subjects in very bright reflected light such as at the beach, in the snow or against a white wall. (The background may white out, but the subjects will show up clearly.)


- Adjustments

- To make a black object blacker, eliminating gray tones.
- When the subject is lit up by a spotlight on stage.
- To balance brightness when photographing objects against a background such as a black wall.

RESETTING TO DEFAULT MODE

How to return all settings to the Default mode.

RESETTING TO DEFAULT MODE



Turn the DIAL SWITCH to PHOTO MODE and then turn the POWER ON.


1

Press the MENU button and select  RESET DEFAULT using the ◀▶ buttons.


When the ⚡ FLASH button is pressed a message will appear on the monitor.



2

To reset to Default mode, press the  MACRO button to OK the reset.


Press the ⚡ FLASH button to cancel the reset.



VIEWING RECORDED IMAGE DATA

How to view technical data of recorded images.

DISPLAYING RECORDED IMAGE DATA



Turn the DIAL SWITCH to PLAYBACK MODE and then turn the POWER ON.

1

Press the MENU button and select **INFORMATION** with the ◀▶ buttons.


The image data will appear on the LCD monitor.
Press the ◀ button to return to the MENU.



2

Press the ▼ button to review the rest of the data for this image.


Press the ▲ button to view the previous data screen.



VIDEO CLIPS

How to record a VIDEO CLIP with sound, playback and delete video clips.

RECORDING A VIDEO CLIP



Turn the DIAL SWITCH to VIDEO CLIP MODE and then turn the POWER ON.

1 The VIDEO CLIP screen will appear on the LCD monitor.



Sound will be recorded along with the VIDEO CLIP. Make sure that you are not covering the mic when recording.



2 Press the SHUTTER button to begin recording the VIDEO CLIP.

The upper left corner of the monitor will display the VIDEO CLIP icon and the upper right corner will display the seconds until the camera's memory is full.



3 Press the SHUTTER button again to stop recording.

After you have finished recording, the sequence will be exported to the memory card. After the export is completed you may continue recording.




When recording a VIDEO CLIP, you must set the focus in the usual manner before recording. Once you begin recording, the focus cannot be changed, and the zoom buttons will not work.

NOTE



Selecting VIDEO CLIP Resolution

When you press the MENU button in VIDEO CLIP mode, the Resolution screen will appear on the monitor. Using the ▲▼ buttons, choose between 320 X 240 or 160 X 120 pixels. The Resolution screen will disappear when you press the MENU button again.



NOTE


VIDEO CLIP files are very large. Be sure you have enough memory space before you begin.

Image size	Recording Time (16MB)	Recording Time (8MB)
320 × 240 ★★	Approx. 60 seconds	Approx. 30 seconds
160 × 120 ★	Approx. 150 seconds	Approx. 70 seconds

Frame data will also be installed on the provided SD Memory card. This may reduce the total indicated on the table.

PLAYING BACK A CLIP

You can watch a Video Clip using the LCD monitor.



Turn the **DIAL SWITCH** to **PLAYBACK MODE** and then turn the **POWER ON**.

1

Select a sequence using the ◀▶ buttons.

Information for the VIDEO CLIP will appear on the LCD monitor.

**NOTE**

Press the **W** ZOOM button if you want to see multiple images at the same time. The 📺 icon will appear for VIDEO CLIPS.



2

Press the ⚡ FLASH button to playback a VIDEO CLIP.

Press the ⬇️ MACRO button to pause the playback.

Press the ⬆️ MACRO button again to resume the playback.


**NOTE**

Speaker Volume

You can adjust the speaker volume using the ▲▼ buttons.

DELETING VIDEO CLIPS

Deleting VIDEO CLIPS from the SD memory card. (See page 36.)



Turn the DIAL SWITCH to PLAYBACK MODE and then turn the POWER ON.

- 1 Find the VIDEO CLIP using the ◀ ▶ buttons, then use the ⏏ MACRO button to select it.

The VIDEO CLIP information will be displayed on the LCD monitor.

Press **W** on the ZOOM button in order to view 6 images at a time. The 📷 icon will appear for VIDEO CLIPS.



- 2 Using the ▲▼ buttons choose between "Delete this file." or "Delete all files.". Then press the ⚡ FLASH button to confirm deletion.

If you do not wish to delete any files, press the ⏏ MACRO button.

If the data is protected the screen "This file cannot be deleted because it is locked." or "Cannot be deleted." will come up (See page 99.)



- 3 If there is still data left on the memory card, the monitor will return to the PLAYBACK mode screen. If there is no data "No images" will be displayed.

DIRECT PRINTING

P.66	●	DIRECT PRINTING
P.67	●	DIRECT PRINTING PROCESS
P.70	●	PRINT Image Framer (P.I.F.) PRINTING
P.71	●	PRINTING PRINT Image Framer (P.I.F.) IMAGES
P.74	●	PRINT SETTINGS
P.77	●	PRINTER UTILITIES

DIRECT PRINTING

Printing directly from the camera to the printer is known as the **DIRECT PRINTING** process. You can print directly from this camera to a printer without going through a computer. Different models support different capabilities and hardware, so please confirm the compatibility of your printer before using.



ALERT The correct cable to be used can vary depending on the printer model. Please refer to the list below.

LIST OF COMPATIBLE PRINTERS

L300/200 Compatible Printers

Apr. 2003-present

MODEL	CABLE	MODEL	CABLE
Stylus Photo 810	Printer Cable 	Stylus Photo 935	PC Cable
Stylus Photo 830			
Stylus Photo 830U			
Stylus Photo 900			
Stylus Photo 1290s			



NOTE The information and settings fixed with each image are recorded in Exif.2.2 format by this camera. The information includes the SCENE mode and Lowlight scenes. You can print with PRINT Image Matching on any printer supporting this system.



About Exif Print & PRINT Image Matching


PRINT Image Matching is a program that will work with your digital camera and printer to create truly beautiful pictures. Pictures taken with this camera can be sent to the printer as is and it will print the image exactly the way the camera captured it. For the most up-to-date information please go to the EPSON website.



ALERT When you print with a printer that does not support PRINT Image Matching, or if you have made any changes using a photo software program, the PRINT Image Matching parameters will not be followed. The image will be treated (printed) as regular data, and will not show the changes made in the camera.

DIRECT PRINTING PROCESS

Please make sure to use the correct cable to connect the camera to the printer.
Turn the printer on and put the printer on standby. *Refer to the printer manual.*




The printing process quickly drains the battery. Using the AC adaptor is recommended when printing.

This illustration depicts the connections when using the Stylus Photo 830U. For other printers refer to the printer manuals.

PRINTING THE IMAGE SEEN ON THE LCD MONITOR

Only the images visible on the LCD monitor will be printed.



Turn the DIAL SWITCH to PLAYBACK MODE and then turn the POWER ON.

- Pressing the PRINT button changes the display to DIRECT PRINTING mode and highlights "Displayed image."

Press the MACRO button to return to PLAYBACK mode.


- Press the PRINT button again to confirm selection. Use the buttons to select the number of prints.

To change the print setting, press the MENU button. (See page 74.)

Press the FLASH button to display P.I.F. Editing mode.


- Press the PRINT button to begin printing.

Press the MACRO button to cancel printing.



PRINTING ALL THE IMAGES IN MEMORY

How to print all the images on the memory card.



Turn the DIAL SWITCH to PLAYBACK MODE and then turn the POWER ON.

1

Press the PRINT button to change the display to DIRECT PRINTING mode.

Press the MACRO button to return to PLAYBACK mode.

2

Using the buttons select "All Images." then press the PRINT button.

To change the print setting, press the MENU button. (See page 74.)

Review each image using the buttons. Select the number of copies of each image using the buttons. The default setting is 1 copy. You can set the number to "--" if you do not want a copy of a particular image.


Press the MACRO button to return to the previous step.

Press the FLASH button to display P.I.F. Editing mode.

3

Press the PRINT button to begin printing.


Press the MACRO button to cancel printing.



This camera displays the number of shots to be printed out of the total taken. StylusPhoto935 displays the number of shots remaining out of the total to be printed. This camera and StylusPhoto935 utilize different display methods.

PRINTING SELECTED IMAGES

How to select and print an image.



Turn the DIAL SWITCH to PLAYBACK MODE and then turn the POWER ON.

1


Press the PRINT button to change the display to DIRECT PRINTING mode.

Press the MACRO button to return to PLAYBACK mode.



2

Using the buttons select "Select Images." then press the PRINT button.



3

Use the buttons to choose the images, then use the buttons to enter the number of copies desired.

Press the MACRO button to return to step ②.

To change the print setting, press the MENU button. (See page 74.)

Press the FLASH button to display P.I.F. Editing mode.



4

Press the PRINT button to begin printing.

Press the MACRO button to cancel printing.




If any DPOF files (See page 80.) exist, a message will appear asking whether you would like the settings to be used. If you choose not to use the settings, all images will be set at "0".


PRINT Image Framer (P.I.F.) PRINTING

Images that have been taken in P.I.F. mode must be printed using DIRECT PRINTING in order for the frame to show up on the print. Any other printing method will break the link between the frame and the image and only the image will be printed with no frame.

Shooting in P.I.F. mode



Using DIRECT PRINTING



Printing through your computer



When an image that has been taken in P.I.F. mode is transferred to a computer the link is broken and the frame will not be printed on the image.

Printing from the memory card



PRINTING WITH A Stylus Photo 935



Frame will not be printed.

PRINTING AT A DIGITAL PRINT SHOP



Frame will not be printed.




When images are shot in P.I.F. mode and the data in the memory card is set in DPOF, if the images are printed with a Stylus Photo 935, the first frame in the list will be selected.

PRINTING PRINT Image Framer (P.I.F.) IMAGES

PRINTING THE P.I.F. IMAGE DISPLAYED ON THE LCD MONITOR


How to print images taken in P.I.F. by using the DIRECT PRINTING method.



Turn the DIAL SWITCH to PLAYBACK MODE and then turn the POWER ON.

1

Select an image taken in P.I.F. and display it on the monitor.



2

Press the PRINT button to display the DIRECT PRINTING screen.

Press the MACRO button to return to PLAYBACK mode.




3

Press the PRINT button again to print the image.


Press the MENU button to change the print settings. (See page 74.)

Press the MACRO button to return to step ②.



OTHER P.I.F. PRINTING OPTIONS

You can also print all or only a selected set of images taken in P.I.F. mode.



Turn the DIAL SWITCH to PLAYBACK MODE and then turn the POWER ON.

1

Press the PRINT button. The LCD monitor will show the print screen.

Press the MACRO button to return to PLAYBACK mode.

2

Use the buttons to select the print option, then press the PRINT button.

If you choose "All Images" every single picture will be printed. However, you may also choose to print only a group of images that you select. (See page 68-69.)

If you choose "Select Images" only those you mark will be printed, together with their frames. Images not taken in P.I.F. will be printed normally. You can also print multiple copies of each. (See page 69.)



ALERT

If any DPOF files (See page 80.) exist, a message will appear asking whether you would like the settings to be used. If you choose not to use the settings, all images will be set at "0".

3


Press the PRINT button to begin the printing process.

Press the MENU button to change the print settings. (See page 74.)

Press the MACRO button to return to step 2.

CHANGING THE FRAMES

Frames may be changed when printing directly from the camera.



Turn the DIAL SWITCH to PLAYBACK MODE and then turn the POWER ON.

1

When viewing 1 image, use the ◀▶ buttons, when viewing 6 use the ▲▼ ◀▶ buttons to choose the images you wish to print. Press the PRINT button to go to the printing screen.



For PRINTING mode see pages 67-69.



2

Use the ▲▼ buttons to select the desired option, then press the PRINT button.

Press the MENU button to change the print settings. (See page 74.)



Screen for printing "Displayed image." Screen for printing "All images." Screen for printing "Selected images."

3


Press the FLASH button and frame choices will be displayed on the monitor.

Press the MACRO button to return to step ②.

4

Use the ▲▼ buttons and display the frame that you would like to use. To remove a frame select the number "---".

Press the MACRO button to return to step ②.




5

Press the FLASH button to link the displayed frame to your picture.


PRINT SETTINGS

How to select different print settings for better images.

HOW TO CHANGE PRINT SETTINGS



Turn the DIAL SWITCH to PLAYBACK MODE and then turn the POWER ON.



1

Press the PRINT button to change the display to DIRECT PRINTING mode.

Press the MACRO button to return to PLAYBACK mode.

2


Use the buttons to select the print option, then press the PRINT button.

3

Press the MENU button to go to PRINT SETUP.

Press the MENU button or the MACRO button to return to step ②.

Press the button to go to the "Utility" screen.



The next steps are all continued from


4


SETTING PAPER SIZE

How to specify the size of the paper for your photo.


Continued from page 74

4 Use the ▲▼ buttons and select "Paper Size".

Press the MENU button or the  MACRO button to return to step ②.



5 Use the ◀▶ buttons to change the settings.

Press the MENU button or the  MACRO button to return to step ②.

NOTE



You can choose to print on any of two sizes of Premium Glossy paper: "4" X 6" / PM Glossy", "100 X 150 mm/PM Glossy".




SELECTING PRINT BORDERS


You can print pictures with or without borders.

Not to be confused with frames, borders refer to white spaces between the edges of the photo and the edges of the paper.


Continued from page 74

4 Use the ▲▼ buttons and select "Border".

Press the MENU button or the  MACRO button to return to step ②.



5 Use the ◀▶ buttons to change the settings.

Press the MENU button or the  MACRO button to return to step ②.


PRINTING THE DATE

All pictures taken have a record of the date (Y.M.D. or D.H.M.).
You can choose to print the date record on your pictures.

Continued from page 74.


4


Use the ▲▼ buttons and select "Date".

Press the MENU button or the  MACRO button to return to step ②.

5

Use the ◀▶ buttons to change the settings.

Press the MENU button or the  MACRO button to return to step ②.



ALERT

This camera can combine a photo and a frame so the user can print it with the DIRECT PRINTING mode. If the user tries to choose Date to Print with the frame, the date is not printed because the frame composition takes precedence.


HIGH SPEED PRINTING

You may print your pictures faster, but the quality will be affected. HIGH SPEED OFF produces higher quality prints.

Continued from page 74.


4


Use the ▲▼ buttons and select "Mode".

Press the MENU button or the  MACRO button to return to step ②.

5

Use the ◀▶ buttons to change the settings.

Press the MENU button or the  MACRO button to return to step ②.




ALERT

- The finished product may vary slightly depending on the size of paper or the type of printer you use.
- The P.I.F. (image) you see in the LCD monitor may vary from the printed outcome.
- If the user selects High Speed mode on the camera, StylusPhoto935 prints the image in "high" quality mode. If Normal Speed is selected, the StylusPhoto935 prints in "super high" quality mode.


PRINTER UTILITIES

You may use a range of supported printer utilities.



PRINTER UTILITIES



Turn the DIAL SWITCH to PLAYBACK MODE and then turn the POWER ON.



- 1** Press the PRINT button to change the display to DIRECT PRINTING mode.
Press the MACRO button to return to PLAYBACK mode.
- 2** Use the buttons to select the print option, then press the PRINT button.
- 3** Press the MENU button to go to PRINT SETUP.
Press the MENU button or the MACRO button to return to step 2.
- 4** Press the button to go to the "Utility" screen.
Press the button to go to the "Print Setup" screen.



The next steps are all continued from


5

TEST PRINTING FOR NOZZLE CHECK

You can use the "Nozzle Check" to test the printer when there is a problem with the printed image.

Continued from page 77.


5 Use the ▲▼ buttons and select "Nozzle Check".

Press the MENU button or the  MACRO button to return to step ②.

6 Press the ⚡ FLASH button.

The message "Print a Nozzle Check pattern? Load A4 or Letter size paper." will appear on the monitor. Place the paper in the printer and then press the ⚡ FLASH button to print the Nozzle Check pattern.

To check the printed Nozzle Check pattern, or to fix any gaps, refer to the instructions provided with your printer.




If the printer you are using does not support the Nozzle Check feature, the message "This function cannot be performed from the camera with the printer you are using." will appear on the monitor. In this case refer to the printer manual.

HEAD CLEANING

If the printed images appear smudged or the printing is patchy, use this utility to clean the printer head.


Continued from page 77.

5 Use the ▲▼ buttons and select "Head Cleaning".

Press the MENU button or the  MACRO button to return to step ②.

6 Press the ⚡ FLASH button.

At this time the message "Clean the print head?" will appear on the monitor. Press the ⚡ FLASH button to begin the head cleaning process.



If the printer you are using does not support the Head Cleaning feature, the message "This function cannot be performed from the camera with the printer you are using." will appear on the monitor. In this case refer to the printer manual.

ADDITIONAL SETTINGS

P.80	●	DIGITAL PRINT ORDER FORMAT(DPOF)
P.80	●	SAVING PHOTOS IN DPOF
P.81	●	SOUND AND SHUTTER SETTINGS
P.82	●	AUTO POWER SAVE
P.82	●	RESETTING THE AUTO POWER SAVE
P.83	●	DATE & TIME AND DATE/TIME FORMATS
P.84	●	ADJUSTING LCD BRIGHTNESS
P.85	●	MEMORY CARD FORMATTING
P.86	●	RULES FOR NAMING FILES (Cumulative function)
P.86	●	RESETTING FILE NUMBERS
P.87	●	RESETTING VIDEO OUT
P.87	●	SETTING THE MENU LANGUAGE
P.88	●	RESETTING CAMERA DEFAULTS


DIGITAL PRINT ORDER FORMAT (DPOF)

DPOF is the abbreviation for Digital Print Order Format. This format allows you to record information on the SD memory card including which images and how many copies you want to have printed out.




From this camera, you may use the PRINT button to select certain pictures and set them as DPOF formatted picture files. By saving this information onto a memory card, you can print these pictures easily with printers that can read and understand DPOF files.

No computer is required. Simply use the controls on the LCD monitor to format the files.



SAVING PHOTOS IN DPOF



Turn the DIAL SWITCH to **PLAYBACK MODE** and then turn the **POWER ON**.

1

Press the **PRINT** button to change the display to **DIRECT PRINTING mode**.

Press the **MACRO** button to return to **PLAYBACK mode**.

2

Using the buttons to select "**Make print order.**" and press the **PRINT** button.

Press the **MACRO** button to return to step ①.



NOTE




Message Icon



Viewable on the LCD monitor but not printable.

- 3** Highlight an image you want to print as DPOF with the ◀▶ buttons. Use the ▲▼ buttons to enter the number of copies. Then press the ⚡ FLASH button to save the data to the memory card.



When making a print order with DPOF, you may print 99 copies of one image. You may copy up to 999 different images, but you may only print up to 9999 copies in DPOF. Press the 📷 MACRO button to cancel.



DPOF Printing Options


- You can print the selected images with the [EPSON PhotoQuicker] when you connect the camera to the computer and run EPSON Camera Starter.
- You can print the selected images by removing the memory card from the camera and inserting it into a printer that is made to read DPOF files.
- You can remove the memory card from the camera and bring it to a local digital print service photo shop which will print the selected files.



Frame data cannot be read by DPOF printers. Framed images may be printed only by DIRECT PRINTING methods. (See page 66.)

SOUND AND SHUTTER SETTINGS

You can choose one of the various Shutter Release sounds and/or choose to turn shutter and other camera operation sounds on or off.



Turn the DIAL SWITCH to SET UP MODE and then turn the POWER ON.

The SETUP menu will appear on the LCD monitor.


- 1** Use the ▲▼ buttons to choose "Shutter" or "Sound". Use the ◀▶ buttons to change the settings.

Shutter Sound Settings

SETTINGS	EFFECT
Beep (Default)	Beep sound
Sound 1	Traditional shutter sound-A
Sound 2	Traditional shutter sound-B


Sound Settings

SETTINGS	EFFECT
ON (Default)	Both OPERATION & SHUTTER sounds ON
OFF	Both OPERATION & SHUTTER sounds OFF
Shutter	Only SHUTTER sound is ON



ADJUSTING LCD BRIGHTNESS

You may change the brightness of the LCD monitor




Turn the DIAL SWITCH to SET UP MODE and then turn the POWER ON.

The SETUP menu will come up on the monitor.

Use the ▲▼ buttons to choose "LCD Brightness".

Use the ◀▶ buttons to change the settings.



Brighter LCD monitor



Darker LCD monitor


MEMORY CARD FORMATTING

You can reset the card to its default status.



- Everything on the card will be completely deleted!
- Please note that when a memory card is formatted, all the data that was included in the card at the factory like the PRINT Image Framer frames will also be deleted.
- Back up desired images by exporting them to a computer before you reformat.
- Never format a camera memory card using a computer. Use this camera only.

SET
UP




Turn the DIAL SWITCH to SET UP MODE and then turn the POWER ON.

The SETUP menu will appear on the LCD monitor.

1


Choose **FORMAT** using the ▲▼ buttons, then press either the ► or ⚡ FLASH button.



2

The message "All data on the memory card will be erased." will appear. Press the ⏏ MACRO button to go ahead with the formatting.

If you wish to cancel the "Format" action, press the ⚡ FLASH button.




NOTE



SD MEMORYCARD LOCKING MECHANISM

How to protect your precious photos from accidental deletion. Slide the small switch on the side of the SD memory card in the direction of the arrow to the LOCK position. Images will not be able to be deleted or overwritten. If you try to take a photo when the card is locked the message "This memory card is write-protected." appears on the monitor.



AUTO POWER SAVE

When the camera is turned on but inactive for a period of time, the camera automatically shuts down to save battery power.

- 1** When there is no activity for over 3 minutes, the camera will enter sleep mode.

While in sleep mode, the green light will flash. The LCD monitor will turn off and the CPU will also be in sleep mode.




NOTE To cancel Sleep mode, press the SHUTTER button, or any other button on the back of the camera. You can also simply turn the DIAL SWITCH.

- 2** When the camera is left in Sleep mode for over 10 minutes, it will shut down automatically.

The lens will retract and the lens cover will close.

RESETTING THE AUTO POWER SAVE


You can change the setting for Auto Power Save. The default is 3 minutes, but you can also choose 1, 5 or 20 minutes.



Turn the DIAL SWITCH to SET UP MODE and then turn the POWER ON.

The SETUP menu will appear on the LCD monitor.


- 1** Use the ▲▼ buttons to choose "Power Save". Use the ◀▶ buttons to change the setting.



NOTE When using an AC adapter When you are using an AC adapter, the camera will enter sleep mode after 20 minutes (no matter what the settings). The camera will automatically turn off 5 minutes after it has entered sleep mode.

DATE & TIME AND DATE/TIME FORMATS

How to set the Date and Time



Turn the DIAL SWITCH to SET UP MODE and then turn the POWER ON.

The SETUP menu will appear on the LCD monitor.

- Use the ▲▼ buttons to choose "Date/Time".
Use the ◀▶ buttons to choose the year/month/date.








The limit on setting the DATE and TIME is 2033.12.31.

- Use the ▲▼ buttons to change the numbers then press the ⚡ FLASH button to confirm the new value.
Press the 🍀 MACRO button to deselect.

- Use the ▲▼ buttons to select "Date Format" then use the ◀▶ buttons to select "Y.M.D. 24hr".

- Use the ▲▼ buttons to change to "M.D.Y.". Use the ◀▶ buttons to select the "hr" format. Then use the ▲▼ buttons again to change to "12 hr".

- To confirm the new formats, press the ⚡ FLASH button.
Press the 🍀 MACRO button to deselect.




RULES FOR NAMING FILES (Cumulative function)

Explanation of the rules for naming files

The format for an image file name must always be EPSNXXXXXX.xxx

Pictures (image files) and linked files are automatically numbered by the camera. When the setting for "File Number Reset" is ON, the numbers are counted from EPSN0001.xxx in each new folder.


When "File Number Reset" is OFF, the numbering is cumulative. For example, if the last picture on one memory card is ESPN0500.jpg, the picture on a new card will be numbered ESPN0501.jpg.

ALERT  **Memory cards and file names.**

- If you change the name of a file on the memory card, the camera may have trouble retrieving that file.
- When folder numbers reach 999, or file numbers reach 9999, you will not be able to add any more photos to that memory card. Replace it with a new one.
- When you copy any data to a computer, be sure that the same file name (number) doesn't already exist in your picture directory. The newly copied file could overwrite the existing one and you would lose it.

RESETTING FILE NUMBERS

It is possible to reset the sequence of image file numbers.

FYI  **About file numbers**

Picture files are automatically numbered so that no two files can have the same number. They are numbered in the order in which they are shot.


SET
UP



Turn the DIAL SWITCH to SET UP MODE and then turn the POWER ON.


The SETUP menu will appear on the LCD monitor.

Use the ▲▼ buttons to choose "File No. Reset" then use the ◀▶ buttons to choose either ON or OFF.



RESETTING VIDEO OUT


You may have to reset the "video out" to match the national video system of wherever you may be showing pictures.



Turn the DIAL SWITCH to SET UP MODE and then turn the POWER ON.

The SETUP menu will appear on the LCD monitor.


Use the ▲▼ buttons to choose "Video out".
Use the ◀▶ buttons to change the setting.



NOTE
About Video Signals
There are two available settings, NTSC and PAL, each used in different countries.

SETTING THE MENU LANGUAGE


You can change the language displayed on the LCD monitor.



Turn the DIAL SWITCH to SET UP MODE and then turn the POWER ON.

The SETUP menu will appear on the LCD monitor.

1 Use the ▲▼ buttons to choose "Language".
Use the ▶ buttons to select the language list.




2 Use the ▲▼◀▶ buttons to highlight the language you want to use for the LCD monitor. Press the ⚡ FLASH button to confirm the selection.



RESETTING CAMERA DEFAULTS

How to reset the camera to the original factory default settings.




Turn the DIAL SWITCH to SET UP MODE and then turn the POWER ON.

The SETUP menu will appear on the LCD monitor.

1


Use the ▲▼ buttons to choose **RESET DEFAULT**. Press the ⚡ **FLASH** button.



2

To reset the camera to its original default settings, press the 🍷 **MACRO** button.

To cancel the default resetting, press the ⚡ **FLASH** button.



ADDITIONAL INFORMATION

P.90 ● CLEANING THE CAMERA

P.91 ● SPECIFICATIONS L-300

P.92 ● SPECIFICATIONS L-200

CLEANING THE CAMERA

It is important to keep the camera clean so it will function well **anytime** you need it.

CAUTION



When performing any camera maintenance, be sure to disconnect the AC adapter. Otherwise, you could receive a shock.

WHEN THE CAMERA NEEDS CLEANING

CLEANING THE CAMERA EXTERIOR

Wipe the outside of the camera with a soft dry cloth. If there is heavy soil use a cloth dampened with a natural detergent. Wipe again with soft dry cloth.

To clean the lens make sure the camera is turned off, then blow off any loose dust or dirt or use a lens and camera cleaning brush. Next, blow on the lens and wipe off all moisture with a soft dry cloth.

Clean the LCD monitor also with a soft dry cloth.

CLEANING BATTERY TERMINALS

When the battery terminals or contacts on the battery cover and compartment become dark (oxydized) you should wipe them with a clean dry cloth.

If the battery terminal is dirty, it may shorten the life of the battery.

CAUTION



NEVER use volatile chemicals such as alcohol, paint thinner or benzine. They will damage the camera exterior. The same is true for the battery compartment.

STORING THE CAMERA

CAUTION



The camera is made of precision electronic components sensitive to strong magnetic fields. Be careful where you store it. Please refer to the SAFETY INSTRUCTIONS listed at the beginning of this User's Guide. For more information, see page 102 for the CUSTOMER SERVICE SUPPORT section.

Store the camera in a cool and dry location and remove the batteries to prevent corrosion or leaks if you will not be using the camera for a long period of time.

SPECIFICATIONS L-300

General

Dimension	105mm (Width) × 60mm (height) × 31.5mm (Depth) <i>except parts that stick out</i>
Weight	185g <i>without batteries, memory card and strap</i>
Power supply	AA-size alkaline batteries × 4 AA-size Ni-MH batteries × 4 AA-size nickel-manganese batteries × 4 <i>can not use AA-size manganese battery and lithium batteries</i>
External power supply	Dedicated AC Adapter Model: A211H Input: AC 100V-240V, 50-60Hz Output: DC 6.0V 2.0A Power consumption: 0.3A, 16W Temperature: 5 to 35°C Dimensions: 43 × 104 × 31mm
Recording media	SD Memory Card <i>max 512MB</i> MultiMedia Card(MMC) <i>max 512MB</i> <i>Hitachi or SanDisk MMC cards v2.1 or later.</i>
Image recording capacity	<when using 16MB SD Memory Card> Standard 640 × 480 pixels: 127 images Fine 1600 × 1200 pixels: 35 images Super fine 2048 × 1536 pixels: 21 images <i>New or formatted memory cards without any P.I.F. data and images taken at normal compression.</i>

Optical

CCD	1/2.5 inch color area CCD Primary color filter
Effective pixels	3.24 megapixels
Lens	f=5.6 to 16.8mm <i>equivalent to a 34 to 102mm lens on a 35mm camera.</i> F2.8 (WIDE) to 4.9 (TELE) 7 elements in 6 groups (including 2 aspherical lenses.)
Aperture	Wide angle; F2.8/F4.8, Telephoto; F4.9/F8.4
Viewfinder	Real-image optical view range approx. 77%
Focus	Auto focus
Focal length	0.5m to infinity 0.11 to 0.5m (macro mode, wide)
Shutter	Mechanical shutter with electric iris
Shutter speed	Still picture; Normal mode 1/2 - 1/2000 seconds Landscape mode 1/2 - 1/2000 seconds Portrait mode 1/2 - 1/2000 seconds Movie; 1/32 - 1/6200 sec

SPECIFICATIONS L-200

General

Dimension	105mm (Width) × 60mm (height) × 31.5mm (Depth) <i>except parts that stick out</i>
Weight	185g <i>without batteries, memory card and strap</i>
Power supply	AA-size alkaline batteries × 4 AA-size Ni-MH batteries × 4 AA-size nickel-manganese batteries × 4 <i>can not use AA-size manganese battery and lithium batteries</i>
External power supply	Dedicated AC Adapter Model: A211H Input: AC 100V-240V, 50-60Hz Output: DC 6.0V 2.0A Power consumption: 0.3A, 16W Temperature: 5 to 35°C Dimensions: 43 × 104 × 31mm
Recording media	SD Memory Card <i>max 512MB</i> MultiMedia Card(MMC) <i>max 512MB</i> <i>Hitachi or SanDisk MMC cards v2.1 or later.</i>
Image recording capacity	<when using 8MB SD Memory Card> Standard 640 × 480 pixels: 62 images Fine 1280 × 960 pixels: 32 images Super fine 1600 × 1200 pixels: 16 images <i>New or formatted memory cards without any P.I.F. data and images taken at normal compression.</i>

Optical

CCD	1/2.5 inch color area CCD Primary color filter
Effective pixels	2.00 megapixels
Lens	f=5.6 to 16.8mm <i>equivalent to a 34 to 102mm lens on a 35mm camera.</i> F2.8 (WIDE) to 4.9 (TELE) 7 elements in 6 groups (including 2 aspherical lenses.)
Aperture	Wide angle; F2.8/F4.8, Telephoto; F4.9/F8.4
Viewfinder	Real-image optical view range approx. 77%
Focus	Auto focus
Focal length	0.5m to infinity 0.11 to 0.5m (macro mode, wide)
Shutter	Mechanical shutter with electric iris
Shutter speed	Still picture; Normal mode 1/2 - 1/2000 seconds Landscape mode 1/2 - 1/2000 seconds Portrait mode 1/2 - 1/2000 seconds Movie; 1/32 - 1/6200 sec

TROUBLESHOOTING

P.94 ● TRUBLESHOOTING

P.99 ● LIST OF ERROR MESSAGES

TROUBLESHOOTING

This manual has a list of common operating problems and simple solutions. Look up the problem and see the appropriate manual page when necessary.

IF YOU RUN INTO TROUBLE

- The list of common camera problems and solutions begins on page 94.
- For an explanation of error messages displayed on the LCD monitor see page 99.

CAUTION



If any of the following occurs to the camera, immediately take out the batteries, disconnect AC adapter or recharger plug and take the camera to the store you where you bought it or call the EPSON customer service center.

- If the camera itself, recharger, or AC adapter begins to heat up to excessively high temperatures, or if the case changes shape.
- If it starts to smell funny, gives off a strange sound or begins to smoke. Internal electricity is high voltage so do not take it apart to avoid the possibility of electrocution.

BEFORE YOU CALL CUSTOMER SUPPORT

Before calling the customer support with questions or for repair, refer to the "List of Error Messages." If you cannot find the answer even after checking through this list, contact the appropriate place for answers.


■ If your camera breaks down

You cannot personally fix or replace parts within the camera itself. If your camera breaks down or needs to be looked at, take it to the store where you bought it or contact the EPSON customer service center.

For the number of EPSON customer support see page 102.


CAMERA BODY PROBLEMS

CAMERA POWER WON'T TURN ON.





Did you insert the batteries correctly?

Check the (+ -) direction of the battery poles to be sure they are inserted correctly. (See page 17.)



Do you have enough battery life?

The low battery icon  on the display panel indicates when the battery power is too low. Replace them when the  begins to flash. (See page 17.)



Did you turn the DIAL SWITCH fully?

Turn the DIAL SWITCH fully to the mode you want and press the POWER button fully. (See page 18.)

YOU CAN'T TAKE A PHOTO.

check



Is the power switched on?

See [Camera won't turn on] above and check the camera.

check



Did you insert a memory card?

You can't take photos without a memory card. (See page 16.)

check



Do you have enough space left on the memory card?

You can't take photos when the memory card is full. (See page 16.)

check



Did you press the SHUTTER button fully and straight down?

The button must be pressed fully and straight down to take a photo.

check



Is the photo image number on the LCD display 0?

This means the memory card is full. Transfer the contents of the full card to a PC then delete them from the card to free up space. (See page 29.)

check



Is the red indicator light on?

Turn off the power. Turn the DIAL SWITCH to PHOTO mode and turn on the power again. If the power won't turn off, remove the batteries or disconnect the AC power, replace them or reconnect and turn the power on. If the red light is still on, bring the camera to the shop where you bought it or the EPSON service center.

THE POWER SWITCHES OFF AUTOMATICALLY.

check



Is Power Saving turned on?

Turn off the Power Save function. (See page 82.)

IT TAKES A LONG TIME TO TAKE A PHOTO.

check



Did you press the SHUTTER button completely?

Usually you should press the SHUTTER button halfway and hold it to set the focus, then press the rest of the way to take a photo. (See page 21.)

When you press the SHUTTER button fully all at once, it takes time to focus and set the exposure before the shutter releases. It may seem to take longer than when you do it in two steps.

NO FLASH.

check



The flash doesn't work.

Is the FLASH setting correct? ⚡ "No Flash" If the flash is set for external lights, the camera's own flash will not go off. (See page 30.)

THERE IS NO PLAYBACK IMAGE ON THE LCD MONITOR.**check****Did you turn the DIAL SWITCH completely?**

Turn the DIAL SWITCH carefully to PLAYBACK. Be sure to turn press the POWER button fully (See page 22.)

check**Is Power Saving turned on?**

Turn off the Power Save function. (See page 82.)

check**Is the camera connected to a TV?**

When the camera is operating on batteries only while connected to TV, the LCD monitor is disabled.

check**Is the camera connected to a computer?**

When the camera is connected to a computer, the LCD monitor is disabled.

AFTER TAKING A PHOTO THROUGH THE LCD MONITOR THE DISPLAY PANEL DISAPPEARS.**check****Is Power Saving turned on?**

If the power saving interval is set at 1 minute, it may simply be that the power saving is working properly. You can extend the time it takes before going into sleep status. You can also turn it off. (See page 82.)

check**Are your batteries strong enough?**

When the batteries are low, the LCD monitor will turn off briefly while the camera recycles for the next shot.

THE LCD MONITOR IS HARD TO SEE.**check****Have you tried adjusting the LCD monitor brightness level?**

Adjust the "LCD Brightness" control. (See page 84.)

THE LCD MONITOR DISPLAYS VERTICAL LINES.**check****Did you point the camera toward very bright light?**

When you use the LCD monitor to take photos, any very bright light may affect the CCD and cause the lines to appear on your screen. They will NOT appear in the recorded image itself.

NO IMAGE APPEARS ON THE TV SCREEN WHEN THE CAMERA IS CONNECTED.**check****Is the power switched on?**

See [Camera power won't turn on] on page 94 and check the camera.

check



The camera connected correctly to the TV?

Check that the camera-AV cable is connected properly at both ends. (See page 38.)

check



Is the TV set up to recognize the camera as a picture source?

Check that the TV/video selector on your TV is on [video]. See your TV instruction booklet for details.

check



Is the [video out] correctly selected on the camera?

Check to see that the [video out] control (NTSC/PAL) is correctly set for the TV system of the country where you are showing your pictures. (See page 87.)

IMAGE PROBLEMS

IMAGES ARE OUT OF FOCUS.

check



Did you operate the auto-focus correctly?

To use auto-focus, place the subject in the center of the viewfinder and press the SHUTTER button halfway. (See page 22.)

check



Is the camera in the right distance mode setting?

Be sure to take photos no closer than 50 cm from the camera in NORMAL mode. For distances from 11-50 cm, use the MACRO mode. (See page 50.)

check



Is the lens dirty?

Use an lens cleaning brush or gently blow on the lens to free it of dirt. Then blow on it and wipe it with a soft dry cloth. (See page 90.)

check



Is the captured image blurred?

Hold the camera in the proper position when shooting, with your lower, support arm close to your body. (See page 22.) Use a tripod for night views and other low light situations.

check



Did you touch the lens during shooting?

If you touch the lens during shooting, the lens may become dirty and the picture may come out blurred. Holding the camera in the proper position will help you in not touching the lens. (See page 20.) If the lens becomes dirty in any way, use a soft dry cloth to wipe it. (See page 90.)

THE IMAGE IS TOO DARK.

check



Use the flash.

See page 30 to learn about the range of the flash. If you use external flash sources, refer to the device's instruction booklet.

check



Adjust the exposure control in the + direction.

You can brighten shots by adjusting the Ev control. (See page 58.)

check

**Select a higher light sensitivity setting.**

This is especially useful when it's impossible to use a flash. (See page 57.)

THE IMAGE IS TOO BRIGHT.

check

**Did you have to point the camera toward a strong bright light?**

Move your subject so the light is behind the camera.

check

**Avoid using the flash for close-ups.**

Set the control for NO FLASH. (See page 30.) If the image is too dark, increase the light sensitivity setting. (See page 57.)

check

**Adjust the exposure control in the - direction.**

You can increase brightness by adjusting the Ev control. (See page 58.)

PART OF THE IMAGE IS MISSING.

check

**Was your finger covering the lens?**

When you take photos using the viewfinder, it is possible that fingers, straps or pieces of clothing may be partially covering the lens.

check

**Are you looking straight through the viewfinder?**

You can misjudge the composition of the picture if you are looking through the viewfinder at an angle or holding the camera away from your face.

check

**Is the subject of the picture very close to the camera?**

When the object is less than 1 meter from the lens, you may be experiencing parallax problems. (See page 25.) You may want to compose the shot using the LCD monitor. (See page 22.)

THE IMAGE COLOR IS WRONG.

check

**Is the white balance set correctly?**

- If you use the AUTO setting under fluorescent lighting conditions, the image is balanced only for green light. Instead, use the FLUORESCENT setting and the camera will adjust to the specific fluorescent source in your scene.
- Use the INCANDESCENT, when you want to keep the reddish orange hues that come from shooting at sunset.

PRINTING PROBLEMS

See pages 77-78 or your printer instruction booklet for details.

LIST OF ERROR MESSAGES

Follow the appropriate instructions below when the error message appears.

PHOTO MODE MESSAGES

MESSAGE	PROBLEM & SOLUTION
This memory card is write-protected.	Problem:Memory card is locked. Solution:Unlock the memory card by hand. (See page 85.)
Memory card error. Check the memory card.	Problem:Unspecified memory card problem. Solution:Remove the card and replace it. (See page 16.) Contact the card maker.
No memory card inserted.	Problem:The camera has no memory card inserted. Solution:Insert a memory card. (See page 16).
The memory card is full.	Problem:No more room for data on the memory card. Solution:Make room by deleting data (See pages 36-37.) or export the data to your computer and then reformat the card. (See page 85.)
No Frames.	Problem:No frames stored in the camera. Solution:Load up to 2 frames into the camera.(See pages 48-49.)
This Frame file cannot be used with this camera.	Problem:The camera doesn't support the frame. Solution:Reload with different frame that can be used with this camera. (See pages 49.)

PLAYBACK MODE MESSAGES

MESSAGE	PROBLEM & SOLUTION
No images	Problem:There are no images recorded on the memory card. Solution:Insert a memory card with images. Also check the image after each shot to confirm.
This image cannot be displayed.	Problem:The image file exists but can't be displayed. Solution:Playback System (See page 32.)
This file cannot be deleted because this file is locked or cannot be deleted.	Problem:This image has been locked to prevent deletion. Solution:Delete the image with the machine that took the image or locked it.
Some files are locked or could not be deleted.	Problem:Some images on this card have been write-protected. Solution>Delete the image with the device that took the image or locked it.
The necessary Frame file does not exist or is unusable.	Problem:The picture can't be viewed because there is no file or the link has been broken. Solution:The link has been broken or the frames itself has been deleted. Replace or add a frame linked to this file. (See pages 49.)

SET UP MODE MESSAGES

MESSAGE	PROBLEM & SOLUTION
Not enough free space on the memory card.	Problem:Not enough memory left on the card to record the picture. Solution:Either delete some pictures or reformat the card. (See pages 36-37.)
Not enough free space in the camera's memory.	Problem:Not enough camera memory to transmit the frame. Solution>Delete one or more PIF frames from camera memory. (See page 48.)
A Frame with the same name already exists. Replace it with this Frame?	Problem:Another frame with this name exists either on the memory card or in the camera. Solution:You may choose to replace it. Please note that the new file will overwrite the existing one.

DIRECT PRINTING MESSAGES

MESSAGE	PROBLEM & SOLUTION
Battery power is low. Connect AC adapter.	Problem:Little battery power remaining. Solution:The camera won't continue to direct print when the power is low. Connect to AC power.
Make sure that the printer is on and connected.	Problem:The DP cable is disconnected; the printer selected doesn't support the direct printing; is connected to another device (other than a computer), the printer power is turned off. Solution:Reconnect the camera correctly to the printer and turn the printer power on. (See page 66.)
Black ink out. Replace the black ink cartridge.	Problem:The printer is out of black ink. Solution:Replace the black cartridge following the printer instruction booklet.
Color ink out. Replace the color ink cartridge.	Problem:The printer is out of colored ink. Solution:Replace the colored cartridge(s) following the printer instruction booklet.
Check the ink cartridges.	Problem:An ink cartridge is missing or not set properly in the printer. Solution:Set or reset ink cartridge(s) following the printer instruction booklet.
Paper out. Load paper.	Problem:The paper isn't set properly in the printer. Solution:Set or reset the paper following the printer instruction booklet
Paper jam.	Problem:A sheet of paper has jammed during printing. Solution:Clear the jam following the printer instruction booklet.
This image cannot be printed.	Problem:You have selected an image that can't be printed. Solution:Select another image.

MESSAGE	PROBLEM & SOLUTION
Printer error.	<p>Problem:There may be a problem with the printer.</p> <p>Solution:Turn the printer off for a few seconds then turn the power back on. If the error message still appears, turn the power off and check to see if there is anything (packing materials, paper) stuck inside the printer. Then turn the power back on.</p>
There is no response from the printer.	<p>Problem:The printer has frozen and won't communicate with the camera.</p> <p>Solution:Check the camera to printer connection. Check that the printer power is turned on. See the printer instruction booklet for further details.</p>
Could not print.Try printing again?	<p>Problem:If the printer is in the middle of printing something, it may not be able to accept the next request.</p> <p>Solution:Restart the printer or wait until the current print run is finished and then try again.</p>
Could not print.	<p>Problem:The printer has rejected the print request.</p> <p>Solution:If neither of the above works, see the printer instruction booklet for further remedies.Restart the printer or resend the request from the camera. If none of these remedies work, contact your nearest Epson Customer Support.</p>
A communication error has occurred.	<p>Problem:Either the cable has been disconnected or the power has been turned off.</p> <p>Solution:Recheck that the cable is connected, turn the power back on and try again.</p>
xx images could not be printed.	<p>Problem:If some of the images were taken with another camera or have been changed by software, only the images taken with this camera will be printed.</p> <p>Solution:Use the actual camera or computer that was used to create the images in order to print them.</p>
Cannot print because the necessary Frame file does not exist or is corrupted.	<p>Problem:The picture can't be printed because there is no frame file or the link has been broken.</p> <p>Solution:Replace or add a frame linked to this file. (See page 49.)</p>
This function cannot be performed from the camera with the printer you are using.	<p>Problem:The printer does not support this function.</p> <p>Solution:You can try to clean it in some other way, but the printer doesn't support the camera's function.</p>
This printer is not supported.	<p>Problem:The printer isn't made for direct printing.</p> <p>Solution:Make sure the printer supports direct printing before you buy it.</p>
Parts inside your printer require maintenance.	<p>Problem:The printer cannot print because the components within the printer needs adjusting.</p> <p>Solution:Turn the printer off for a few seconds then turn the power back on. If the error message still appears, consult the shop you bought your printer from or the Epson Customer Support.</p>

EPSON INFORMATION

CONTACTING CUSTOMER SUPPORT

If your EPSON product is not operating properly and you cannot solve the problem using the troubleshooting information in your product documentation, contact customer support services for assistance. If customer support for your area is not listed below, contact the dealer where you purchased your product.

Customer support will be able to help you much more quickly if you give them the following information:

- Product serial number
(The serial number label is usually on the back of the product.)
- Product model
- Product software version
(Click About, Version Info, or similar button in the product software.)
- Brand and model of your computer
- Your computer operating system name and version
- Names and versions of the software applications you normally use with your product

For users in Hong Kong

To obtain technical support as well as other after-sales services, users are welcome to contact EPSON Hong Kong Limited.

Internet Home Page

EPSON Hong Kong has established a local home page in both Chinese and English on the Internet to provide users with the following information:

- Product information
- Answers to Frequently Asked Questions (FAQs)
- Latest versions of EPSON product drivers

Users can access our World Wide Web home page at:

Home Page: http://www.epson.com.hk
--

Electronic Bulletin Board System

An electronic bulletin board system (BBS) is also available to obtain product information and the latest versions of product drivers. You can log on to the following number for the BBS service:

BBS: (852) 2827-4244

Technical Support Hotline

You can also contact our technical staff at the following telephone and fax numbers:

Phone: (852) 2585-4399

Fax: (852) 2827-4383

EPSON OVERSEAS MARKETING LOCATIONS

EPSON America, Inc.

3840 Kilroy Airport Way
Long Beach, CA 90806
Phone: (562) 981-3840
Fax: (562) 290-5220

EPSON UK LTD.

Campus 100, Maylands Avenue,
Hemel Hempstead, Herts,
HP2 7TJ, U.K.
Phone: (+44) 01442 261144
Fax: (+44) 01442 227227

EPSON DEUTSCHLAND GmbH

Zülpicher Straße 6,
40549 Düsseldorf Germany
Phone: (0211) 56030
Fax: (0211) 5047787

EPSON FRANCE S.A.

68 bis, rue Marjolin
92300, Levallois-Perret, France
Phone: 33.1.41.86.26.56
Telex: 610657

EPSON AUSTRALIA PTY. LTD.

70 GIBBES STREET,
CHATSWOOD 2067 NSW.
Phone: 2-9903-9000
Fax: 2-9903-9177

EPSON SINGAPORE PTE. LTD.

No. 1 Temasek Avenue #36-00
Millenia Tower, Singapore 039192
Phone: (065) 633 77 911
Fax: (065) 633 41 185

EPSON HONG KONG LTD.

Rooms 4706-10, 47/F,
China Resources Bldg.,
26 Harbour Road, Wanchai, Hong Kong
Phone: 2585-4300
Fax: 2827-7083

EPSON TAIWAN TECHNOLOGY & TRADING LTD.

10F, No. 287 Nanking E. Road, Sec. 3,
Taipei, Taiwan,
Phone: (02) 2717-7360
Fax: (02) 2712-9164

EPSON ITALIA S.p.A.

V.le F.lli Casiraghi 427
20099 Sesto S.Giovanni
MI, Italy
Phone: +3902262331
Fax: +39022440750

EPSON IBERICA S.A.

Av. de Roma, 18-26
08290 Cerdanyola del Valles
Barcelona, Spain
Phone: 582. 15.00
Fax: 582. 15.55

**SEIKO EPSON CORPORATION
(Hirooka Office)**

80 Harashinden, Hirooka
Shiojiri-shi, Nagano-ken
399-0785 Japan

EPSON PORTUGAL, S.A.

R. do Progresso, 471, 1° Perafita
4460 Matosinhos, Portugal
Phone: (02) 996 14 02
Fax: (02) 996 14 11

2003 April

INDEX

A

AC adapter

- AC adapter (A211H) 13, 40, 91, 92
- AC adapter AC Cable 13, 40

Adjusting LCD Brightness 84

Auto Focus 50, 21-26

AV 13, 38

B

Batteries

- Accessing The Batteries 16
- Batteries Installation 16
- Battery / Memory Card Cover 16
- Battery Life Indicator 17
- Cleaning Battery Terminals 90
- Setting The Batteries 17

Blurred Shot 30

Buttons

- Display Button 42
- Flash Button 30
- Macro Button 50
- Menu Button 31, 43, 62
- Power Button 18
- Print Button 67-69, 71-74, 77
- Review Button 35
- Shutter Button 21-26, 62
- Zoom Button 27, 33, 35, 46, 64

C

Camera Range 21, 50

Cable

- AC Cable 13, 40
- AV Cable 13, 38
- PC Cable 13, 66
- Printer Cable 13, 38, 66

Changing The Frames 73

Color Temperatures 54

Compatible Printers 66

Compression 28, 29, 32, 51

- Fine Compression 28, 29, 51
- Normal Compression 28, 29, 51

Confirming The Number Of Photographs 29

Continuous Shooting 51

D

Date & Time 18, 83

Deleting

- Deleting All Images 36
- Deleting A Single Photo 37
- Deleting Frames 48
- Deleting Video Clip 64

Digital Zoom 27

Dial Switch

- Photo Mode 22-26, 28, 31, 35, 42-43, 45, 50-60
- Playback Mode 32-34, 36-37, 46, 61, 63-64, 67-69, 71-78, 80
- Setup Mode 23, 48-49, 81-88

Video Clip Mode 62

Direct Printing

- Direct Printing From Camera To Printer 39, 66
- Direct Printing Messages 100
- Head Cleaning 78
- High Speed Printing 76
- List Of Compatible Printers 66
- Printer Utilities 77, 78
- Print Images Framed (P.I.F.) Printing 70-73
- Printing All The Images In Memory 68
- Printing Selected Images 69
- Printing The Date 76
- Printing The Image Seen On The LCD Monitor 67
- Print Settings 74
- Selecting Print Borders 75
- Setting Paper Size 75
- Test Printing For Nozzle Check 78

Displaying On A Tv 38

Displaying Recorded Image Data 61

DPOF

- Digital Print Order Format (DPOF) 80
- DPOF Printing Options 81
- Saving Photos In DPOF 80

E

EV 58, 59

Exif 66

Exposure Adjustment 58, 59

F

Fine Compression 28, 29, 51

Fine Resolution 28, 29, 51

Flash

- Flash Control 30
- Flash Icons 30
- Flash Range 30

Focus Area 21, 50

Full Shutter 21

H

Half Shutter 21

Holding The Camera 20

I

If The Captured Image Is Out Of Focus 26

Illumination Light 31

Initial Settings 18

ISO 30, 56, 57

L

LANDSCAPE Mode 53

Language 18, 87

LCD Monitor

- LCD Monitor Off 42
- Printing The Image Seen On The LCD Monitor 67
- Taking Photos Using The LCD Monitor 22
- No Playback Image On The LCD Monitor 96

Light Sensitivity

- Automatic Sensitivity Mode 56

Setting Light Sensitivity Manually 57

List Of Compatible Printers 66

M

Macro Mode 50

Memory Card

Memory Card Formatting 85

Multimedia Card 16, 29

SD Memory card 12, 29, 63

SD Memory Card Installation 16

SD Memory Card Write-protection 85

Message Icon 80

N

Normal Compression 28, 29, 51

Normal Mode 52, 53, 91, 92

NTSC 18, 38, 87

O

Optical Zoom 27

P

PRINT Image Framer(P.I.F.)

Changing The Frames 73

Deleting Frames 48

PRINT Image Framer (P.I.F.) Printing 44, 70-73

PRINT Image Framer (P.I.F.) Shooting 45

Viewing A P.I.F. Image 46

PAL 18, 87

Parallax 25, 50

Photograph Quality Settings 28

Playback System

Displaying Multiple Images 33

Image Enlargement 33

MENU For Playback Mode 43

One By One Playback 32

PLAYING BACK A CLIP 63

Quick Photo Review 35

Slide Show 34

Power On/Off 18

PRINT Image Matching 66

Q

Quick Photo Review 35

Quick View 23

R

Resetting

Resetting Camera Defaults 88

Resetting File Numbers 86

Resetting The Auto Power Save 82

Resetting To Default Mode 60

Resetting Video Out 87

Resolution

Fine Resolution 28, 29, 51

Standard Resolution 28, 29, 51

Super Fine Resolution 28, 29, 51

Rules For Naming Files 86

S

SCENE Modes

Landscape Mode 53, 91, 92

Normal Mode 52, 53, 91, 92

Portrait Mode 53, 91, 92

Selecting A Scene Mode 52

Self Timer

Self Timer 31

Short Self Timer 31

Slow Shutter Speeds 30

Slow Syncro Shutter 30, 53

Slide Show 34

Sound

Shutter Sound Settings 81

Sound Settings 81

Speaker Volume 63

Specifications 91, 92

Shutter Button

Full Shutter 21

Half Shutter 21

Standard Resolution 28, 29, 51

Super Fine Resolution 28, 29, 51

T

Tables

Approximate Number Of Images 29

Compression 29

Continuous Image Recording Table 51

Flash Range 30

Resolution 28, 29

Shutter Sound Settings 81

Sound Settings 81

Video Clip Resolution 63

Taking Photos

Taking Photos In MACRO Mode 50

Taking Photos Using The Viewfinder 24

Taking Photos Using The LCD Monitor 22

Tv 38

U

Utilities

Head Cleaning 78

Printer Utilities 77

Test Printing For Nozzle Check 78

V

Video Clip

Deleting Video Clip 64

Playing Back A Clip 63

Recording A Video Clip 62

Selecting Video Clip Resolution 62

Video icon 33

Viewfinder 24, 25

W

White Balance

Automatic White Balance 54

Selecting White Balance Manually 55

Z

Zoom 27

EPSON

User's Guide

L-300/200