














User's Guide

– for use without a computer –

	Introduction	
	Important Safety Instructions	1
	Copyright Notice.....	2
	Control Panel Information.....	2
	Guide to Parts and Control Panel Functions	
	Parts	3
	Control Panel Functions	4
	Handling Paper	
	Selecting Paper	6
	Loading Paper.....	6
	Copying	
	Placing Originals on the Document Table	8
	Copying Documents	8
	Copying Photos.....	10
	Printing from a Memory Card	
	Handling a Memory Card	12
	Printing Photos	14
	Selecting and Printing Photos Using an Index Sheet.....	16
	Printing from a Digital Camera	
	Digital Camera Requirements	18
	Connecting and Printing.....	18
	Maintenance	
	Replacing Ink Cartridges.....	19
	Checking and Cleaning the Print Head	22
	Aligning the Print Head.....	23
	Cleaning This Product	24
	Transporting This Product.....	24
	Solving Problems	
	Error Messages.....	25
	Problems and Solutions	27
	Contacting Customer Support	29
	Panel Icon List	30

Where to Find Information

Paper manuals	
	<p>Start Here</p> <p>Be sure to read this sheet first. This sheet tells you how to set up the product and install the software. It also includes instructions on loading paper and placing originals.</p>
<p>(this book)</p> 	<p>User's Guide -for use without a computer-</p> <p>This book contains information on how to use the product without connecting your computer, such as instructions on copying and printing from a memory card.</p> <p>If you have problems using the product, see the Solving Problems chapter in this book.</p>
Online manuals	
	<p>User's Guide</p> <p>This guide provides instructions for printing and scanning from your computer and information on the software.</p> <p>This guide is included on the software CD-ROM and installed automatically when you installed the software. To read this guide, double-click the icon on your desktop.</p>
	<p>Online help</p> <p>Online help is built in each application included on the software CD-ROM. It provides detailed information on the application.</p>

Introduction

Important Safety Instructions

Before using this product, read and follow these safety instructions:

- Use only the power cord that comes with the product. Use of another cord may cause fire or shock. Do not use the cord with any other equipment.
- Make sure the power cord meets all relevant local safety standards.
- Use only the type of power source indicated on the label.
- Place the product near a wall outlet where the power cord can be easily unplugged.
- Do not let the power cord become damaged or frayed.
- If you use an extension cord with the product, make sure the total ampere rating of the devices plugged into the extension cord does not exceed the cord's ampere rating. Also, make sure the total ampere rating of all devices plugged into the wall outlet does not exceed the wall outlet's ampere rating.
- Avoid locations that are subject to rapid changes in heat or humidity, shocks or vibrations, or dust.
- Leave enough room around the product for sufficient ventilation. Do not block or cover openings in the case or insert objects through the slots.
- Do not place the product near a radiator or heating vent or in direct sunlight.
- Place the product on a flat, stable surface that extends beyond its base in all directions. It will not operate properly if it is tilted or at an angle.
- Make sure the back of the product is at least 10 cm away from the wall.
- Do not open the scanner unit while copying, printing, or scanning.
- Do not spill liquid on the product.
- Do not use aerosol products that contain flammable gases inside or around the product. Doing so may cause fire.
- Except as specifically explained in your documentation, do not attempt to service the product yourself.
- Unplug the product and refer servicing to qualified service personnel under the following conditions: if the power cord or plug is damaged; if liquid has entered the product; if the product has been dropped or the case damaged; if the product does not operate normally or exhibits a distinct change in performance. Adjust only those controls that are covered by the operating instructions.
- When storing or transporting the product, do not tilt it, stand it on its side, or turn it upside down; otherwise ink may leak from the cartridges.
- Be careful not to trap your fingers when closing the scanner unit.

Ink cartridge safety instructions

- Keep ink cartridges out of the reach of children and do not drink the ink.
- Be careful when you handle used ink cartridges; there may be ink remaining around the ink supply port. If ink gets on your skin, wash it off with soap and water. If it gets in your eyes, flush them immediately with water. If you still have discomfort or vision problems, see a doctor immediately.
- Do not put your hand inside the product or touch any cartridges during printing.
- Install a new ink cartridge immediately after you remove an expended cartridge. Leaving cartridges uninstalled can dehydrate the print head and may prevent the product from printing.
- If you remove an ink cartridge for later use, protect the ink supply area from dirt and dust and store it in the same environment as the product. Note that there is a valve in the ink supply port, making covers or plugs unnecessary, but care is needed to prevent the ink from staining items that the cartridge touches. Do not touch the ink cartridge, ink supply port, or surrounding area.

Warnings, Cautions, and Notes

Follow these guidelines as you read your instructions:

Warning:

Warnings must be followed carefully to avoid bodily injury.

Caution:

Cautions must be observed to avoid damage to your equipment.

Note:

Notes contain important information about the product.

Tip:

Tips contain hints for using the product.

Copyright Notice

No part of this publication may be reproduced, stored in a retrieval system, or transmitted in any form or by any means, electronic, mechanical, photocopying, recording, or otherwise, without the prior written permission of Seiko Epson Corporation. The information contained herein is designed only for use with this product. Epson is not responsible for any use of this information as applied to other printers.

Neither Seiko Epson Corporation nor its affiliates shall be liable to the purchaser of this product or third parties for damages, losses, costs, or expenses incurred by the purchaser or third parties as a result of accident, misuse, or abuse of this product or unauthorized modifications, repairs, or alterations to this product, or (excluding the U.S.) failure to strictly comply with Seiko Epson Corporation's operating and maintenance instructions.

Seiko Epson Corporation shall not be liable for any damages or problems arising from the use of any options or any consumable products other than those designated as Original Epson Products or Epson Approved Products by Seiko Epson Corporation.

Seiko Epson Corporation shall not be held liable for any damage resulting from electromagnetic interference that occurs from the use of any interface cables other than those designated as Epson Approved Products by Seiko Epson Corporation.

EPSON® is a registered trademark and EPSON STYLUS™ and Exceed Your Vision are trademarks of Seiko Epson Corporation.

USB DIRECT-PRINT™ and the USB DIRECT-PRINT logo are trademarks of Seiko Epson Corporation. Copyright © 2002 Seiko Epson Corporation. All rights reserved.

DPOF™ is a trademark of CANON INC., Eastman Kodak Company, Fuji Photo Film Co., Ltd. and Matsushita Electric Industrial Co., Ltd.

SDHC™ is a trademark.

Memory Stick, Memory Stick Duo, Memory Stick PRO, Memory Stick PRO Duo, MagicGate Memory Stick and MagicGate Memory Stick Duo are trademarks of Sony Corporation.

xD-Picture Card™ is a trademark of Fuji Photo Film Co., Ltd.

General Notice: Other product names used herein are for identification purposes only and may be trademarks of their respective owners. Epson disclaims any and all rights in those marks.

Copyright © 2006 Seiko Epson Corporation. All rights reserved.

Control Panel Information

Some displays on the control panel and LCD screen vary depending on the area you purchased the product.

Control panel

Icon panel




Text panel



LCD display

Icon display



Icons only are displayed.


Text display



A text message or text with icons is displayed.



Guide to Parts and Control Panel Functions

Parts



Control Panel Functions

Buttons




	Button	Function	
1	Copy	Press to select the copy mode.	
		100%	Select this option to print your photo at the actual size.
		[Fit to Page]	Select this option to reduce or enlarge the copied photo to fit the selected paper size.
2	4-way scroll	◀ ▶	Press to select the photo you want to print, to select color or black-and-white copy, or to select the setup and utility functions.
		▲ ▼	Press to select the number of copies or to select the numbers when using the Head Alignment Utility.
3	[Setup/Utilities]	Press to run maintenance programs or adjust miscellaneous settings.	
4	Paper Type	Press to select the paper type you loaded in the sheet feeder.	
		[Photo Paper]	Premium Glossy Photo Paper, Premium Semigloss Photo Paper, Glossy Photo Paper, Ultra Glossy Photo Paper
		[Matte Paper]	Matte Paper - Heavyweight
	[Plain Paper]	Plain paper, Bright White Ink Jet Paper, Premium Ink Jet Plain Paper	
5	On	Press to turn the product on and off.	
6	Memory Card	Press to select a memory card print option.	
		[Select Photo]	Select this option to choose the photos you want to print.
		[Print All / PictBridge]	Select this option to print all the photos on a memory card, to print photos using the DPOF information stored on the memory card, or to print photos directly from a digital camera.
		[Print Index Sheet]	Select this option to print an index sheet of the photos on your memory card.
	[Print from Index Sheet]	Select this option to print the photos you selected on the index sheet.	
7	Photo	Press to copy from photos. You can copy them as they are or with color restoration.	
8	Paper Size	Press to select the size of the paper loaded in the sheet feeder. You can select 10 × 15/4" × 6", 13 × 18/5" × 7" or A4.	
9	Stop/Clear	Press to stop printing, copying, or reset the settings you have made. The sheet being printed is ejected and the number of copies is reset.	
10	Start	Press to start printing, copying, or confirm the settings you have selected.	


LCD Screen

The screen displays a preview of the selected photos, or displays settings that you can change with the buttons.

Icon display



Text display



Low power mode


If the product is inactive for 13 minutes, the LCD screen turns black and all lights, except the On light, go out to save energy.

Press any button (except **On**) to return the screen to its previous state.

Changing LCD contrast

If you want to change LCD contrast, follow these steps.

1. Press the **Setup/Utilities** button to enter the setup mode. Use the **Left** or **Right** button to select **Photo Viewer Adjustment**.



2. Press the **Start** button.
3. Use the **Up** or **Down** button to select the LCD contrast. You can choose from -2 to +2.



darker


brighter

4. Press the **Start** button again to confirm your selection.
5. Press the **Setup/Utilities** button to return to the previous mode.

Changing LCD display for text display users only

There are two types of LCD display settings. Follow these steps to change your display setting.

1. Press the **Setup/Utilities** button to enter the setup mode. Use the **Left** or **Right** button to select **Display**.



2. Press the **Start** button.
3. Use the **Up** or **Down** button to select the options.

Settings	Description
	<p>Pictographic: (Icon display)</p> <p>Icons only are displayed on the LCD screen.</p>
	<p>English: (Text display)</p> <p>Icons and text are displayed on the LCD screen.</p>

4. Press the **Start** button to confirm your selection.
5. Press the **Setup/Utilities** button to return to the previous mode.

Handling Paper

Epson offers an extensive line of special papers that provide outstanding results when used with Epson printers and ink. The type of paper you choose affects the way your printout looks, so be sure to select the correct paper for your job.

Selecting Paper

If you are just making a copy or printing a rough draft of an image, plain paper is fine. However, for the best results, you will want to use one of Epson's special ink jet papers designed for the product.

Before printing, you need to select the correct Paper Type setting on the control panel. This important setting determines how the ink is applied to the paper.

Choose from these paper types and settings:

Paper Type	Size	Paper Type Setting	Loading Capacity
Plain paper*	A4	Plain paper	12 mm
Bright White Ink Jet Paper	A4	Plain paper	80 sheets
Premium Ink Jet Plain Paper	A4	Plain paper	100 sheets
Premium Glossy Photo Paper	10 × 15 cm (4 × 6 in.), 13 × 18 cm (5 × 7 in.), A4	Photo paper	20 sheets
Premium Semigloss Photo Paper	10 × 15 cm (4 × 6 in.), A4	Photo paper	20 sheets
Glossy Photo Paper	10 × 15 cm (4 × 6 in.), 13 × 18 cm (5 × 7 in.), A4	Photo paper	20 sheets
Ultra Glossy Photo Paper	10 × 15 cm (4 × 6 in.), 13 × 18 cm (5 × 7 in.), A4	Photo paper	20 sheets
Matte Paper -Heavyweight	A4	Matte Paper	20 sheets


* You can use paper with a weight of 64 to 90 g/m².

Note:


The availability of special media varies by location.

Loading Paper


1. Open and extend the paper support.







2. Open the output tray and slide out the extensions.






3. Flip the feeder guard forward.




4. Set the paper as shown in the following illustrations.




5. Flip the feeder guard back.






10 × 15 cm (4 × 6 in.) and 13 × 18 cm (5 × 7 in.)



A4

Also make sure the paper thickness lever is set down to the  position.



The LCD screen indicates that the lever has been moved and the  or  position has been changed.


Note:

Make sure you do not load more than the recommended number of sheets. Check the **Paper Type** setting before printing to make sure it matches the type of paper you have loaded (➔ "Selecting Paper" on page 6).

Copying



You can copy documents and photos without a computer.

Note the following when copying:

- The copied image may not be exactly the same size as the original.
- Depending on the type of paper used, print quality may decline in the top and bottom areas of the printout, or these areas may be smeared.
- If you see a low ink  icon while you are copying, you can either continue copying until the ink is expended, or stop and replace the cartridge.
- Keep the document table clean.
- Make sure the document or photo is flat against the document table; otherwise, the copy will be out of focus.
- Do not pull out paper that is being printed; it will be ejected automatically.

Placing Originals on the Document Table

1. Open the document cover and place your original face-down on the document table, in the upper left corner.




2. Close the cover gently so you do not move the original.

Caution:

Never open the document cover beyond where it stops and do not place heavy objects on top of the product.

If you need to copy a thick or large document, you can remove the document cover. Just open it and pull it straight up.



If you need to press the document flat while you copy it, do not press too hard and be careful not to move it.

When you are done, replace the document cover by inserting the tabs back into the slots.


Copying Documents




Tip:

Plain photocopier paper works well for making everyday copies. For crisper text and more vivid colors, try one of the special Epson papers (➔ “Selecting Paper” on page 6).

1. Load A4 plain paper (➔ page 6).
2. Place your original on the document table (➔ “Placing Originals on the Document Table” on page 8).
3. Make the following settings on the control panel.



- 1 Press the **Copy** button.
- 2 Use the **▲** or **▼** button to select the number of copies (1 to 99).




Use the **◀** or **▶** button to select color copy or black-and-white copy.

Display	Color Copy	Black-and-White Copy
Icon		
Text		

- 3 Select **[Plain Paper]**.
- 4 Select **A4**.

Tip:

If you want to automatically resize the copy to the size of paper that you loaded, press the **Copy** button until the icon shown below is displayed on the LCD screen.



- 5 Press the **Start** button. Your document is copied.

If you need to stop copying, press the **Stop/Clear** button.

Note:

If the edges of the copy are cropped off, move the original away from the corner slightly.

Selecting copy quality

If you want to make a copy quickly and do not need high quality, you can print a “Draft” copy. Alternatively, if you want to print high quality photos, you can print a “Photo” copy.

1. Press the **[Setup/Utilities]** button to enter the setup mode. Use the **◀** or **▶** button to select **Copy Quality**.



2. Press the **Start** button.
3. Use the **▲** or **▼** button to select **Normal**, **Draft**, or **Photo**.

Setting		Description
Icon display	Text display	
		Normal: This is automatically selected when you turn the product on. This mode is the best for text copy.
		Draft: Select this if you want to make a quick copy and quality is not important.
		Photo: Select this if you want to print high quality photos.































4. Press the **Start** button again to confirm your selection.




Press the **[Setup/Utilities]** button to return to the previous mode.





Restoring color in photos

If you have photos that have faded over time, you can bring them back to life with color restoration when you reprint them.

1. Load photo paper (➔ page 6).
2. Place your original on the document table making sure that it is aligned correctly (➔ “Placing Originals on the Document Table” on page 8).

You can place more than two photos on the document table at one time (➔      ).
                       .

3. Press the  **Photo** button.
4. Use the  or  button to set the color restoration mode to on or off.






Display	Color Restoration	
	On	Off
Icon		
Text		


5. Press the  **Start** button. The photo is scanned, and a preview is displayed on the LCD screen.

Note:

When color restoration is on, the icon shown below is displayed at the top of the LCD screen.




6. Use the  or  button to view the photos. Use the  or  button to set the number of copies (1 to 99).
7. Select the paper type you loaded.
8. Select the paper size you loaded.
9. Press the  **Start** button again. Your photo is copied.

If you need to stop copying, press the  **Stop/Clear** button.

Copying multiple photos

Place each photo vertically as shown in the illustration below.



- You can copy two 10 × 15 cm (4 × 6 in.) size photos at a time. If the edge of the photo is missing after you print, try copying them one at a time.
- Place your photo 5 mm away from the edge of the document table. Also when you place two photos, position each photo at least 5 mm away from the adjacent photo.
- You can copy several different sized photos at the same time, as long as they are larger than 30 × 40 mm and all fit inside the 216 × 297 mm area.

Printing from a Memory Card

You can print photos directly from your digital camera's memory card. Just insert it into the memory card slot and you are ready to print.

Handling a Memory Card


Compatible cards

Make sure your memory card meets the following requirements.



Card type	CompactFlash, Microdrive, SD Memory Card, SDHC Memory Card, MultiMediaCard, miniSD card, miniSDHC card, microSD card, microSDHC card, Memory Stick, Memory Stick PRO, Magic Gate Memory Stick, Magic Gate Memory Stick Duo, Memory Stick Duo, Memory Stick PRO Duo, xD-Picture Card, xD-Picture Card Type M, xD-Picture Card Type H
Media format	DCF (Design rule for Camera File system) version 1.0 or 2.0 compliant All card types standard version compliant.
File format	JPEG with the Exif Version 2.21 standard
Image size	80 × 80 pixels to 9200 × 9200 pixels
Number of files	Up to 999

Inserting a memory card



1. Turn off your computer or disconnect it from the product.
2. Make sure the product is turned on.
3. Open the memory card slot cover.




4. Make sure the memory card light is off and no memory cards are in the slots. Then insert your memory card.



CompactFlash
Microdrive




xD-Picture Card
xD-Picture Card Type M
xD-Picture Card Type H



Caution:

Make sure you check which direction the card should be inserted, and if the card needs an adapter make sure you attach the adapter before inserting the card. Otherwise, you may not be able to remove the card from the product.

5. Make sure the memory card light flashes and then stays on.
6. Close the memory card slot cover.



Caution:

- Do not insert more than one memory card at a time.
- Do not try to force the memory card into the slot. Memory cards will not go all the way in. Forcing a memory card into the slot may damage the product, the memory card, or both.
- Keep the memory card slot cover closed while a memory card is inserted. This protects the memory card and the slot from dust and static; otherwise data on the memory card may be lost, or the product may be damaged.
- The static charge on memory cards may cause malfunction.

Note:

- You can print only in color from a memory card; you cannot print in black and white.
- If a digital camera is connected to the product, disconnect it before you insert your memory card.


Removing the memory card

1. Make sure all print jobs are finished.
2. Open the memory card slot cover.
3. Make sure the memory card light is not flashing.
4. Remove the memory card by pulling it straight out of its slot.
5. Close the memory card slot cover.

Caution:

- Do not remove the memory card or turn off the product while the memory card light is flashing, or you may lose data on the memory card.
- If your computer uses Windows 2000 or XP, never turn off the product or disconnect the USB cable when a memory card is inserted; you may lose data on the memory card. See your online *User's Guide* for details.

Printing Photos




After inserting a memory card you can:

Setting		Description
Icon panel	Text panel	
	Select Photo	Prints only the photos that you choose.
	Print All/ PictBridge	Prints all the photos on your card, or prints the photos with DPOF information.
	Print Index Sheet	Prints an index sheet of the photos on your card.
	Print from Index Sheet	Prints the photos you selected on the index sheet.

Printing selected photos

Follow the steps below to select the photos you want to print from your memory card.

1. Load the type of paper you want to use (➔ page 6). Load enough sheets for the number of photos you want to print.
2. Insert a memory card (➔ page 12).
3. Press the **Memory Card** button until the [Select Photo] light turns on.



Note:

If your camera supports DPOF, you can use it to select the photos you want to print and the number of copies (➔ "Printing all photos or DPOF photos" on page 14).

Depending on the data on your card, you see a screen like this:



4. Use the ◀ or ▶ button to select a photo. Use the ▲ or ▼ button to set the number of copies.
5. Select the paper type you loaded.

If you select [Plain Paper], the photos are printed with a white border. If you select [Photo Paper] or [Matte Paper], the photos are printed without borders to the edge of the paper.


6. Select the paper size you loaded.
7. Press the **Start** button. Your photos are printed.



If you need to cancel printing, press the **Stop/Clear** button.

Printing all photos or DPOF photos

Follow the steps below to print one copy of each photo on the card or to print only those photos that were pre-selected with your camera's DPOF feature.

1. Load the type of paper you want to use (➔ page 6). Load enough sheets for the number of photos you want to print.
2. Insert a memory card (➔ page 12).
3. Press the **Memory Card** button until the [Print All/PictBridge] light turns on.



If your memory card contains DPOF information, one of the following screens is displayed. You cannot print all of the photos on the card, even when /  [**Print All/PictBridge**] is selected. To print all the photos on the memory card, cancel the DPOF information from your digital camera.




Icon display





Text display



4. Select the paper type you loaded.




If you select  [**Plain Paper**], the photos are printed with a white border. If you select  [**Photo Paper**] or  [**Matte Paper**], the photos are printed without borders to the edge of the paper.


5. Select the paper size you loaded.
6. Press the  **Start** button. Your photos are printed.






If you need to cancel printing, press the  **Stop/Clear** button.

Printing the date on photos

Follow the steps below to print the date they were taken.

1. Press the  [**Setup/Utilities**] button.
2. Use the  or  button to select **Date Stamp**.




3. Press the  **Start** button.
4. Use the  or  button to select the format you want to use. The date format options are **No Date** (no date), **yyyy.mm.dd** (2006.06.16), **mmm.dd.yyyy** (Jun.16.2006), or **dd.mmm.yyyy** (16.Jun.2006).
5. Press the  **Start** button to confirm your selection.
6. Press the  [**Setup/Utilities**] button to return to the previous mode.


Selecting and Printing Photos Using an Index Sheet

To select photos for printing, you can use an index sheet. First, print an index sheet which has small images of all the photos on your memory card. Then, mark the photos on the index sheet that you want to print, scan the sheet, and the selected photos will be printed automatically.


Printing an index sheet




Selecting photos from the index sheet



Scanning the index sheet



Printing the selected photos



1. Printing an index sheet

1. Load several sheets of A4-size plain paper (➔ page 6).


Up to 30 images are printed on each page, so if there are more than 30 photos on your memory card, you will need enough sheets for all the index pages to be printed.

2. Insert a memory card (➔ page 12).
3. Press the **Memory Card** button until the **[Print Index Sheet]** light turns on.

Icon panel



Text panel



One of the following screens is displayed.

Icon display



Text display



4. Make sure **[Plain Paper]** and **A4** are selected.
5. Press the **Start** button. The index sheet is printed.

If you need to cancel printing, press the **Stop/Clear** button.

Note:

- Make sure the triangle mark on the upper left corner of the index sheet is printed properly. If the index sheet is not printed correctly, the product cannot scan it.
- If there are a lot of photos on your memory card, this may take a few minutes.
- For multiple index sheets, the pages are printed from the last sheet to the first, so the most recent images are printed first.

2. Selecting photos from the index sheet

On the index sheet, use a dark pen or pencil to fill in the circles and make your selections.


Good: ●

NOT good: ⊕ ⊖ ☹


Select **All** to print one copy of each photo, or fill in the number beneath each photo to select 1, 2, or 3 copies.

3. Scanning the index sheet and printing the selected photos

1. Place the index sheet face-down on the document table, in the upper left corner, so that the top of the sheet is aligned against the left edge of the document table.



2. Close the document cover.
3. Load the type of paper you want to use (➔ page 6). Load enough sheets for the number of photos you want to print.
4. Make sure the [Print from Index Sheet] light is on.



One of the following screens is displayed.

Icon display



Text display



5. Select the paper type you loaded.

If you select [Plain Paper], the photos are printed with a white border. If you select [Photo Paper] or [Matte Paper], the photos are printed without borders to the edge of the paper.

6. Select the paper size you loaded.
7. Press the **Start** button. Your photos are printed.

If you want to stop printing, press the **Stop/Clear** button.

Note:

If you have more than one index sheet, wait each time until printing is complete. Then repeat the steps above to scan and print from each additional sheet.

Printing from a Digital Camera

You can print your photos by connecting your digital camera directly to this product.


Digital Camera Requirements

Make sure your camera and photos meet the following requirements.

Direct printing compatibility	PictBridge or USB DIRECT-PRINT
File format	JPEG
Image size	80 × 80 pixels to 9200 × 9200 pixels

Connecting and Printing

1. Make sure the product is not printing from a computer.
2. Load the type of paper you want to use (➔ page 6). Load enough sheets for the number of photos you want to print.
3. Select the paper type you loaded.
If you select [Plain Paper], the photos are printed with a white border. If you select [Photo Paper] or [Matte Paper], the photos are printed without borders to the edge of the paper.
4. Select the paper size you loaded.
5. Connect the USB cable that came with your camera to the external interface USB port of the product.



6. Make sure your camera is turned on. The [Print All/PictBridge] light turns on, and one of the following screens is displayed.


Display	PictBridge	USB DIRECT-PRINT
Icon		
Text		

7. Use your camera to select the photos you want to print, adjust any necessary settings, and print your photos. See your camera's manual for details.


Note:

- ❑ If your camera is not compatible with PictBridge or USB DIRECT-PRINT, one of the following screens is displayed. Epson cannot guarantee the compatibility of any cameras.

Icon display



Text display



- ❑ Depending on the settings on the product and the digital camera, some combinations of paper type, size, and layout may not be supported.
- ❑ Some of the settings on your digital camera may not be reflected in the output.

Maintenance

You can keep the operation of the product at its best by performing the procedures described in this chapter. Also, this section includes instructions on how to replace ink cartridges and transport the product.

Replacing Ink Cartridges

When an ink cartridge is low, the icon shown below is displayed in the upper-left corner of the LCD screen.

Icon display




Text display



When printing or copying, a bar showing which ink cartridge is low is displayed next to the Ink Low icon.


Icon display



Text display



When an ink cartridge is expended, the following LCD screen is displayed.



Tip:

If a cartridge is more than six months old, print quality may decline. If necessary, try cleaning the print head (➔ “Checking the print head” on page 22). If printouts still do not look their best, you may need to replace the cartridge.

Checking the ink cartridge status

Follow these steps to check your ink cartridge status.


1. Press the **[Setup/Utilities]** button.

2. Use the **◀** or **▶** button to select **Check Ink Levels**.



3. Press the **Start** button.

You see a graphic showing the ink cartridge status.



4. When you are done checking the ink cartridge status, press the **Start** button.
5. Press the **[Setup/Utilities]** button to return to the previous mode.

When your ink starts getting low, make sure you have replacement cartridges available. You cannot print if a cartridge is expended.

Note:

Epson cannot guarantee the quality or reliability of non-genuine ink. If non-genuine ink cartridges are installed, the ink status will not be displayed.

Purchasing ink cartridges

Use the Epson ink cartridges within six months of installing them and before the expiration date.

Color	Part Number	
	DX6000 series	CX5900 series
Black	T0711	T0731
Cyan	T0712	T0732
Magenta	T0713	T0733
Yellow	T0714	T0734

Caution:

Epson recommends the use of genuine Epson ink cartridges. The use of non-genuine ink may cause damage that is not covered by Epson's warranties, and under certain circumstances, may cause erratic printer behavior. Epson cannot guarantee the quality or reliability of non-genuine ink. Information about the ink cartridge status is not displayed when non-genuine ink is used.

Ink cartridge precautions

Warning:

If ink gets on your hands, wash them thoroughly with soap and water. If ink gets in your eyes, flush them immediately with water. If you still have discomfort or vision problems, see a doctor immediately.

- To avoid damaging the product, never move the print head by hand.
- When an ink cartridge is expended, you cannot continue copying or printing even if the other cartridges still contain ink.
- Leave the expended cartridge installed until you have obtained a replacement. Otherwise the ink remaining in the print head nozzles may dry out.
- An IC chip on each ink cartridge monitors the amount of ink used from the cartridge. Cartridges are usable even if they are removed and reinserted. However, some ink is consumed each time cartridges are inserted because the printer automatically checks their reliability.
- For maximum ink efficiency, only remove an ink cartridge when you are ready to replace it. Ink cartridges with low ink status cannot be used when reinserted.

Removing and installing ink cartridges

Make sure you have a new ink cartridge before you begin. Once you start replacing a cartridge, you must complete all the steps in one session.


Note:

Do not open the ink cartridge package until you are ready to install it in the printer. The cartridge is vacuum packed to maintain its reliability.

1. Do one of the following:


■ If an ink cartridge is expended:

Look at the LCD screen to find out which cartridge should be replaced, then press the **Start** button.



■ If an ink cartridge is not expended:


Check the ink cartridge status (→). Press the **[Setup/Utilities]** button. Use the **◀** or **▶** button to select **Change Cartridges**. Then press the **Start** button.



2. Press the **Start** button again, and then lift up the scanner unit.

Caution:

Do not lift up the scanner unit when the document cover is open.




One of the following screens is displayed.


Icon display



Text display




3. Open the cartridge cover.



Caution:


- ❑ Never attempt to open the cartridge cover when the print head is moving. Wait until the cartridges have moved to the replacement position.
- ❑ Be careful not to touch the parts highlighted below.



- Remove the cartridge you need to replace. Squeeze the tab at the back of the cartridge, lift it straight up and out of the product. Dispose of it carefully.

Note:


If it is difficult to remove the cartridge, lift the cartridge with more force until it comes out.



Caution:


Do not refill the ink cartridge. Other products not manufactured by Epson may cause damage that is not covered by Epson's warranties, and under certain circumstances, may cause erratic printer behavior.

- Before you open the new ink cartridge package, shake it four or five times. Then remove it from the package.




Caution:

Do not touch the green chip on the side of the cartridge. This can damage the ink cartridge.




- Remove the yellow tape from the bottom of the ink cartridge.




Caution:


- You must remove the yellow tape from the cartridge before installing it; otherwise, print quality may decline or you may not be able to print.
- If you have installed an ink cartridge without removing the yellow tape, take the cartridge out of the product remove the yellow tape, and then reinstall it.
- Do not remove the transparent seal from the bottom of the cartridge; otherwise, the cartridge may become unusable.



- Do not remove or tear the label on the cartridge; otherwise, ink will leak.



- Place the ink cartridge into the cartridge holder with the bottom down. Then push down the ink cartridge until it clicks into place.




- Replace any other ink cartridges that need to be replaced.


- Close the ink cartridge cover and press it until it clicks into place.

Caution:


If you find it difficult to close the cover, make sure all the cartridges are firmly seated. Press down on each cartridge until you hear it click into place. Do not attempt to force the cover closed.



- Close the scanner unit.



- Press the **Start** button.




When the product begins charging, one of the following LCD screens is displayed.

Icon display



Text display



This takes about one minute. When the ink charging finishes, it automatically returns to the Copy mode.

Caution:

Do not turn off the product during ink charging as this will waste ink.

Note:

If you had to replace the ink cartridge during copying, the documents or photos on the document table may have moved slightly when you opened and closed the scanner unit. To ensure copy quality, after ink charging is finished, cancel the job that is copying and start again from placing the originals.

Checking and Cleaning the Print Head

If your printouts are unexpectedly light, colors are missing, or you see light or dark lines across the page, you may need to clean the print head. This clears the print head nozzles, which can become clogged if you do not use the product for a long time.

Tip:

We recommend that you turn on the product at least once a month to maintain good print quality.

Checking the print head

You can print a nozzle check pattern to see if any print head nozzles are clogged, or to check the results after cleaning the print head.

- Load A4-size plain paper in the sheet feeder (➔ page 6).
- Press the **[Setup/Utilities]** button.
- Use the **◀** or **▶** button to select **Check Ink Nozzles**, and then press the **Start** button to print the nozzle check pattern.



- Examine the nozzle check pattern you printed. Each staggered line should be solid, with no gaps, as shown.



- If your printout looks okay, the print head does not need to be cleaned yet. Press the **[Setup/Utilities]** button to return to the previous mode.
- If you see any gaps, as shown below, clean the print head as described in the next section.



Cleaning the print head

Follow these steps to clean the print head so it can deliver ink properly. Before cleaning the print head, run a nozzle check to see if the print head needs cleaning (➔ “Checking the print head” on page 22).

Note:

- ❑ Print head cleaning uses ink, so clean it only if quality declines.
 - ❑ If a message on the LCD screen tells you that a cartridge is expended or low on ink, you cannot clean the print head. You must first replace the ink cartridge indicated (➔ “Replacing Ink Cartridges” on page 19).
1. Make sure the product is turned on but not printing.
 2. Press the **⌂ [Setup/Utilities]** button.
 3. Use the **◀** or **▶** button to select **Clean Print Head**, and then press the **⬢ Start** button to start cleaning.




During cleaning, one of the following screens is displayed.

Icon display



Text display



Caution:

Never turn off the product while head cleaning is in progress. You may damage it.

4. When cleaning finishes, print a nozzle check pattern to check the results (➔ “Checking the print head” on page 22).

If there are still gaps or the test patterns are faint, run another cleaning cycle and check the nozzles again.

Note:


If you do not see any improvement after cleaning about four times, turn off the product and wait for at least 6 hours. This lets any dried ink soften. Then try cleaning the print head again. If quality still does not improve, one of the ink cartridges may be old or damaged and needs to be replaced (➔ “Replacing Ink Cartridges” on page 19).

Aligning the Print Head

If you notice that vertical lines are not aligned properly on the nozzle check printout, you may be able to solve this problem by aligning the print head.

You can align the print head by pressing the buttons, or you can run the Print Head Alignment utility from your computer. For the most accurate alignment, the utility is recommended.

1. Load A4-size plain paper (➔ page 6).
2. Press the **⌂ [Setup/Utilities]** button.
3. Use the **◀** or **▶** button to select **Align Print Head**, and then press the **⬢ Start** button to print the alignment sheet.



Note:

Do not press the **⊞ Stop/Clear** button while printing an alignment pattern.

4. Look at pattern #1 and find the patch that is most evenly printed, with no noticeable streaks or lines.
5. Press the **▲** or **▼** button until the number for that patch is displayed on the LCD screen.




6. Press the **⬢ Start** button.
7. Repeat steps 4 to 6 for each of the other alignment patterns.
8. Press the **⌂ [Setup/Utilities]** button to return to the previous mode.

Cleaning This Product

To keep the operation of the product at its best, clean it periodically using the following procedure.

1. Unplug the power cord.
2. Remove all paper from the sheet feeder.
3. Use a soft brush to carefully clean away all dust and dirt from the sheet feeder.
4. If the glass surface of the document table gets dirty, clean it with a soft, dry, clean cloth. If the glass surface is stained with grease or some other hard-to-remove material, use a small amount of glass cleaner and a soft cloth to remove it. Wipe off all remaining liquid.
5. If the inside of the product accidentally gets soiled with ink, use a soft, dry, clean cloth to wipe the ink off the area indicated in the illustration.



Warning:

Be careful not to touch the gears or rollers inside the product.

Caution:

- ❑ Do not press the glass surface of the document table with any force.
- ❑ Be careful not to scratch or damage the glass surface of the document table, and do not use a hard or abrasive brush to clean it. A damaged glass surface can decrease the copy quality.
- ❑ Do not apply grease to the metal parts under the print head carriage.
- ❑ Never use alcohol or thinner to clean the product. These chemicals can damage the components as well as the case.
- ❑ Be careful to keep water away from the printing and copying mechanisms and electronic components.
- ❑ Do not spray the inside of the product with lubricants. Unsuitable oils can damage the mechanism. Contact your dealer or a qualified service person if lubrication is needed.


Transporting This Product

If you need to move the product some distance, you need to prepare it for transportation in its original box or one of a similar size.


Caution:

- ❑ When storing or transporting the product, avoid tilting it, placing it vertically, or turning it upside down; otherwise ink may leak from the cartridges.
- ❑ Leave the ink cartridges installed; removing the cartridges for transportation may damage the product.

1. Remove all paper from the sheet feeder and make sure the product is off.
2. Open the scanner unit and make sure the print head is in the home position on the right.
3. Secure the ink cartridge holder to the case with tape as shown.



4. Close the scanner unit.
5. Unplug the power cord from the outlet, then disconnect the USB cable from your computer.
6. Close the paper support, the feeder guard, and the output tray.



7. Repack the product in the box, using the protective materials that came with it.

Keep the product level as you transport it. After you move it, remove the tape securing the print head. If you notice a decline in print quality, run a cleaning cycle (➔ "Checking and Cleaning the Print Head" on page 22) or align the print head (➔ "Aligning the Print Head" on page 23).















Solving Problems





















If you have a problem with the product, check the messages on the LCD screen to diagnose what may be causing the problem.

You can also check “Problems and Solutions” on page 27 for troubleshooting suggestions on using the product without a computer. See the *User’s Guide* included in the software CD-ROM for help on using the product with a computer.

Error Messages

You can diagnose and solve most problems by checking the messages on the LCD screen. If you cannot solve the problems by checking the messages, use the following table and try the recommended solution.

LCD Screen		Cause	Solution
Icon	Text		
		The ink cartridge is expended.	Change the expended ink cartridges (➔ “Replacing Ink Cartridges” on page 19).
		The ink cartridge is not installed or not installed correctly.	Install the ink cartridges correctly (➔ “Replacing Ink Cartridges” on page 19).
		No paper is loaded in the sheet feeder.	Load paper in the sheet feeder. Then press ⬠ Start to continue or Ⓞ Stop/Clear to cancel (➔ “Loading Paper” on page 6).
		Paper is jammed.	Clean the jam, then press ⬠ Start (➔ “Paper feed problems” on page 27).
		The index sheet was not recognized because it is not positioned correctly.	Position the index sheet correctly on the document table, aligning the top of it with the left edge of the glass. Then press ⬠ Start to continue or Ⓞ Stop/Clear to cancel. The index sheet was not printed correctly. Print the index sheet, mark it, and try again (➔ “Selecting and Printing Photos Using an Index Sheet” on page 16).
		The index sheet is marked incorrectly.	Remove the index sheet, mark it correctly, and try again (➔ “2. Selecting photos from the index sheet” on page 17).
		The index sheet does not match the photos on the memory card.	Remove the memory card and insert the card used to print the index sheet - or place the correct index sheet on the document table. Then press ⬠ Start to continue or Ⓞ Stop/Clear to cancel.

LCD Screen		Cause	Solution
Icon	Text		
		An error occurred during photo pre-scanning.	Check that the photo is placed correctly and try again (➔ “Placing Originals on the Document Table” on page 8).
		Not enough ink to perform head cleaning.	Replace with new ink cartridges (➔ “Replacing Ink Cartridges” on page 19).
		There is a problem with the product.	Turn the product off and then back on. If the error does not clear, contact your dealer (➔ “Contacting Customer Support” on page 29).
		Waste ink pad in the product is saturated.	Contact your dealer to replace it (➔ “Contacting Customer Support” on page 29).
			
		The memory card does not contain any valid photos.	Remove the memory card (➔ “Handling a Memory Card” on page 12).
		Memory card error.	Remove the memory card (➔ “Handling a Memory Card” on page 12).
		The connected camera is not recognized.	Check the connection and try again (➔ “Printing from a Digital Camera” on page 18).
		The paper thickness lever is set to the wrong position.	Set the paper thickness lever to the correct position and try again. If you are printing on paper, move the lever to the □ position. If you are printing on envelopes, move the lever to the ☒ position.
		No memory card is inserted.	Insert a valid memory card and try again (➔ “Handling a Memory Card” on page 12).

Problems and Solutions

Check the solutions below if you are having problems using the product.

Setup problems

The product makes noise after you turn it on.

- Make sure the protective tape is not blocking the print head. After releasing the print head, turn off the power, wait a moment, then turn it back on.

The product makes noise after ink cartridge installation.

- When you install ink cartridges, the ink delivery system must be charged. Wait until charging is finished, then turn off the product. If you turn it off too soon, it may use extra ink the next time you turn it on.
- Make sure the ink cartridges are seated securely and no protective material remains in the product. Open the cartridge cover and push the cartridges down until they click into place. Turn off the power, wait a moment, then turn it back on.

A screen that prompts you to restart the computer did not display after finishing the software installation.

- The software has not been installed correctly. Eject and insert the CD-ROM, and then install the software again.

Printing and copying problems

The product makes printing sounds, but nothing prints.

- The print head nozzles may need cleaning (➔ “Checking the print head” on page 22).
- Make sure the product is on a flat, stable surface.

The margins are incorrect.

- Make sure your original is positioned in the top left corner of the document table.
- If the edges of the copy are cropped off, move the original away from the corner slightly.
- Make sure the paper size settings are correct for the paper you have loaded.
- Make sure your paper is loaded short edge first, all the way to the right, with the left edge guide lightly against the paper (➔ “Loading Paper” on page 6).

- Do not load paper above the \cong arrow mark inside the left edge guide (➔ “Loading Paper” on page 6).

Blank pages are printed.

- Make sure the paper size settings are correct for the paper you have loaded.
- The print head nozzles may need cleaning (➔ “Cleaning the print head” on page 23).

Paper feed problems

Paper does not feed correctly or is jammed.

- If paper does not feed, remove it from the sheet feeder. Fan the paper, load it against the right side, and slide the left edge guide against the paper (but not too tightly). Make sure the paper is not in front of the feeder guard.
- Do not load paper above the \cong arrow mark inside the left edge guide (➔ “Loading Paper” on page 6).
- If paper is jammed, the icon or the message is displayed on the LCD screen. Follow these steps to clear the jam:
 1. Press the \diamond **Start** button to eject the jammed paper. If the jammed paper is not ejected, go on to the next step.
 2. If the paper is stuck near the sheet feeder or output tray, gently pull it out then press the \diamond **Start** button.

If the paper is stuck inside the product, press the \odot **On** button to turn it off. Open the scanner unit and remove any paper inside, including any torn pieces. Do not pull it backward; this can damage the sheet feeder. Close the scanner unit, then turn the product back on.

- If paper jams frequently, make sure the left edge guide is not pushed too tightly against the paper. Try loading fewer sheets of paper.

Print quality problems

You see banding (light lines) in your printouts or copies.



- Clean the print head (➔ “Checking the print head” on page 22).
- Make sure you select the correct paper type (➔ “Selecting Paper” on page 6).
- Make sure the printable (whiter or glossier) side of the paper is face-up.
- The ink cartridges may need replacing (➔ “Removing and installing ink cartridges” on page 20).
- Align the print head (➔ “Aligning the Print Head” on page 23).
- Clean the document table (➔ “Cleaning This Product” on page 24).

Your printout is blurry or smeared.



- Make sure the document is placed flat against the document table. If only part of the image is blurred, your original may be wrinkled or warped.
- Make sure the product is not tilted or placed on an uneven surface.
- Make sure your paper is not damp, curled, or loaded face-down (the whiter or glossier printable side should be face-up). Load new paper face-up.
- Use a support sheet with special paper or try loading your paper one sheet at a time.
- Load your paper one sheet at a time. Remove sheets from the output tray so not too many collect at a time.
- Align the print head (➔ “Aligning the Print Head” on page 23).
- Make several copies without placing a document on the document table.
- Use only paper recommended by Epson and genuine Epson cartridges.
- Set the paper thickness lever to the position for most paper types. If you are printing on envelopes, set the lever to the position.

- Clean the document table (➔ “Cleaning This Product” on page 24).

Your printout is faint or has gaps.

- Clean the print head (➔ “Cleaning the print head” on page 23).
- If you notice jagged vertical lines, you may need to align the print head (➔ “Aligning the Print Head” on page 23).
- The ink cartridges may be old or low on ink. Replace the ink cartridges (➔ “Replacing Ink Cartridges” on page 19).
- Make sure you select the correct paper type (➔ “Selecting Paper” on page 6).
- Make sure your paper is not damaged, old, dirty, or loaded face-down. If it is, load new paper with the whiter or glossier side face-up.

Your printout is grainy.

- If you are printing or copying a photo, make sure you are not enlarging it too much. Try printing it smaller.
- Align the print head (➔ “Aligning the Print Head” on page 23).

You see incorrect or missing colors.

- Clean the print head (➔ “Cleaning the print head” on page 23).
- The ink cartridges may be old or low on ink. Replace the ink cartridges (➔ “Replacing Ink Cartridges” on page 19).
- Make sure you loaded the right paper and selected the correct setting for it on the control panel.

The image size or position is incorrect.

- Make sure you loaded the right paper and selected the correct setting for it on the control panel.
- Make sure the original is placed correctly on the document table (➔ “Placing Originals on the Document Table” on page 8).
- Clean the document table (➔ “Cleaning This Product” on page 24).

Other problems

When you turn off the product, a red lamp inside the product may remain on.

- The lamp will stay on for a maximum of 15 minutes, then go out automatically. This does not indicate malfunction.

Contacting Customer Support

Regional customer services

If your Epson product is not operating properly and you cannot solve the problem using the troubleshooting information in your product documentation, contact customer support services for assistance. If customer support for your area is not listed below, contact the dealer where you purchased your product.

Customer support will be able to help you much more quickly if you give them the following information:

- Product serial number
(The serial number label is usually on the back of the product.)
- Product model
- Product software version
(Click **About**, **Version Info**, or a similar button in the product software.)
- Brand and model of your computer
- Your computer operating system name and version
- Names and versions of the software applications you normally use with your product

Note:























For more information on contacting customer support, see the online *User's Guide*.

Europe	
URL	http://www.epson.com Select the Support section of your local EPSON web site for the latest drivers, FAQs, manuals and other downloadables.
Check your Pan-European Warranty Document for information on how to contact EPSON Customer support.	
Australia	
URL	http://www.epson.com.au
Telephone	1300 361 054
Fax	(02) 8899 3789
Singapore	
URL	http://www.epson.com.sg
Telephone	(65) 6586 3111











Thailand	
URL	http://www.epson.co.th
Telephone	(66)2-670-0333
Vietnam	
Telephone	84-8-823-9239
Indonesia	
URL	http://www.epson.co.id
Telephone/ Fax	Jakarta: (62) 21-62301104
	Bandung: (62) 22-7303766
	Surabaya: (62) 31-5355035/31-5477837
	Medan: (62)61-4516173
Telephone	Yogyakarta: (62) 274-565478
	Makassar: (62)411-350147/411-350148
Hong Kong	
URL	http://www.epson.com.hk
Phone	(852) 2827-8911
Fax	(852) 2827-4383
Malaysia	
URL	http://www.epson.com.my
Phone	603-56288333
India	
URL	http://www.epson.co.in
Phone	30515000
FAX	30515005/30515078
Philippines	
URL	http://www.epson.com.ph
Phone	(63) 2-813-6567
Fax	(63) 2-813-6545
E-mail	epchelpdesk@epc.epson.com.ph

Panel Icon List







Error Message









Display		Meaning
Icon	Text	
		The ink cartridge is expended. Change the expended ink cartridges.
		The ink cartridge is not installed. Install the ink cartridge correctly.
		Paper out. No paper is loaded in the sheet feeder.
		Paper is jammed. Clear paper jam, then press the Start button.
		Index sheet error. Position the index sheet correctly.
		Index sheet error. Fill in the circles correctly.
		Index sheet error. The index sheet does not match the photos on the memory card. Check the memory card.
		Pre-scanning error. Check photo placement.
		Not enough ink to perform head cleaning. Replace with new ink cartridges.
		Mechanical error. Contact your dealer.
		Waste ink pad in the product is saturated. Contact your dealer.

Warning Message







Display		Meaning
Icon	Text	
		Waste ink pad in the product is saturated. Contact your dealer.
		No photo data on the memory card. Check data on the memory card.
		Memory card error. Check the memory card.
		Cannot recognize camera. Check connection.
		Paper thickness lever position error. Set the paper thickness lever correctly.

Information







Display		Meaning
Icon	Text	
		Insert a memory card.
		PictBridge camera connected.
		USB DIRECT-PRINT camera connected.





Display		Meaning
Icon	Text	
		Paper thickness lever position was changed.
		
		Ink cartridge status
		PC connected.

Common

Display		Meaning
Icon	Text	
		Ink low indicator.
		Ink low indicator (when printing).
		Copying/printing a color copy.

Copy Mode

Display		Meaning
Icon	Text	
		Copies.
		Color copying.
		B&W copying.

Display		Meaning
Icon	Text	
		Copying/printing a B&W copy.
		Fit to page.

Memory Card Mode










































































Display		Meaning
Icon	Text	
		Print All.
		Print index sheet.
		Print from index sheet. Place the index sheet and then press the Start button.
		DPOF data found.

Photo Mode

Display		Meaning
Icon	Text	
		Restoration on.
		Restoration off.

Setup/Utilities Mode

Display	Meaning												
	<p>Check ink cartridge status.</p> <p>You can check the ink cartridge status.</p> <p>Press the Start button to enter this mode.</p>												
	<p>Check ink nozzles.</p> <p>You can print a nozzle check pattern.</p> <p>Press the Start button to enter this mode.</p>												
	<table border="1"> <thead> <tr> <th>Icon</th> <th>Text</th> <th>Printing nozzle check pattern.</th> </tr> </thead> <tbody> <tr> <td></td> <td></td> <td></td> </tr> </tbody> </table>	Icon	Text	Printing nozzle check pattern.									
Icon	Text	Printing nozzle check pattern.											
													
	<p>Clean print head.</p> <p>You can clean the print head.</p> <p>Press the Start button to enter this mode.</p>												
	<p>Copy Quality</p> <p>You can select the copy quality.</p> <p>Press the Start button to enter this mode.</p>												
	<table border="1"> <thead> <tr> <th>Icon</th> <th>Text</th> <th>Quality</th> </tr> </thead> <tbody> <tr> <td></td> <td></td> <td>Normal</td> </tr> <tr> <td></td> <td></td> <td>Draft</td> </tr> <tr> <td></td> <td></td> <td>Photo</td> </tr> </tbody> </table>	Icon	Text	Quality			Normal			Draft			Photo
Icon	Text	Quality											
		Normal											
		Draft											
		Photo											
	<p>Date</p> <p>You can print the date on your photo.</p> <p>Press the Start button to enter this mode.</p>												
	<table border="1"> <tbody> <tr> <td></td> <td>No date</td> </tr> <tr> <td></td> <td>2006.06.16</td> </tr> <tr> <td></td> <td>Jun.16.2006</td> </tr> <tr> <td></td> <td>16.Jun.2006</td> </tr> </tbody> </table>		No date		2006.06.16		Jun.16.2006		16.Jun.2006				
	No date												
	2006.06.16												
	Jun.16.2006												
	16.Jun.2006												

Display	Meaning						
	<p>Change Cartridges.</p> <p>You can change the ink cartridges.</p> <p>Press the Start button to enter this mode.</p>						
	<p>Press the Start button, and then open the scanner unit.</p>						
	<p>Change ink cartridges.</p>						
	<p>Close the scanner unit, and then press the Start button.</p>						
	<p>Align print head.</p> <p>You can align the print head.</p> <p>Press the Start button to enter this mode.</p>						
	<table border="1"> <thead> <tr> <th>Icon</th> <th>Text</th> <th>Printing head alignment set pattern.</th> </tr> </thead> <tbody> <tr> <td></td> <td></td> <td></td> </tr> </tbody> </table>	Icon	Text	Printing head alignment set pattern.			
Icon	Text	Printing head alignment set pattern.					
							
	<p>Set head alignment.</p>						
	<p>Change LCD contrast.</p> <p>You can change the LCD contrast.</p> <p>Press the Start button to enter this mode.</p>						
<p>Text display users only</p> 	<p>Display</p> <p>You can select the display settings.</p> <p>Press the Start button to enter this mode.</p>						
	<table border="1"> <tbody> <tr> <td></td> <td>Icons only are displayed on the LCD screen.</td> </tr> <tr> <td></td> <td>Icons and text are displayed on the LCD screen.</td> </tr> </tbody> </table>		Icons only are displayed on the LCD screen.		Icons and text are displayed on the LCD screen.		
	Icons only are displayed on the LCD screen.						
	Icons and text are displayed on the LCD screen.						

EPSON

EXCEED YOUR VISION



MEMORY STICK PRO™



Purchasing ink cartridges

Product name	Black	Cyan	Magenta	Yellow
DX6000 series	T0711	T0712	T0713	T0714
CX5900 series	T0731	T0732	T0733	T0734



410739800