



**WF-M1561**

# Basic Guide

---

# Ink Cartridge Code

	<p><b>BK (Black)</b></p> <p>251</p>
---	-------------------------------------

---

## Contents

### **Introduction..... 2**

- Where to Find Information..... 2
- Caution, Important and Note..... 2

### **Safety Instructions..... 2**

### **Control Panel Overview..... 3**

- Buttons and LCD..... 3
- Lights..... 4

### **Paper and Media Handling..... 5**

- Selecting Paper..... 5
- Loading Paper..... 5
- Placing Originals..... 6
  - Automatic Document Feeder (ADF)..... 6
  - Scanner glass..... 7

### **Copying..... 7**

### **Scanning..... 8**

### **Faxing..... 8**

- Introducing FAX Utility..... 8
- Connecting to a Phone Line..... 8
  - About a phone cable..... 8
  - Using the phone line for fax only..... 9
  - Sharing line with phone device..... 9
  - Checking the fax connection..... 9
- Setting Up Fax Features..... 10
  - Setting up speed dial entries..... 10
  - Setting up group dial entries..... 10
- Sending Faxes..... 10
- Receiving Faxes..... 11
- Printing Reports..... 11

### **Replacing Ink Cartridges..... 12**

- Safety instructions..... 12
- Precautions..... 12
- Replacing an Ink Cartridge..... 13

### **Basic Troubleshooting..... 15**

- Error Messages..... 15
- Paper Jams..... 16
  - Removing jammed paper from inside the product..... 16
  - Removing jammed paper from the Automatic Document Feeder (ADF)..... 16
- Print Quality Help..... 18
- Faxing Help..... 18

### **Where To Get Help..... 18**

- Technical Support Web Site..... 18

---



---

# Introduction

---



---

## Where to Find Information

The latest version of the following manuals are available on the Epson support website.  
<http://support.epson.net/>

**Start Here (paper):**

Provides you with information on setting up the product and installing the software.

**Basic Guide (paper):**

Provides you with basic information when you are using the product without a computer.

**User's Guide (PDF):**

Provides you with detailed operating, safety, and troubleshooting instructions. See this guide when using this product with a computer.  
 To view the PDF manual, you need Adobe Acrobat Reader 5.0 or later, or Adobe Reader.

**Network Guide (HTML):**

Provides network administrators with information on both the printer driver and network settings.

## Caution, Important and Note

Caution, Important, and Note in this manual are indicated as below and have the following meaning.



**Caution**

*must be followed carefully to avoid bodily injury.*



**Important**

*must be observed to avoid damage to your equipment.*

**Note**

*contain useful tips and restrictions on product operation.*

---



---

## Safety Instructions

---



---

Read and follow these instructions to ensure safe use of this product. Make sure you keep this guide for future reference. Also, be sure to follow all warnings and instructions marked on the product.

- Use only the power cord supplied with the product and do not use the cord with any other equipment. Use of other cords with this product or the use of the supplied power cord with other equipment may result in fire or electric shock.
- Be sure your AC power cord meets the relevant local safety standard.
- Never disassemble, modify, or attempt to repair the power cord, plug, printer unit, scanner unit, or options by yourself, except as specifically explained in the product's guides.
- Unplug the product and refer servicing to qualified service personnel under the following conditions: The power cord or plug is damaged; liquid has entered the product; the product has been dropped or the casing damaged; the product does not operate normally or exhibits a distinct change in performance. Do not adjust controls that are not covered by the operating instructions.
- Place the product near a wall outlet where the plug can be easily unplugged.
- Do not place or store the product outdoors, near excessive dirt or dust, water, heat sources, or in locations subject to shocks, vibrations, high temperature or humidity.
- Take care not to spill liquid on the product and not to handle the product with wet hands.
- Keep this product at least 22 cm away from cardiac pacemakers. Radio waves from this product may adversely affect the operation of cardiac pacemakers.


### Control Panel Overview

- ❑ If the LCD screen is damaged, contact your dealer. If the liquid crystal solution gets on your hands, wash them thoroughly with soap and water. If the liquid crystal solution gets into your eyes, flush them immediately with water. If discomfort or vision problems remain after a thorough flushing, see a doctor immediately.
- ❑ Avoid using a telephone during an electrical storm. There may be a remote risk of electric shock from lightning (for fax capable model).
- ❑ Do not use a telephone to report a gas leak in the vicinity of the leak (for fax capable model).

**Note:**  
 The following provides safety instructions for ink cartridges.  
 ➔ “Replacing Ink Cartridges” on page 12

## Control Panel Overview

**Note:**  
 Although the control panel design and menu and option names and other items in the LCD display may slightly differ from the actual product, the method of operation is the same.










\* emits a beep.



## Buttons and LCD

Buttons	Function
a	Turns the product on and off.
b	Enters copy mode.
c	Enters fax mode.
d	Enters scan mode.
e	- LCD screen
f	Press ◀, ▶, ▲, ▼ to select menus. Press <b>OK</b> to confirm the setting you have selected and go to next screen. When typing a fax number, ◀ acts as a backspace key, and ▶ inserts a space.

### Control Panel Overview

	Buttons	Function
g	0-9,*,#	Specifies the date/time or the number of copies, as well as fax numbers. Enters alphanumeric characters and switches between uppercase, lowercase, and numbers each time it is pressed. Press 1 symb to enter symbols such as the sharp sign (#), plus (+), and apostrophe (').
h		Displays speed dial/group dial lists. Press again to switch lists.
i		Displays the last number dialed. When entering numbers in fax mode, this inserts a pause symbol (-) that acts as a brief pause during dialing.
j		Stops the ongoing operation or initialize the current settings. If this button is pressed to cancel copying, scanning, or faxing while the ADF is in use, all originals in the ADF will be fed out.
k		Displays detailed settings for each mode.
l		Cancels/returns to the previous menu.
m		Displays the <b>Wi-Fi Setup</b> menus that allow you to set up the product wirelessly. For instructions on using the menus, see the Network Guide.
n		Start copying/faxing.

## Lights

Lights	Function
	On when the product is on. Flashes when the product is receiving data, printing/copying/scanning/faxing, replacing an ink cartridge, charging ink, or cleaning the print head.
	Stays on while the product is connected to a Wi-Fi network. Flashes while the Wi-Fi network settings are being made.
<b>ADF</b>	On when originals are detected in the ADF.

# Paper and Media Handling

## Selecting Paper


The product automatically adjusts itself for the type of paper you select in your print settings. That is why the paper type setting is so important. It tells your product what kind of paper you are using and adjusts the ink coverage accordingly. The table below lists the settings you should choose for your paper.

For this paper	LCD paper type
Plain paper	Plain Paper
Epson Bright White Ink Jet Paper	
Epson Matte Paper - Heavyweight	Matte


## Loading Paper

Follow these steps to load paper:

- 1 Flip the feeder guard forward.



- 2 Slide out the paper support and the output tray and then raise the stopper.




**Note:**

Leave enough space in front of the product for the paper to be fully ejected.

- 3 Slide the edge guide to the left.

- 4 Load paper with the printable side up, against the right side of the rear paper feed.




**Note:**

- Fan and align the edges of the paper before loading.
- The printable side is often whiter than the other side.
- Always load paper into the rear paper feed short edge first, even when you are printing landscape-oriented pictures.
- You can use the following sizes of paper with binding holes: A4, A5, A6, Legal, Letter. Load only 1 sheet of paper at a time.


Paper and Media Handling

- 5 Slide the edge guide against the left edge of the paper, but not too tightly.



**Note:**  
 For plain paper, do not load paper above the ▼ arrow mark inside the edge guide.  
 For Epson special media, make sure the number of sheets is less than the limit specified for the media.

- 6 Flip the feeder guard back.



**Note:**  
 For instructions on loading media other than plain paper, see the PDF User's Guide.

## Placing Originals

### Automatic Document Feeder (ADF)


You can load your original documents in the Automatic Document Feeder (ADF) to copy, scan, or fax multiple pages quickly. You can use the following originals in the ADF.

Size	A4/Letter/Legal
Type	Plain paper
Weight	64 g/m <sup>2</sup> to 95 g/m <sup>2</sup>
Capacity	Total thickness of 3 mm, up to about 30 sheets (Letter, A4) 10 sheets (Legal)


**! Important:**  
 To prevent paper jams, avoid the following documents. For these types, use the scanner glass.

- ❑ Documents held together with paper clips, staples, etc.
- ❑ Documents that have tape or paper stuck to them.
- ❑ Photos, OHPs, or thermal transfer paper.
- ❑ Paper that is torn, wrinkled, or has holes.

- 1 Make sure that there are no originals on the scanner glass. The ADF may not detect documents in the feeder if there are originals on the scanner glass.
- 2 Tap the originals on a flat surface to even the edges.




- 3 Slide the edge guide on the Automatic Document Feeder.






## Copying

- 4 Insert the originals face-up and short edge first into the Automatic Document Feeder.





- 5 Slide the edge guide until it is flush with the originals.




- 6 Check that the ADF light in the control panel is on.

**Note:**


- ❑ The ADF light may stay off if there is any other original on the scanner glass. If you press  in this case, the original on the scanner glass will be copied, scanned, or faxed instead of the originals in the ADF.
- ❑ The ADF light will not turn on when the product is in sleep mode. Press any button other than  to recover from sleep mode. It may take some time for the light to turn on after recovery from sleep mode.
- ❑ Be careful not to let any foreign object get inside the hole on the left front corner of the scanner glass. Doing so may prevent the ADF from operating.
- ❑ When you use the copy function with the Automatic Document Feeder (ADF), the print settings are fixed at Reduce/Enlarge - **Actual Size**, Paper Type - **Plain Paper**, and Paper Size - **A4/Legal**. The print is cropped if you copy an original larger than A4/Legal.

## Scanner glass

- 1 Open the document cover and place your original face-down on the scanner glass.







- 2 Slide the original to the corner.



- 3 Close the cover gently.

## Copying

Follow the steps below to copy documents.

- 1 Load paper.  
➔ "Loading Paper" on page 5
- 2 Place your original(s) in the Automatic Document Feeder or on the scanner glass.  
➔ "Placing Originals" on page 6
- 3 Press  to enter the copy mode.
- 4 Press  or  to set the number of copies.
- 5 Press  to display the copy setting menus.

6 Select the appropriate copy settings such as layout, paper size, paper type, and quality. Use ▲ or ▼ to select a setting item and then press **OK**. When finished, press **≡** again to return to the copy mode top screen.

7 Press **◇** to start copying.

---

## Scanning

---

You can scan documents and send the scanned image from the product to a connected computer. Make sure you have installed software for the product on your computer and connected to the computer.

- 1 Place your original(s) in the Automatic Document Feeder or on the scanner glass.
  - ➔ “Placing Originals” on page 6
- 2 Press **◇** to enter the scan mode.
- 3 Select a scan menu item. Use ▲ or ▼ to select a menu, and press **OK**.
- 4 Select your computer.

**Note:**

- If the product is connected to a network, you can select the computer to which you want to save the scanned image.
- You can change the computer name displayed on the control panel using *Epson Event Manager*.

5 Press **OK** to start scanning.

**Note:**

For more information on other scan functions and the scan mode menu list, see the *PDF User’s Guide*.

Your scanned image is saved.

---

## Faxing

---

**Note:**

Refer to the *PDF User’s Guide* for other faxing functions and the Fax mode menu list.

## Introducing FAX Utility

FAX Utility is a software capable of transmitting data such as documents, drawings, and tables created using a word processing or spreadsheet application directly by fax, without printing. Use the following procedure to run the utility.

**Windows**

Click the start button (Windows 7 and Vista) or click **Start** (Windows XP), point to **All Programs**, select **Epson Software**, and then click **FAX Utility**.

**Mac OS X**

Click **System Preference**, click **Print & Fax** or **Print & Scan**, and then select **FAX** (your product) from **Printer**. Then click as follows;  
 Mac OS X 10.6.x, 10.7.x: **Option & Supplies - Utility - Open Printer Utility**  
 Mac OS X 10.5.x: **Open Print Queue - Utility**

**Note:**

For more details, see the online help for FAX Utility.

## Connecting to a Phone Line

---

### About a phone cable


Use a phone cable with the following interface specification.

- RJ-11 Phone Line
- RJ-11 Telephone set connection

Depending on the area, a phone cable may be included with the product. If so, use that cable.

## Using the phone line for fax only

- 1 Connect a phone cable leading from a telephone wall jack to the LINE port.




- 2 Make sure **Auto Answer** is set to **On**.

➔ “Receiving Faxes” on page 11


**! Important:**  
If you do not connect an external telephone to the product, make sure you turn on auto answer. Otherwise, you cannot receive faxes.

## Sharing line with phone device


- 1 Connect a phone cable leading from a telephone wall jack to the LINE port.



- 2 Remove the cap.



- 3 Connect a phone or answering machine to the EXT. port.



**Note:**  
See the PDF User’s Guide for other connection methods.

## Checking the fax connection

You can check whether the product is ready to send or receive faxes.

- 1 Load plain paper.  
➔ “Loading Paper” on page 5
- 2 Press to enter the fax mode.
- 3 Press to display the menus.
- 4 Select **Fax Settings > Check Fax Connection**.  
Use or to select a menu, and press **OK**.
- 5 Press to print the report.







**Note:**

If an errors are reported, try the solutions in the report.




## Setting Up Fax Features

### Setting up speed dial entries

You can create a speed dial list allowing you to select fax recipient numbers quickly when faxing. Up to 60 combined speed dial and group dial entries can be registered.

- 1 Press  to enter the fax mode.
- 2 Press  to display the menus.
- 3 Select the menu shown below. Use  or  to select a menu, and press **OK**.  
  
Select **Fax Settings > Speed Dial Setup**.
- 4 Select **Create**. You see the available speed dial entry numbers.
- 5 Select the speed dial entry number that you want to register. Use  or  to select a number, and press **OK**. You can register up to 60 entries.
- 6 Use the numeric keypad to enter a phone number, and press **OK**. You can enter up to 64 digits.











**Note:**

- Press  to enter a space. Press  to delete numbers. Press  to enter a hyphen (-).
- A hyphen ("-") causes a slight pause when dialing. Only include it in phone numbers when a pause is necessary. Spaces entered between numbers are ignored when dialing.


- 7 Enter a name to identify the speed dial entry. You can enter up to 30 characters.  
  
Press **OK** to register the name.

### Setting up group dial entries

You can add speed dial entries to a group, allowing you to send a fax to multiple recipients at the same time. Up to 60 combined speed dial and group dial entries can be entered.

- 1 Press  to enter the fax mode.
- 2 Press  to display the menus.
- 3 Select the menu shown below. Use  or  to select a menu, and press **OK**.  
  
Select **Fax Settings > Group Dial Setup**.
- 4 Select **Create**. You see the available group dial entry numbers.
- 5 Select the group dial entry number that you want to register. Use  or  to select a number, and press **OK**.
- 6 Enter a name to identify the group dial entry. You can enter up to 30 characters.  
  
Press **OK** to register the name.
- 7 Select a speed dial entry that you want to register in the group dial list. Use  or  to select the entry and press  to add it to the group.  
  
When you want to cancel the selection, press  again.
- 8 Repeat step 7 to add other speed dial entries to the group dial list. You can register up to 30 speed dial entries in a group dial.
- 9 Press **OK** to finish creating a group dial list.

### Sending Faxes




- 1 Place your original(s) in the Automatic Document Feeder or on the scanner glass.  
➔ "Placing Originals" on page 6
- 2 Press  to enter the fax mode.


## Faxing

- 3** Use the keys on the numeric keypad to enter the fax number. You can enter up to 64 digits.


If you want to send the fax to more than one recipient, press **OK** after entering a one fax number, and select **Yes** to add another fax number.

**Note:**

- ❑ To display the last fax number you used, press /☺.
- ❑ You can change fax quality and contrast settings. Press  and select **Quality** or **Contrast**. When finished, press  again to return to the fax mode top screen.
- ❑ Make sure you have entered the header information. Some fax machines automatically reject incoming faxes that do not include header information.

- 4** Press  to start sending.


**Note:**


If the fax number is busy or there is some problem, this product redials after one minute. Press /☺ to redial immediately.

## Receiving Faxes

Follow the instructions to make settings to receive faxes automatically. For instructions on receiving faxes manually, see the PDF User's Guide.

- 1** Load plain paper in the rear paper feed.  
➔ "Loading Paper" on page 5

- 2** Press  to enter the fax mode.



- 3** Press  to display the menus.

- 4** Make sure Auto Answer is set to On.



**Fax Settings > Send/Receive Setup > Auto Answer > On**

**Note:**

- ❑ When an answering machine is connected directly to this product, make sure you set **Rings to Answer** correctly using the following procedure.
- ❑ Depending on the region, **Rings to Answer** may be unavailable.

- 5** Press  and  to select **Communication** and press **OK**.

- 6** Select **Rings to Answer** and press **OK**.

- 7** Press  or  to select the number of rings and press **OK**.

**! Important:**

Select more rings than needed for the answering machine to pick up. If it is set to pick up on the fourth ring, set the product to pick up on the fifth ring or later. Otherwise the answering machine cannot receive voice calls.


**Note:**


When you receive a call and the other party is a fax, the product receives the fax automatically even if the answering machine picks up the call. If you pick up the phone, wait until the LCD screen displays a message saying that a connection has been made before you hang up. If the other party is a caller, the phone can be used as normal or a message can be left on the answering machine.

## Printing Reports

Follow the instructions below to print a fax report.

- 1** Load plain paper in the rear paper feed.  
➔ "Loading Paper" on page 5

- 2** Press  to enter the fax mode.

- 3** Press  to display the menus.

## Replacing Ink Cartridges

- 4** Select the menu shown below. Use ▲ or ▼ to select a menu, and press **OK**.

Select **Fax Settings** > **Print Report**.

- 5** Select the item you want to print.

**Note:**

Only **Fax Log** can be viewed on the screen.

- 6** Press ◊ to print the report you selected.

**Note:**

For more information on other fax functions and the fax mode menu list, see the *PDF User's Guide*.

---



---

# Replacing Ink Cartridges

---



---

## Safety instructions

- ❑ Keep ink cartridges out of the reach of children.
- ❑ Be careful when you handle used ink cartridges, as there may be some ink around the ink supply port. If ink gets on your skin, wash the area thoroughly with soap and water. If ink gets into your eyes, flush them immediately with water. If discomfort or vision problems continue after a thorough flushing, see a doctor immediately. If ink gets into your mouth, spit it out immediately and see a doctor right away.


## Precautions

- ❑ Epson recommends the use of genuine Epson ink cartridges. Epson cannot guarantee the quality or reliability of non-genuine ink. The use of non-genuine ink may cause damage that is not covered by Epson's warranties, and under certain circumstances, may cause erratic product behavior. Information about non-genuine ink levels may not be displayed.

- ❑ You cannot use the cartridge that came with your product for the replacement.
- ❑ To maintain optimum print head performance, some ink is consumed from a cartridge not only during printing but also during maintenance operations such as ink cartridge replacement and print head cleaning.
- ❑ If you need to remove an ink cartridge temporarily, be sure to protect the ink supply area from dirt and dust. Store the ink cartridge in the same environment as the product. When storing the cartridge, be sure that its label identifying the color of the ink cartridge is facing upward. Do not store ink cartridges upside down.
- ❑ For maximum ink efficiency, only remove an ink cartridge when you are ready to replace it. An ink cartridge with low ink status may not be used when reinserted.
- ❑ Do not open the ink cartridge package until you are ready to install it in the product. The cartridge is vacuum packed to maintain its reliability. If you leave a cartridge unpacked for a long time before using it, normal printing may not be possible.

# Replacing an Ink Cartridge

- 1 When prompted to replace an ink cartridge, open the scanner unit and press **OK**. The ink cartridge holder moves to the ink cartridge replacement position. When you replace an ink cartridge before it is expended, follow the instruction below. Press **≡** and select **Maintenance > Ink Cartridge Replacement**.




**!** **Important:**

- ❑ Do not lift up the scanner unit when the document cover is open.



- ❑ Do not move the ink cartridge holder by hand; otherwise, you may damage the product.


- 2 Pinch and remove the ink cartridge.



**Note:**

A removed ink cartridge may have ink around the ink supply port, so be careful not to get any ink on the surrounding area when removing the cartridge.


- 3 Gently shake a new replacement cartridge four or five times and then unpack.




## Replacing Ink Cartridges

**! Important:**

- ❑ Be careful not to break the hooks on the side of the ink cartridge when you remove it from the package.
- ❑ Do not touch the green IC chip or the small window on the cartridge. Doing so may prevent normal operation and printing.




**4** Remove only the yellow tape.



**! Important:**


- ❑ You must remove the yellow tape from the cartridge before installing it; otherwise, print quality may decline or you may not be able to print.
- ❑ If you have installed an ink cartridge without removing the yellow tape, take the cartridge out of the product, remove the yellow tape, and then reinstall it.
- ❑ Do not remove the transparent seal from the bottom of the cartridge; otherwise, the cartridge may become unusable.
- ❑ Do not remove or tear the label on the cartridge; otherwise, ink will leak.

**5** Insert the cartridge and press it until it clicks.



**6** Close the scanner unit slowly and press **OK**. Ink charging starts.

**Note:**

- ❑ The  light continues to flash while the product is charging ink. Do not turn off the product during ink charging. If the ink charging is incomplete, you may not be able to print.
- ❑ If you had to replace an ink cartridge during copying, to ensure copy quality after ink charging is finished, cancel the job that is copying and start again from placing the originals.


Ink cartridge replacement is complete. The product will return to its previous status.



# Basic Troubleshooting

## Error Messages

This section describes the meaning of messages displayed on the LCD screen.

Error Messages	Solutions
Paper jam Press OK. If the error does not clear, remove the paper by hand.	Remove the jammed paper. ➔ "Paper Jams" on page 16
Paper jam in the ADF. Remove the jammed paper.	
Communication error. Make sure the cable is connected, then try again.	Make sure the computer is connected correctly. If the error messages still appears, make sure that scanning software is installed on your computer and that the software settings are correct.
Printer error Paper jam. Open the scanner unit and remove the paper, then turn off the printer. See your documentation.	Turn the product off and then back on. Make sure that no paper is still in the product. If the error message still appears, contact Epson support.
ADF Error. Remove any objects or documents inside ADF. Turn power off. See documentation.	
Printer error See your documentation.	
Scanner error See your documentation.	Turn the product off and then back on. If the error message still appears, contact Epson support.
A fax error has occurred. See your documentation.	
A printer's ink pad is nearing the end of its service life. Please contact Epson Support.	Press <b>OK</b> to resume printing. The message will be displayed until the ink pad is replaced.  Contact Epson support to replace ink pads before the end of their service life. When the ink pads are saturated, the product stops and Epson support is required to continue printing.
A printer's ink pad is at the end of its service life. Please contact Epson Support.	Contact Epson support to replace the ink pad.
No dial tone. Fax job incomplete.	Make sure the phone cable is connected correctly and the phone line works.  ➔ "Connecting to a Phone Line" on page 8  If you connected the product to a PBX (Private Branch Exchange) phone line or Terminal Adapter, turn off the <b>Dial Tone Detection</b> .  ➔ Press  and then  . Then select <b>Fax Settings &gt; Communication &gt; Dial Tone Detection</b> .

Basic Troubleshooting

Error Messages	Solutions
Recovery Mode	The firmware update has failed. You will need to re-attempt the firmware update. Ready a USB cable and visit your local Epson website for further instructions.

## Paper Jams



**Caution:**


Never touch the buttons on the control panel while your hand is inside the product.

**Note:**

- ❑ Cancel the print job if prompted by a message from the LCD screen or the printer driver.
- ❑ After you have removed the jammed paper, press the button indicated in the LCD screen.

### Removing jammed paper from inside the product

- 1 Open the scanner unit.




**Important:**

Do not lift up the scanner unit when the document cover is open.



- 2 Remove all of the paper inside, including any torn pieces.




- 3 Close the scanner unit slowly.

### Removing jammed paper from the Automatic Document Feeder (ADF)

- 1 Remove the stack of paper from the ADF input tray.


Basic Troubleshooting

- 2 Open the ADF cover.




**!** **Important:**  
Make sure you open the ADF cover before removing jammed paper. If you do not open the cover, the product may be damaged.


- 3 Carefully remove the jammed paper.



- 4 Open the Automatic Document Feeder (ADF).




- 5 Remove all of the paper inside, including any torn pieces.




- 6 Close the Automatic Document Feeder (ADF).

- 7 Raise the ADF input tray.




- 8 Carefully remove the jammed paper.




- 9 Return the ADF input tray to its original position, and close the ADF cover.

## Print Quality Help

If you see banding (light lines), or any other quality problems in your printouts, try the following solutions.

- Make sure you have loaded the paper and place your original correctly.
  - ➔ “Loading Paper” on page 5
  - ➔ “Placing Originals” on page 6
- Check the paper size settings and the paper type settings.
  - ➔ “Selecting Paper” on page 5
- The print head may be clogged. Perform a nozzle check first and then clean the print head. Press  and select **Maintenance > Nozzle Check**.



- (a) OK  
(b) Needs a head cleaning

## Faxing Help

- Make sure the phone cable is connected correctly and check that the phone line works. You can check the line status by using the **Check Fax Connection** function.
  - ➔ “Connecting to a Phone Line” on page 8
- If the fax did not send, make sure that the recipient’s fax machine is turned on and working.
- If this product is not connected to a phone and you want to receive faxes automatically, make sure you turn on auto answer.
  - ➔ “Receiving Faxes” on page 11

**Note:**

For more solutions to faxing problems, see the online User’s Guide.

## Where To Get Help

### Technical Support Web Site

Epson’s Technical Support Web Site provides help with problems that cannot be solved using the troubleshooting information in your product documentation. If you have a Web browser and can connect to the Internet, access the site at:

<http://support.epson.net/>

If you need the latest drivers, FAQs, manuals, or other downloadables, access the site at:

<http://www.epson.com>

Then, select the support section of your local Epson Web site.

**Note:**

If your Epson product is not operating properly and you cannot solve the problem using the troubleshooting information in your product’s documentation, contact Epson support services for assistance. See the User’s Guide for Epson support information.

## Copyright Notice

No part of this publication may be reproduced, stored in a retrieval system, or transmitted in any form or by any means, electronic, mechanical, photocopying, recording, or otherwise, without the prior written permission of Seiko Epson Corporation. The information contained herein is designed only for use with this product. Epson is not responsible for any use of this information as applied to other printers.

Neither Seiko Epson Corporation nor its affiliates shall be liable to the purchaser of this product or third parties for damages, losses, costs, or expenses incurred by the purchaser or third parties as a result of accident, misuse, or abuse of this product or unauthorized modifications, repairs, or alterations to this product, or (excluding the U.S.) failure to strictly comply with Seiko Epson Corporation's operating and maintenance instructions.

Seiko Epson Corporation shall not be liable for any damages or problems arising from the use of any options or any consumable products other than those designated as Original Epson Products or Epson Approved Products by Seiko Epson Corporation.

Seiko Epson Corporation shall not be held liable for any damage resulting from electromagnetic interference that occurs from the use of any interface cables other than those designated as Epson Approved Products by Seiko Epson Corporation.

EPSON® is a registered trademark, and EPSON EXCEED YOUR VISION or EXCEED YOUR VISION is a trademark of Seiko Epson Corporation.

General Notice: Other product names used herein are for identification purposes only and may be trademarks of their respective owners. Epson disclaims any and all rights in those marks.

© 2012 Seiko Epson Corporation. All rights reserved.  
Printed in XXXXXX



\*412375300\*