

Safety Instructions

Read all of the instructions in this section when setting up and using this product.

When placing this product

- ❑ Avoid places subject to rapid changes in temperature and humidity. Also, keep this product away from direct sunlight, strong light, and heat sources.
- ❑ Avoid places subject to dust, shocks, and vibrations.
- ❑ Leave enough room around this product for sufficient ventilation.
- ❑ Place this product near a wall outlet where you can easily plug in and unplug this product.
- ❑ Place this product on a flat, stable surface that extends beyond this product base in all directions. If you place this product by the wall, leave more than 10 cm between the back of this product and the wall. This product will not operate properly if it is tilted at an angle.
- ❑ When storing or transporting this product, do not tilt it, stand it on its side, or turn it upside down; otherwise, ink may leak from the cartridge.

When choosing a power source

- ❑ Use only the type of power source indicated on the label on the back of this product.
- ❑ Use only the power cord that comes with this product. Use of another cord may cause fire or electric shock.
- ❑ This product's power cord is for use with this product only. Use with other equipment may cause fire or electric shock.
- ❑ Be sure your AC power cord meets the relevant local safety standards.
- ❑ Do not use a damaged or frayed power cord.
- ❑ If you use an extension cord with this product, make sure that the total ampere rating of the devices plugged into the extension cord does not exceed the cord's ampere rating. Also, make sure that the total ampere rating of all devices plugged into the wall outlet does not exceed the wall outlet's ampere rating.

When handling ink cartridges

- ❑ Do not shake the ink cartridge after removing from the package; this can cause leakage.
- ❑ Keep the ink cartridge out of the reach of children. Do not allow children to handle it, or drink ink.
- ❑ Be careful when you handle used ink cartridges, as there may be some ink remaining around the ink supply port. If ink gets on your skin, wash the area thoroughly with soap and water. If ink gets into your eyes, flush them immediately with water. If discomfort or vision problems remain after a thorough flushing, see a doctor immediately.
- ❑ Do not remove or tear the label on the cartridge; otherwise, ink will leak.

When using this product

- ❑ Do not put your hand inside this product or touch the ink cartridges during printing.
- ❑ Do not block or cover the openings on this product.
- ❑ Do not attempt to service this product by yourself.
- ❑ Unplug this product and refer servicing to qualified service personnel under the following conditions:
The power cord or plug is damaged; liquid has entered into this product; this product has been dropped or the cover damaged; this product does not operate normally or exhibits a distinct change in performance.
- ❑ Do not insert objects into the slots on this product.
- ❑ Never spill liquid on this product.

安全性說明

當您在安裝和使用這台機器之前，請先詳細閱讀下列的指示說明。

當選擇放置這台機器的位置時

- ❑ 請避免將這台機器放置在溫度、溼度變化很大的環境下。
另外，請將這台機器放置在遠離陽光、強光的照射或是其它熱源之處。
- ❑ 請避免將這台機器放置在灰塵多、晃動或不平穩的地方。
- ❑ 請確定這台機器的四週有足夠的空間，並保持這台機器周圍空氣的流通。
- ❑ 請將這台機器放置在靠近牆壁電源插座，方便拔掉電源線的地方。
- ❑ 請將這台機器放置在平坦、穩固而且空間大於這台機器本體的地方。
若這台機器放置在靠近牆壁的地方，請和牆壁保持 10cm 的距離。
- ❑ 當儲存或搬運這台機器時，請勿傾斜或上下顛倒放置，否則，墨水可能會溢出。

當選擇電源插座時

- ❑ 請只使用這台機器所標示的電力規格。
- ❑ 請只使用這台機器所附贈的電源線。
- ❑ 這台機器所附贈的電源線只適用於這台機器。
- ❑ 請確定電源線是符合當地的安全標準。
- ❑ 請不要使用有損壞或磨損的電源線。
- ❑ 如果您使用延長線，請確定延長線上所有機器設備在使用時所耗費的安培數沒有超過這條延長線所能負載的總安培數。

當處理墨水卡匣時

- ❑ 將墨水卡匣從包裝袋中取出後，請不要搖晃；否則墨水可能會外漏。
- ❑ 請將墨水卡匣放置在孩童無法拿到之處，避免孩童誤飲到墨水或是觸碰到墨水卡匣。
- ❑ 處理使用過的墨水卡匣時，請特別小心，因為可能有少許的墨水殘留在墨水孔周圍。
當皮膚不小心沾到墨水時，請用肥皂及清水徹底沖洗乾淨。如果墨水不慎濺入眼睛，請以大量的清水沖洗眼睛。若在清洗過後，眼部仍感到不適，請立即就醫。
- ❑ 請不要撕除墨水卡匣上的標籤，否則墨水可能會外漏。

當使用這台機器時

- ❑ 列印時，請不要將手伸入這台機器內或用手觸碰印字頭。
- ❑ 請不要堵塞或遮蓋這台機器上的凹槽。
- ❑ 請不要嘗試自行維修這台機器。
- ❑ 當這台機器發生下列的情況時，請拔下機器的電源線並洽詢 EPSON 授權維修中心：
電源線或插頭已受損；有液體濺入多功能事務機內；機體不慎掉落或機殼已經損壞；
多功能事務機無法正常運作或所呈現的列印效果與預期的結果有明顯的落差。
- ❑ 請不要將物體插入這台機器的插槽中。
- ❑ 請避免將液體潑灑在這台機器上。

안전 지시 사항

제품을 사용하거나 설치하기 전에 이 절의 지시사항들을 모두 읽으십시오.

제품을 설치할 때

- 온도나 습도의 변화가 급격한 곳에 제품을 설치하지 마십시오. 또한, 직사광선이나 강한 조명기구, 발열기구로 부터 제품을 보호하십시오.
- 먼지나 충격, 진동이 있는 장소에 제품을 설치하지 마십시오.
- 제품 주변에 충분한 공간을 남겨 통풍이 잘 되도록 하십시오.
- 플러그를 쉽게 꽂고 뽑을 수 있는 벽면 콘센트 부근에 제품을 설치하십시오.
- 본 제품은 받침대를 모든 방향으로 확장 가능한 평평하고 안정된 장소에 설치하십시오. 본 제품을 벽면에 설치할 경우에는 제품 후면과 벽 사이에 적어도 10cm 이상 띄우십시오. 제품이 기울어져 있으면 정상적으로 작동하지 않을 수 있습니다.
- 제품을 보관하거나 운반할 때 제품을 기울이거나 옆으로 세우거나 뒤집지 마십시오. 잉크가 썰 수도 있습니다.

전원을 연결할 때

- 제품의 뒷면에 부착되어 있는 라벨에 표시된 전원만 사용하십시오.
- 제품과 함께 동봉되어 있는 전원코드만 사용하십시오. 다른 코드를 사용할 경우 화재나 감전을 일으킬 수 있습니다.
- 본 제품의 전원코드는 본 제품에만 사용하십시오. 다른 장비에 사용할 경우 화재나 감전을 일으킬 수 있습니다.
- AC전원코드는 해당 지역의 안전규정에 적합한지 확인하십시오.
- 손상되거나 마모된 전원코드는 사용하지 마십시오.
- 멀티탭을 사용하여 전원을 연결하는 경우, 멀티탭에 연결된 총 전류량이 전원콘센트의 정격 전류량을 초과하지 않아야 합니다.

잉크 카트리지를 다룰 때

- 잉크 카트리지 포장을 제거한 후에는 흔들지 마십시오. 잉크가 썰 수 있습니다.
- 잉크 카트리지는 어린이의 손이 닿지 않는 곳에 보관하십시오. 어린이가 잉크 카트리지를 만지거나 마시지 않도록 주의하십시오.
- 다 사용한 잉크 카트리지를 다룰 때에는 잉크 공급 포트 주위에 남은 잉크가 묻어있을 수 있으니 주의하십시오. 잉크가 피부에 묻었을 경우, 비눗물로 깨끗하게 닦으십시오. 잉크가 눈에 들어간 경우에는 바로 흐르는 물로 씻어내십시오. 씻어낸 후에도 불편하거나 시력에 문제가 있는 경우에는 즉시 의사의 진찰을 받으십시오.
- 카트리지에 있는 라벨을 제거하거나 찢지 마십시오. 잉크가 썰 수도 있습니다.

제품을 사용할 때

- 인쇄 작업 중에 프린터 안으로 손을 넣거나 잉크 카트리지를 만지지 마십시오.
- 제품 본체의 구멍을 막거나 덮지 마십시오.
- 제품을 직접 수리하지 마십시오.
- 다음과 같은 상황이 발생하면, 제품의 플러그를 뽑고 전문 서비스 기술자에게 수리를 의뢰하십시오. 전원 코드나 플러그가 손상된 경우, 액체물질이 제품 내부로 흘러 들어간 경우, 제품을 떨어뜨렸거나 덮개가 망가진 경우, 제품이 정상적으로 작동하지 않거나 성능이 현저하게 저하된 경우.
- 제품의 슬롯에 이물질이 묻지 마십시오.
- 제품에 액체 물질을 엿지르지 마십시오.