


Start Here



PictureMate™ **PM 250**

1. Unpacking




Travel Case



Start Here



User's Guide



Portable Quick Guide







Photo Cartridge



AC Adapter



Power Cord



CD-ROM






Photo Paper


2. Turning On the Printer




Open




Remove




Close




Connect




Pull down




Open




Turn on




Raise




3. Installing the Photo Cartridge




Open




Unlock




Unpack




Insert




Click



Lock



Close



About 3.5 min.




Press





Note:

The photo cartridge first installed in your printer will be partly used to charge the print head. Subsequent photo cartridges will last for their full rated life.


4. Getting More Information Without Using a Computer




Portable Quick Guide



User's Guide







For Computer Users


Installing the software

Do not connect the USB cable until you are instructed to do so.



If this screen appears, click **Cancel**.

For Windows XP, XP x64, 2000, and Mac OS X



Insert

For Windows

For Mac OS X



Double-click




Click


Follow the instructions

☐ For Windows. No installation screen?

➔ Double-click the CD-ROM icon




When this screen appears, connect to your PC.



Connect

Follow the instructions



Installation complete.


For Windows Me and 98 SE

Download the printer driver.
<http://www.epson.com>




SETUP

Double-click **Setup.exe** and follow the on-screen instructions to install.




When this screen appears, connect to your PC.



Connect



Click




Insert



Click

Follow the instructions




Installation complete.

For information on using the printer with a computer, see the online User's Guide.



Double-click



User's Guide

