



Start Here


1. Unpacking




2. Removing Protective Tape




3. Unlocking and Turning On




4. Selecting a Language



5. Installing Ink Cartridges




6. Installing the Software




Making Copies

1. Loading Paper




2. Copying




Troubleshooting


Does not turn on



Does not print




Does not recognize




Features


Copying





Printing from Films





Memory Card, Camera, and Mobile Phone Printing



Printing



Scanning



Storing Film Holder

